



DTM-952R Windows CE Total Station
SMART MAX GEOSYSTEMS CO., LTD



| | |
|--|----|
| Forward..... | 1 |
| 1 Descriptions and functions of components of the instrument | 3 |
| 1.1 Component descriptions..... | 3 |
| 1.2 Display | 5 |
| 1.2.1 Main menu | 5 |
| 1.2.2 Measurement menu..... | 6 |
| 1.2.3 Display symbols | 7 |
| 1.2.4 Screen operation keys..... | 7 |
| 1.3 Operational keys | 8 |
| 1.4 Function keys (soft)..... | 9 |
| 1.5 Symbols | 10 |
| 1.6 Icons..... | 10 |
| 1.7 Star key (★) mode | 10 |
| 1.7.1 EDM..... | 11 |
| 1.7.2 VD..... | 12 |
| 1.7.3 Measurement parameter setting (temperature, air pressure, meteorological correction value (PPM), prism constant value (PSM) and reflector constant) | 12 |
| 1.7.4 Laser line | 13 |
| 1.7.5 Laser point | 13 |
| 1.7.6 Leveling | 14 |
| 2 Battery box mounting and charging | 15 |
| 2.1 Battery box mounting | 15 |
| 2.2 Charging of battery box | 15 |
| 3 Initial settings | 17 |
| 3.2 Laser plummet setting | 18 |
| 3.3 Prism constant setting | 19 |
| 3.4 Meteorological correction setting..... | 19 |
| 3.4.1 Calculation of meteorological correction value | 21 |
| 3.4.2 How to directly set meteorological correction value | 21 |
| 3.5 Reflector constant setting | 22 |
| 3.6 Atmospheric refraction and earth curvature correction..... | 23 |
| 4 Preparations prior to measurement..... | 23 |
| 4.1 Unpacking and storage of the instrument | 23 |
| 4.2 Erection of the instrument | 24 |
| 4.3 Turn on power switch..... | 26 |
| 4.4 Battery level icon..... | 26 |
| 4.5 Reflecting prism | 27 |
| 4.6 Disassembly and assembly of base | 28 |

| | |
|--|----|
| 4.7 Adjustment and aiming of telescope objective lens | 28 |
| 4.8 Vertical angle tilt correction | 29 |
| 4.9 Instrument system error compensation | 29 |
| 4.10 Methods for entering numbers and letters | 29 |
| 5 Meas mode | 31 |
| 5.1 Angle measurement | 33 |
| 5.1.1 Horizontal angle (right) and vertical angle measurement | 33 |
| 5.1.2 Horizontal angle measurement mode (right angle/left angle) switching | 34 |
| 5.1.3 Setting of horizontal limb reading | 35 |
| 5.1.4 Vertical angle grad mode | 36 |
| 5.2 Distance measurement | 36 |
| 5.2.1 Laser type setting | 36 |
| 5.2.2 Setting of meteorological correction, prism constant and non-prism constant | 37 |
| 5.2.3 Distance measurement (continuous) | 38 |
| 5.2.4 Distance measurement (N measurements) | 38 |
| 5.2.5 Fine measurement/tracking mode | 40 |
| 5.2.6 Lofting | 42 |
| 5.3 Coordinate measurement | 43 |
| 5.3.1 Setting of station coordinate and instrument height | 43 |
| 5.3.2 Prism height setting | 45 |
| 5.3.3 Coordinate measurement operations | 46 |
| 6 Programs mode (Applied measuring programs) | 48 |
| 6.1 Station setup | 50 |
| 6.1.1 Select job | 51 |
| 6.1.2 Orientation setting | 52 |
| 6.2 Measurement | 56 |
| 6.3 Traverse survey | 59 |
| 6.4 Remote elevation measurement | 63 |
| 6.5 Missing line measurement | 70 |
| 6.6 Repetition angle measurement | 73 |
| 6.7 Coordinate layout | 76 |
| 6.7.1 Layout point setting | 78 |
| 6.7.1.1 Coordinate extraction from job | 79 |
| 6.7.1.2 Manual entry of layout point | 80 |
| 6.7.2 Grid factor | 85 |
| 6.8 Resection | 87 |
| 6.9 Line measurement | 93 |
| 6.10 Offset measurement mode | 98 |

| | |
|--|-----|
| 6.10.1 Angle offset measurement mode | 98 |
| 6.10.2 Distance offset measurement mode | 102 |
| 6.10.3 Plane offset measurement mode | 105 |
| 6.10.4 Column offset measurement mode | 109 |
| 6.11 Road measurement mode | 112 |
| 6.11.1 Road designment | 113 |
| 6.11.1.1 Define horizontal alignment (100 data at most)..... | 114 |
| 6.11.1.2 Edit horizontal alignment..... | 121 |
| 6.11.1.3 Define vertical alignment (100 data at most)..... | 122 |
| 6.11.1.4 Edit vertical alignment | 123 |
| 6.11.2 Road layout | 124 |
| 6.11.2.1 Road layout menu | 125 |
| 6.11.2.2 Station setup for road layout..... | 126 |
| 6.11.2.3 Road curve layout..... | 129 |
| 6.11.3 Road file | 131 |
| 6.11.3.1 Save road file as..... | 132 |
| 6.11.3.2 Create new road file | 134 |
| 6.11.3.3 Delete road file..... | 136 |
| 6.11.3.4 Rename road file..... | 137 |
| 6.11.3.5 View road file..... | 139 |
| 6.12 Area measurement mode | 143 |
| 6.12.1 Calculate area with coordinate data file | 143 |
| 6.12.2 Calculate area with measurement data | 147 |
| 6.12.3 Conversion of display unit | 150 |
| 6.12.4 New area | 150 |
| 7 Manage mode..... | 151 |
| 7.1 Job | 152 |
| 7.1.1 Job deletion | 153 |
| 7.1.2 New job | 154 |
| 7.2 Fixpoints | 155 |
| 7.2.1 Fixpoint query | 156 |
| 7.2.2 New fixpoint | 157 |
| 7.2.3 Fixpoint modification | 159 |
| 7.2.4 Fixpoint deletion | 160 |
| 7.3 Meas. Data | 161 |
| 7.3.1 Measuring point query | 162 |
| 7.3.2 Measuring point viewing | 164 |
| 7.3.3 Measuring point deletion | 166 |

| | |
|---|-----|
| 7.4 Code | 167 |
| 7.4.1 New code | 167 |
| 7.4.2 Code query | 169 |
| 7.4.3 Code deletion | 170 |
| 7.5 Memory initialization | 173 |
| 8 Transfer mode | 175 |
| 8.1 Export data | 176 |
| 9 Configuration mode | 180 |
| 9.1 Work | 182 |
| 9.2 Regional | 185 |
| 9.3 Meas.Parameter | 188 |
| 9.4 Screen & Audio | 193 |
| 9.5 EDM | 195 |
| 9.6 Interface | 198 |
| 10 Tools mode | 201 |
| 10.1.1 Compensator adjustment | 202 |
| 10.1.2 Index error | 202 |
| 10.1.3 Instrument constant | 203 |
| 10.2 Info | 204 |
| 11 Inspection and calibration | 206 |
| 11.1 Level tube | 206 |
| 11.2 Circular vial | 207 |
| 11.3 Telescope reticle | 207 |
| 11.4 Perpendicularity of collimation axis and horizontal axis (2C) | 208 |
| 11.5 Vertical circle index zero automatic compensation | 209 |
| 11.6 Index error of vertical circle (angle i) and vertical circle index zero setting | 209 |
| 11.7 Optical plummet | 212 |
| 11.8 Instrument constant (K) | 213 |
| 11.9 Parallelism of collimation axis and emission electric-optical axis | 214 |
| 11.10 Base foot screw | 215 |
| 11.11 Assemblies for reflector prism | 215 |
| 12 Technical parameters | 216 |
| 13 Accessories | 219 |
| 14 [Annex] Road alignment element calculation | 220 |



Forward

Thank you for choosing our Wince total station!

This manual will introduce to you this new total station in detail. Please carefully read it before operating the instrument.

Features:

1. Menu graphics

Wince total station adopts icon menu featured with high degree of intelligence, powerful functions and easy operation. Measuring programs can be customized for users, meeting the various professional and engineering surveying requirements.

2. Absolute encoder

Absolute encoder is preinstalled and you can directly start measuring when the instrument is started. The angle data will not be lost even power supply is replaced halfway.

3. Powerful memory management

The high-capacity FLASH adopted can store tens of thousands of measured data or coordinate data and facilitate memory management, namely, addition, deletion, modification and transmission of data.

4. Lighter telescope lenses

As compared with the original model, the design of external and internal construction of this new generation of Wince total station is more scientific and rational and the telescope lenses are more compact, making it easier for measuring.

5. Preinstalled road measuring program

In addition to the common basic measuring modes and special measuring programs (remote elevation measurement, offset measurement, missing line measurement, distance layout, coordinate layout, resection and area measurement), the road measuring program is preinstalled, significantly facilitating control survey, topographic survey and engineering lofting.

6. English display (only for English version)

Wince total station (English version) adopts English display which is clear and beautiful, making it easy to operate the instrument.




Notes:


1. Avoid directly pointing the objective lens to the sun when exposed to sunlight. It is recommended to reduce the influence with sun filter lens.
2. When the laser goes to the target surface in a tilted manner, the measurement results may be inaccurate due to weakened or scattered laser.
3. In the case of road surveying, the instrument may not get the correct results due to interference from reflected laser from the front and rear.
4. Avoid storing the instrument at high or low temperature and temperature shock shall also be avoided (excluding temperature change during operation).
5. When the instrument is not working, set it into the case and place it in a dry place. Pay attention to prevent vibration, dust and damp.
6. If there is significant difference between temperature at working place and storage of the instrument, the instrument shall be left in the case until equilibrium is achieved.
7. If the instrument is not used for a long time, the battery shall be removed, separately stored and charged once every month.
8. The instrument shall be set in the case when transporting it and care shall be taken to avoid squeezing, collision and strenuous vibration during transport. For long-distance transport, it would be preferable to set cushions around the case.
9. When erecting the instrument, try to use a wood tripod, because a metal tripod may influence measuring accuracy due to vibration.
10. When exposed optical elements need to be cleaned, degrease cotton or lens tissue shall be used to gently wipe them. Do not use any other items to clean them.
11. When the instrument finishes working, lint or hairbrush shall be used to remove surface dust on the instrument. If the instrument is soaked by rainwater, do not supply power or turn on it. Clean soft cloth shall be used to dry it and then set the instrument in a well-ventilated place for a while.
12. Carefully check the instrument prior to operation, to make sure that the various indices, functions, power supply, initial settings and correction parameters of the instrument all conform to the requirements.
13. If the instrument is found abnormal, nonprofessional maintenance personnel are not allowed to disassemble the instrument, in order to avoid unwanted damage.



1 Descriptions and functions of components of the instrument

1.1 Component descriptions







1.2 Display

1.2.1 Main menu

The main menu is as shown below. Press the keys to fulfill corresponding operations.



[Meas]: measurement mode

(See Chapter 5 “Meas mode” for details.)

[Programs]: application program mode

(See Chapter 6 “Programs mode” for details.)

[Manage]: management mode

Functions of this mode are as follows:

- Job
- Fixpoints
- Measurement data
- Code
- Memory initialization

(See Chapter 7 “Manage mode” for details.)

[Transfer]: transfer mode

(See Chapter 8 “Transfer mode” for details.)



[Configuration]: configuration mode

Functions of this mode are as follows:

- General work configuration
- Regional configuration
- Measurement parameter configuration
- Screen and audio configuration
- EDM configuration
- Interface configuration

The set parameters (excluding interface configuration) will be saved always and the Bluetooth defaults to inactivated state when the system starts.

(See Chapter 9 “Configuration mode” for details.)

[Tools]: tools mode

Functions of this mode are as follows:

- Adjustment
- Exit
- System information

(See Chapter 10 “Tools mode” for details.)

1.2.2 Measurement menu

Example: routine measurement - Meas1

PtID: point name, 1

Pri.HT: prism height, 0.000m

Remark: note, -----

HR: horizontal (right) angle, 0°00'00"

V: vertical angle, 0°00'00"

HD: horizontal distance, 0.000 m



| | | | |
|----------|----------|-------|------|
| Meas 1 | Meas 2 | Coor. | Code |
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Remark : | ----- | | |
| HR : | 0°00'00" | | |
| V : | 0°00'00" | | |
| HD : | 0.000 m | | |

Meas Rec Meas Store ↓

1.2.3 Display symbols

| Symbol | Meaning | Symbol | Meaning |
|--------|--------------------------|--------|---------------------------------|
| PtID | Point name | Code | Code |
| Pri.HT | Prism height | N | North coordinate |
| Remark | Note | E | East coordinate |
| HR | Horizontal angle (right) | Z | Zenith coordinate |
| HL | Horizontal angle (left) | m | In meters |
| V | Vertical angle | ft | In feet |
| V% | Grad | F | Fine mode |
| HD | Horizontal distance | T | Tracking mode (1mm) |
| VD | Elevation difference | ppm | Meteorological correction value |
| SD | Slope distance | | |

1.2.4 Screen operation keys

The keys on the screen can be operated by clicking them with a pen or fingers.
Do not use a ballpoint pen or a pencil.



1.3 Operational keys



| Key | Description | Function |
|-------|-----------------------|--|
| 0~/ | Numeric key | To input numbers (for value presetting) and special symbols |
| A~/ | Letter key | To input letters and special symbols |
| ⬅ | ESC key | To return to the previous screen or mode |
| ★ | Star key | To operate several common functions of the instrument |
| OK | Enter key | To end and confirm data input |
| ☰ | Menu key | To directly enter main menu |
| 👤1 | USER key 1 | To define USER key 1. Functions of this key may be defined with the “Work” menu under “Configuration” menu |
| 👤2 | USER key 2 | To define USER key 2. Functions of this key may be defined with the “Work” menu under “Configuration” menu |
| 🔴 | Navigation key | To control the cursor under editing or input mode or control the current operating cursor |
| POWER | Power button | To control ON/OFF of the power supply |
| F1-F4 | Soft function buttons | Their functions change along with the bottom line on the screen. |



1.4 Function keys (soft)

The upper lines on the screen indicate the observation data while the soft command and function keys are at the bottom line of the screen; the corresponding function button can be activated by pressing corresponding button. The actual meaning of each soft function button depends on the current activated application program and functions.

The figure consists of four screenshots of a software application titled "Routine Meas". Each screenshot shows a data entry form with various fields and a toolbar at the top.

- Screenshot 1 (Top Left):** Shows fields for PtID (1), Pri.HT (0.000 m), Remark (-----), HR (0°00'00"), V (0°00'00"), and HD (0.000 m). Buttons at the bottom include Meas Rec, Meas, Store, V/%, Code, EDM, and a down arrow.
- Screenshot 2 (Top Right):** Similar to Screenshot 1, but includes additional fields for VD (0.000 m) and SD (0.000 m). Buttons at the bottom include V/%, Code, EDM, and a down arrow.
- Screenshot 3 (Bottom Left):** Shows fields for PtID (1), Pri.HT (0.000 m), Remark (-----), N (0.000 m), E (0.000 m), and Z (0.000 m). Buttons at the bottom include Station, Tray, HR, Lofting, Zero, Ins. HT, and a left arrow.
- Screenshot 4 (Bottom Right):** Shows fields for PtID (1), Pri.HT (0.000 m), Code (1), N (0.000 m), E (0.000 m), and Z (0.000 m). Buttons at the bottom include Lofting, Zero, Ins. HT, and a left arrow.

| Display | Function |
|----------|--|
| Meas Rec | To start measuring and record measured data |
| Meas | To start measuring |
| Store | To record measured data |
| V/% | Vertical angle/grad conversion |
| Code | To set the code |
| EDM | To set N measurements, fine measurement/tracking, prism/non-prism mode |
| Station | To set the station |
| Tray | To preset the horizontal angle |
| HR | To change between right and left horizontal angle |



| | |
|---------|---|
| Lofting | Lofting measurement mode |
| Zero | To set horizontal angle to zero |
| Ins. HT | To set prism height and instrument height |
| ↓ | Next page |
| ← | Back to the first page |

1.5 Symbols

A symbol indicates a specific operating state, according to the different software version.

| Key | Meaning |
|-----|---------------------------------------|
| | Indicating there are multiple choices |

1.6 Icons

| Display | Function |
|----------|---|
| | It can activate EDM if the interface has EDM activation function |
| | It can start measuring if the interface has measurement boot function |
| | To launch leveling interface |
| 13:55:30 | To start time setting |
| | To switch between letter and number input at the interface with letter/number switch input mode |
| | To start communication setting |
| | To indicate battery level |

1.7 Star key (★) mode

Press ★ and several operation options of the instrument will be revealed. These options are displayed on two pages.

The following operations can be achieved with star key:

1. EDM
2. VD
3. Meas. Parameter
4. Laser Line
5. Laser Point



6. Level

7. Switch from Home to main menu

| Procedure | Display |
|--|---|
| <p>① Press ★.</p> <p>② Press “Routine1” to show page 1; Press “Routine2” to show page 2.</p> <p>Press “” to return to previous menu.</p> | <p>9:27:24 345</p> <p>Function</p> <p>Routine1 Routine2</p> <p>F1 EDM (1) F2 VD (2) F3 Meas.Parameter (3) F4 Home (4)</p> <p>F1 F2 F3 F4</p> <p>9:27:35 345</p> <p>Function</p> <p>Routine1 Routine2</p> <p>F1 Laser Line (5) F2 Laser Point (6) F3 Level (7) F4 Home (8)</p> <p>F1 F2 F3 F4</p> |

1.7.1 EDM

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Press ★.
- ② Press “F1” or “1” to enter EDM setting interface.
- ③ See “9.5 EDM” for related operation.

1.7.2 VD

| Procedure | Display |
|--|---------|
| <ol style="list-style-type: none">① Press ★.② Press “F2” or “2” to enter VD setting interface.③ Enter prism height and instrument height.④ To save the modifications, press “F4” (Determine).⑤ Press “F1” (Back) to return to previous menu. | |


1.7.3 Measurement parameter setting (temperature, air pressure, meteorological correction value

(PPM), prism constant value (PSM) and reflector constant)

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Press ★.
- ② Press “F3” or “3” to enter Meas. Parameter setting interface.
- ③ See “9.3 Meas.Parameter” for related operations.



1.7.4 Laser line


| Procedure | Display |
|---|---------|
| <ol style="list-style-type: none">① Press ★.② Press “Routine2” to show page 2.③ Press “F1” or “5” to enter laser line setting interface.④ Chose to turn on or off laser line.⑤ Press “F4” (Detemine) to confirm the modification.⑥ Press “F1” (Back) to return to previous menu. | |

1.7.5 Laser point

| Procedure | Display |
|-----------|---------|
| | |



- ① Press ★.
- ② Press “Routine2” to show page 2.
- ③ Press “F2” or 6 to enter laser point setting interface.
- ④ Choose to turn on or off laser point.
- ⑤ Press “F4” (Determine) to confirm the modification.
- ⑥ Press “F1” (Back) to return to previous menu.



1.7.6 Leveling

| Procedure | Display |
|---|---------|
| <ol style="list-style-type: none">① Press ★.② Press “Routine2” to show page 2.③ Press “F3” or 7 to enter leveling interface.④ Tilt compensation has the following options: OFF, uniaxial and biaxial. When biaxial is selected, aiming and horizontal axis values will be shown. | |




2 Battery box mounting and charging

2.1 Battery box mounting


1. Battery mounting

Install the battery box into the frame according to the positive and negative symbols and direction, as shown in the following figure.




2. Battery disassembly

When removing the battery box for charging, hold the ears of the battery box frame with one hand and the battery box with the other hand, and pull it out.




2.2 Charging of battery box

1. Load the battery box into the charge station for charging, as shown in the figure below.



2. Insert one terminal of the transformer into the charge station and the other into the power socket-outlet. Red light of the transformer indicates charging is underway and, when it turns green, it indicates charging is finished.



Notes:

- 1) If red light is normally on, it indicates it is charging.
- 2) Charging time is 7h and initial charging time is 12h to 15h.
- 3) Although the charger has overcharge protection circuit, the plug shall be removed from the socket-outlet when charging is over.
- 4) Charging shall be performed within the temperature range of $0 \sim +45^{\circ}\text{C}$; a temperature out of this range may result in charge failure.
- 5) If the light is not on when the charger is connected to the battery, the charger or the battery may be damaged. Please repair.
- 6) If the red light flashes at relatively long intervals after the plug is inserted into the socket-outlet, please slightly turn the plug to ensure proper contact with the socket-outlet on the battery.
- 7) The battery can be repeatedly charged for 300 to 500 times and full discharge will reduce its service life.






8) To better extend service life of the battery, please ensure to charge it every month.

3 Initial settings

3.1 Instrument constant setting

The instrument constant obtained according to “11.8 Instrument constant (K)” can be set in the following way.

| Procedure | Display |
|--|---|
| <p>① Press “Tools” or “6” from the main menu to enter Tools mode.</p> <p>② Press “Adjustment” or “1” to reveal the adjustment setting interface.</p> <p>③ See “10.1.3 Instrument constant” for related operations.</p> |   |
| | |



3.2 Laser plummet setting

| Procedure | Display |
|---|---|
| <ol style="list-style-type: none">① Press ★.② Press "Routine2" to show page 2.③ Press "F2" or "6" to enter laser point setting interface.④ Choose to turn on or off laser point.⑤ Press "F4" (Determine) to confirm the modification.⑥ Press "F1" (Back) to return to previous menu. | <p>The screenshot shows the 'Function' selection screen. At the top, there are icons for a laser, a battery, and a signal strength, followed by the time '9:27:35'. On the right, there are buttons for '345' and 'Starburst'. Below the header, the title '【Function】' is displayed. Two tabs are shown: 'Routine1' (selected) and 'Routine2'. Below the tabs, there are four options: F1 Laser Line (5), F2 Laser Point (6), F3 Level (7), and F4 Home (8). At the bottom, there are buttons for 'F1', 'F2', 'F3', and 'F4'. <p>The screenshot shows the 'Laser Point' configuration screen. At the top, there are icons for a laser, a battery, and a signal strength, followed by the time '13:29:28'. On the right, there are buttons for '345' and 'Starburst'. Below the header, the title '【Laser Point】' is displayed. A 'Data' tab is selected. In the center, there is a setting for 'Laser Point' with a value of 'OFF' and a double-headed arrow button. At the bottom, there are buttons for 'Back' and 'Determine'.</p></p> |



3.3 Prism constant setting

If prism constant of the prism used is -30, the prism constant shall be set to -30. Hence, the prism constant shall be preset based on the prism used in actual applications. Once the prism constant is set, it will be saved when the instrument is shut down.

- Prism constant setting is completed under star key (★) mode or measurement parameter function.
- Example: prism constant: -30

| Procedure | Display |
|---|---|
| <p>① Press ★ .</p> <p>② Press “Routine1” to show page 1.</p> <p>③ Press “F3” or “3” to enter measurement parameter setting interface.</p> <p>④ See “9.3 Meas.Parameter” for related operations.</p> | <p>The display shows two screens of the instrument's user interface. The top screen is titled 'Function' with tabs for 'Routine1' (selected) and 'Routine2'. It lists four options: F1 EDM (1), F2 VD (2), F3 Meas.Parameter (3), and F4 Home (4). The bottom screen is titled 'Meas. Parameter' with tabs for 'Data' (selected) and 'Store'. It displays meteorological parameters: Air Pressure (1013.7 hPa), Temp (20 °C), Meteorological Correc (4.586 PPM), Prism (-30 mm), and NP.Const (0 mm). Navigation keys F1, F2, F3, and F4 are visible at the bottom of both screens.</p> |

3.4 Meteorological correction setting

Light travels fast in the air and its speed varies together with air temperature and pressure. This instrument will automatically apply meteorological correction on the observation results once the meteorological correction value is set. When the temperature is 20 °C, the barometric pressure is



1013hpa. The meteorological correction value will be saved even the instrument is shut down.

The meteorological correction value can be set under star key (★) mode.

| Procedure | Display |
|---|---|
| <p>① Press ★.</p> <p>② Press “Routine1” to show page 1.</p> <p>③ Press “F3” or “3” to enter setting interface.</p> <p>④ Press “F2” (Air) to enter air pressure input interface.</p> <p>⑤ See “9.3 Meas.Parameter” for related operations.</p> | <p>Function</p> <p>Routine1 Routine2</p> <p>F1 EDM (1) F2 VD (2) F3 Meas.Parameter (3) F4 Home (4)</p> <p>Meas. Parameter</p> <p>Data Store</p> <p>Air Pressure 1013.7 hPa Temp 20 °C Meteorological Correc 4.586 PPM</p> <p>Prism -30 mm NPConst 0 mm</p> <p>Air PPM Determine</p> <p>Air</p> <p>Data</p> <p>Air Pressure 1013.7 hPa Temp 20 °C</p> <p>Back Determine</p> |

※ 1) Data range: Temperature: -30 ~ +60 °C (step: 0.1 °C)



Air pressure: 420 ~ 800 mmHg (step: 1 mmHg)

Meteorological correction value (PPM): -100 ~ +100 PPM (step: 1PPM)

Prism constant (PC): -100 ~ +100 mm (step: 1mm)

※2) The instrument will calculate meteorological correction value based on entered temperature and air pressure.

3.4.1 Calculation of meteorological correction value

The correction calculation formula is as follows: (in m)

$$\text{PPM} = 275.932302 - \frac{78.469981 \times \text{air pressure (hPa)}}{273.14941 + \text{temperature } (^{\circ}\text{C})}$$

- If meteorological correction is not considered, please set PPM to 0.
- Standard meteorological conditions for Wince total station (i.e.: meteorological conditions with meteorological correction value being 4):

Air pressure: 1013 hPa

Temperature: 20 °C

3.4.2 How to directly set meteorological correction value

Measure the temperature and air pressure and calculate the meteorological correction value (ppm) with the above formula.

| Procedure | Display |
|--|---|
| <p>① Press ★.</p> <p>② Press “Routine1” to show page 1.</p> <p>③ Press “F3” or “3” to enter setting interface.</p> <p>④ Press “F3” (PPM) to enter PPM input interface.</p> <p>⑤ See “9.3 Meas.Parameter” for related operations.</p> | <p>The display shows the instrument's menu system. At the top, there are icons for a telescope, a computer, and a battery, followed by the time "9:27:24". To the right of the time are icons for a battery level (345), signal strength, and a network connection. Below the icons is a blue bar labeled "Function". Underneath the blue bar, there are two tabs: "Routine1" (highlighted in orange) and "Routine2". The main menu area contains four items: "F1 EDM" (with a "(1)" label), "F2 VD" (with a "(2)" label), "F3 Meas.Parameter" (with a "(3)" label), and "F4 Home" (with a "(4)" label). At the bottom of the screen, there is a horizontal bar with four buttons labeled "F1", "F2", "F3", and "F4".</p> |




The screenshot shows two main windows of the software:

- 【Meas. Parameter】**: This window displays environmental parameters. It includes fields for Air Pressure (1013.7 hPa), Temp (20 °C), Meteorological Correc (4.586 PPM), Prism (-30 mm), and NP.Const (0 mm). Below these are buttons for Air, PPM, and Detemine.
- 【Meteorological Correction】**: This window shows a value M.C (4.586 PPM) and buttons for Back and Detemine.

※1) Data range: -100 ppm ~ +100 ppm step 1ppm

3.5 Reflector constant setting

| Procedure | Display |
|---|---|
| <ol style="list-style-type: none">① Press ★.② Press “Routine1” to show page 1.③ Press “F3” or “3” to enter setting interface.④ Enter the reflector constant and press “F4” (Detemine) to save the modification.⑤ See “9.3 Meas.Parameter” for related operations. | <p>The screenshot shows the Function menu with Routine1 selected. Other options include F1 EDM (1), F2 VD (2), F3 Meas.Parameter (3), and F4 Home (4). Below the menu are buttons for F1, F2, F3, and F4.</p> |



3.6 Atmospheric refraction and earth curvature correction

The instrument can automatically correct the influence of atmospheric refraction and earth curvature when conducting horizontal distance and elevation difference measurement.

The correction of atmospheric refraction and earth curvature is respectively calculated with the following formulas:

Horizontal distance after correction:

$$D = S * [\cos\alpha + \sin\alpha * S * \cos\alpha(K-2) / 2Re]$$

Elevation difference after correction:

$$H = S * [\sin\alpha + \cos\alpha * S * \cos\alpha(1-K) / 2Re]$$

- The formulas for calculating horizontal distance and elevation difference without atmospheric refraction and earth curvature correction are as follows:

$$D = S \cdot \cos\alpha$$

$$H = S \cdot \sin\alpha$$

Where: $K = 0.14$ atmospheric refraction coefficient

$Re = 6370 \text{ km}$ earth curvature radius

α (or β) vertical angle from horizontal plane

S slope distance

Note: Atmospheric refraction coefficient (K) of the instrument is set to 0.14 before it leaves factory.

4 Preparations prior to measurement

4.1 Unpacking and storage of the instrument

Unpacking

Gently lay the case down; with the cover facing upward, unlock the latch, open the cover and take the instrument out.



·Storage

Cover the telescope with the cap, so that the vertical clamp screw of the alidade and level of the base face upward; then horizontally place the instrument into the case (with the telescope objective lens facing downward). Gently tighten the vertical clamp screw, recover the case and lock it with the latch.

4.2 Erection of the instrument

Place the instrument onto the tripod; carefully level and align it, to ensure accuracy of the measurements (special tripod with central connection screw shall be used).

·Operation reference: Leveling and alignment of the instrument

1. Erect the tripod


- ① First spread the tripod, so that the three feet of the tripod are approximately equally spaced and the top surface is approximately level. Tighten the three fixing bolts.
- ② Adjust the tripod to make its center and the measuring point approximately on the same plumb line.
- ③ Step on the tripod to make it reliably fixed onto the ground.

2. Set the instrument onto the tripod


Carefully place the instrument onto top surface of the tripod. Hold the instrument with one hand and loosen the center connection screw with the other hand. Gently move the instrument until the plumb is aligned with the station mark. Then, gently tighten the connection screw.

3. Roughly level the instrument with the circular vial

- ① Rotate the two foot screws A and B, so that the bubble of the circular vial is on the line perpendicular to line of centers of the above two foot screws.



- ② Turn foot screw C to center the bubble of the circular vial.




4. Level the instrument with level tube in a fine manner


- ① Loosen the horizontal clamp screw and then turn the instrument to make the level tube parallel



with the line formed by foot screws A and B. Afterwards, turn foot screws A and B to center the bubble of the level tube.




- ② Turn the instrument around the vertical axis for 90° , then turn foot screw C to center bubble of the level tube.



- ③ Turn the instrument for 90° again; then repeat steps ① and ②, until the bubbles on the four positions are all centered.

5. Center it with the optical plummet

Adjust objective lens of the optical plummet telescope based on vision of the observer. Loosen the central connection screw, carefully move the instrument to align the center mark of the optical plummet and the station and then tighten the connection screw. When moving the instrument, do not make it turn on the tripod, to prevent the bubbles from drifting.





6. Final fine leveling of the instrument

Conduct fine leveling of the instrument according to step 4, until bubbles of the level tubes are always centered no matter how the instrument turns.



4.3 Turn on power switch

Press the button Power on the panel and the main interface will appear when the instrument starts:



Main Menu Icons

- Check the displayed battery level. When battery level is low, the battery shall be promptly replaced and charged. See “4.4 Battery level icon”.

4.4 Battery level icon

The battery level icon is used to indicate battery level.

When it is empty, please replace the battery and charge it.

Battery level

Notes:

- ① Working hours of the battery depends on environmental conditions, for instance, instrument ambient temperature, duration of charging time and counts of charge and discharge. For your safety, it is recommended to charge the battery in advance or prepare charged batteries for backup.
- ② The battery level icon indicates the battery level under current measuring mode. The battery level indicated under angle measurement mode may not be sufficient for distance measurement, since distance measurement consumes more power than angle measurement. When it switches from angle measurement mode to distance measurement mode, the operation may be interrupted due to low battery.
 - It is recommended to check the battery level before leaving for field survey.
- ③ The battery level icon may not promptly indicate decrease or increase of power when the observation mode changes. The battery level indicator system is used to show overall conditions of the battery and it cannot reflect immediate change in battery level.

• Notes for charging of battery



- ☆ The battery shall be charged with the charger supplied with the instrument.
- ☆ When charging the battery, first connect the charger to the 220V supply; then remove the battery box from the instrument and insert it into the charge socket. An orange light on the charger indicates it is charging. After 7h or when the light turns green, it indicates charging is over. Unplug the plug.

Note for removing onboard battery box:

- ☆ The instrument power must be turned off each time you remove the battery box; otherwise, the instrument may easily get damaged.

Notes for charging:

- ☆ The plug shall be removed from the socket-outlet, although the charger has overcharge protection circuit.
- ☆ Charging shall be performed within the temperature range of $0 \sim \pm 45^{\circ}\text{C}$; a temperature out of this range may result in charge failure.
- ☆ If the light is not on when the charger is connected to the battery, the charger or the battery may be damaged. Please call a professional to repair it.

Notes for battery storage:

- ☆ The battery can be repeatedly charged for 300 to 500 times and full discharge will reduce its service life.
- ☆ To better extend service life of the battery, please ensure to charge it every month.

4.5 Reflecting prism

A reflecting prism shall be set at the target when the total station is conducting distance measurement and other work. A reflecting prism consists of a single (or triple) prism set and it can be connected to the base with the base connector and mounted onto the tripod or directly mounted onto the centering rod. The prism set is to be provided by the user based on actual work demand.

The prism set is as shown below:






4.6 Disassembly and assembly of base

·Disassembly

The triangular base can be removed from the instrument (including the reflecting prism base connector which has a same base), if required. First loosen the base lock knob retaining screw with a screwdriver; then turn the lock knob counterclockwise for about 180° and the base can be separated from the instrument.



·Assembly

Align the directional bump mark of the instrument with the directional slot of the base and place the three fixed feet of the instrument into corresponding holes on the base to load the instrument onto the base. Turn the lock knob clockwise for about 180° to lock the instrument and the base. Finally, tighten the lock knob retaining screw with a screwdriver.

4.7 Adjustment and aiming of telescope objective lens

Method for aiming (for reference only)

- ① Point the telescope toward a bright place and turn the eye piece. Focus it until the graticule is clear (first turn the eye piece toward you and then slowly adjust it to focus and make the graticule clear).
 - ② Use the tip of the triangular mark in the collimator for aiming. Certain distance should be left between your eye and the collimator.
 - ③ Make the target image clearly with the telescope focusing screw.
- ☆ If parallax is found when your eye moves vertically or horizontally over the eye piece, it indicates that focusing or eye piece diopter is not proper (this will affect measurement accuracy) and focusing shall be carefully conducted and eye piece adjusted to eliminate parallax.



4.8 Vertical angle tilt correction

When tilt sensor is activated, the correction to be automatically applied to the vertical angle due to relaxed leveling will be displayed.

The tilt sensor must be activated to ensure precise angle measurement (see 1.7.6 Leveling for related operations). The indicated tilt correction may also be used for fine leveling of the instrument.

- Wince total station can automatically compensate and correct the vertical angle error caused by tilt of instrument vertical axis in direction Y.
- The vertical angle shown will not be stable if the instrument is not stably situated or it is affected by wind. In this case, the automatic tilt correction function for vertical angle can be turned off.

4.9 Instrument system error compensation

- 1) Instrument vertical axis error (deviation of Y-direction tilt sensor)
- 2) Collimation axis error
- 3) Vertical angle zero reference error
- 4) Horizontal axis error

The above errors can be corrected by the software through internal calculation based on the compensation value for each of them. These errors can also be compensated when the instrument only serves as an independent device (circle left/circle right) and the method generally taken to eliminate these errors is to take the average of the observation values with normal and inverted telescope.

- For methods for adjustment or resetting of the above compensation values, see Chapter 11 “Inspection and calibration”.
- For way to stop the tilt correction function, see “1.7.6 Leveling” or Chapter 11 “Inspection and calibration”.

4.10 Methods for entering numbers and letters

Letters and numbers can be entered with the keypad, which is quite fast and convenient.

[Example]: input under measurement

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Press “Meas” or “1” to enter routine measurement interface from main menu.

The screenshot shows the "Routine Meas" interface. At the top, there are icons for a signal, a computer, a compass, and battery level, followed by the time "15:21:44". Below the icons are four tabs: "Meas 1", "Meas 2", "Coor.", and "Code". The "Meas 1" tab is selected. Underneath are five input fields: PtID (0), Pri.HT (0.000 m), Remark (-----), N (0.000 m), E (0.000 m), and Z (0.000 m). At the bottom are three buttons: "Meas Rec", "Meas", and "Store".




- ② Press “OK” to enter input mode.
When the cursor is in the field accepting letters, numbers or symbols, the character input state will be activated.
When the cursor is in the field accepting numbers, “.” or “-”, the numeric input state will be activated.

The screenshot shows the "Routine Meas" interface with character input mode activated. The PtID field contains "adg". The other fields remain blank. At the bottom are four buttons: "Del", "Clear", and "Number".

- ③ Under character input state:
“F2” (Del): to delete character(s);
“F3” (Clear): to clear all characters in the current field;
“F4” (Number): to switch to numeric entry; please enter “123”;
“F4” (Letter): to switch to letter input; please enter “adg”.



The screenshot shows the "Routine Meas" interface with numeric input mode activated. The PtID field contains "123". The other fields remain blank. At the bottom are four buttons: "Del", "Clear", and "Letter".



| | |
|--|--|
| |  |
| <p>④ Under numeric input state: “F2” (Del): to delete character(s); “F3” (Clear): to clear all characters in the current field; Please enter “-1.3”.</p> |  |
| <p>⑤ Press “OK” to confirm the input, end the input mode and automatically jump to the next step; ⑥ Press “” to cancel input and end the input mode.</p> |  |

5 Meas mode

Press (1) or click “Meas”.



Meas 模式

Meas mode

Routine measurement menu consists of four pages and covers all common measuring functions, such as: angle measurement, distance measurement and coordinate measurement, as shown in the figures below.



| Meas 1 | Meas 2 | Coor. | Code |
|----------|---------|-------|------|
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Remark : | ----- | | |
| N : | 0.000 m | | |
| E : | 0.000 m | | |
| Z : | 0.000 m | | |

Station | Trav | HR | ↓ | Lofting | Zero | Ins. HT | ←

| Meas 1 | Meas 2 | Coor. | Code |
|----------|---------|-------|------|
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Code : | 1 | ◀ ▶ | |
| N : | 0.000 m | | |
| E : | 0.000 m | | |
| Z : | 0.000 m | | |



Lofting | Zero | Ins. HT | ←

5.1 Angle measurement

5.1.1 Horizontal angle (right) and vertical angle measurement

| Procedure | Display | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|--|--------|--------|-------|------|--------|---|--|--|----------|---------|--|--|--------|---|-------|--|-----|---------|--|--|-----|---------|--|--|-----|---------|--|--|
| ① Sight the first target (A). | <table border="1"><tr><th>Meas 1</th><th>Meas 2</th><th>Coor.</th><th>Code</th></tr><tr><td>PtID :</td><td>1</td><td></td><td></td></tr><tr><td>Pri.HT :</td><td>0.000 m</td><td></td><td></td></tr><tr><td>Code :</td><td>1</td><td>◀ ▶</td><td></td></tr><tr><td>N :</td><td>0.000 m</td><td></td><td></td></tr><tr><td>E :</td><td>0.000 m</td><td></td><td></td></tr><tr><td>Z :</td><td>0.000 m</td><td></td><td></td></tr></table> <p>Lofting Zero Ins. HT ←</p> | Meas 1 | Meas 2 | Coor. | Code | PtID : | 1 | | | Pri.HT : | 0.000 m | | | Code : | 1 | ◀ ▶ | | N : | 0.000 m | | | E : | 0.000 m | | | Z : | 0.000 m | | |
| Meas 1 | Meas 2 | Coor. | Code | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PtID : | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pri.HT : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Code : | 1 | ◀ ▶ | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Z : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ② Set horizontal angle reading of target A to 0°00'00". Press and hold "F4" (↓ or ←) until button "Zero" appears and then press "F2" (Zero). ③ In the zero confirmation window, press "F4" to confirm zero setting and return to previous menu. | <table border="1"><tr><th>Meas 1</th><th>Meas 2</th><th>Coor.</th><th>Code</th></tr><tr><td>PtID :</td><td>1</td><td></td><td></td></tr><tr><td>Pri.HT :</td><td>0.000 m</td><td></td><td></td></tr><tr><td>Code :</td><td>1</td><td>◀ ▶</td><td></td></tr><tr><td>N :</td><td>0.000 m</td><td></td><td></td></tr><tr><td>E :</td><td>0.000 m</td><td></td><td></td></tr><tr><td>Z :</td><td>0.000 m</td><td></td><td></td></tr></table> <p>Lofting Zero Ins. HT ←</p> <p>Zero to confirm?</p> <p>No Yes</p> | Meas 1 | Meas 2 | Coor. | Code | PtID : | 1 | | | Pri.HT : | 0.000 m | | | Code : | 1 | ◀ ▶ | | N : | 0.000 m | | | E : | 0.000 m | | | Z : | 0.000 m | | |
| Meas 1 | Meas 2 | Coor. | Code | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PtID : | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pri.HT : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Code : | 1 | ◀ ▶ | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Z : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



| | |
|--|---|
| |  |
| (4) Sight the second target (B). The instrument will display horizontal angle and vertical angle of target B. |  |

Method for aiming (for reference only)

- ① Point the telescope toward a bright place and turn the eye piece. Focus it until the graticule is clear (first turn the eye piece toward you and then slowly adjust it to focus and make the graticule clear).
- ② Use the tip of the triangular mark in the collimator for aiming. Certain distance should be left between your eye and the collimator.
- ③ Make the target image clearly with the telescope focusing screw.

☆ If parallax is found when your eye moves vertically or horizontally over the eye piece, it indicates that focusing or eye piece diopter is not proper and this will affect measurement accuracy. Hence, focusing shall be carefully conducted and eye piece adjusted to eliminate parallax.

5.1.2 Horizontal angle measurement mode (right angle/left angle) switching

| Procedure | Display |
|-----------|---------|
|-----------|---------|



| | |
|--|--|
| ① Press and hold “F4” (↓ or ←) until button “HR” appears. Press “F3” (HR) and it will switch from right angle mode to left angle mode of horizontal angle measurement. | |
| ② Measure left angle in the way in which right angle is measured. | |
| ● Each time “HR” is pressed, it will switch between right angle/left angle in turn. | |

5.1.3 Setting of horizontal limb reading

1) Setting with numeric keys

| Procedure | Display |
|---|---------|
| ① Sight the target point for orientation. | |
| ② Press and hold “F4” (↓ or ←) until button “Tray” appears. Press “F2” (Tray). ③ Enter the required horizontal limb reading. ≈ 1) Example: Enter 123.5636 and the horizontal limb is set to 123°56'36". | |



- ④ Press “F4” (Determine).

Now, you can proceed with normal angle measurement with orientation completed.

The screenshot shows the 'Routine Meas' menu with the following data:

| | Meas 1 | Meas 2 | Coor. | Code |
|----------|------------|--------|-------|------|
| PtID : | 0 | | | |
| Pri.HT : | 0.000 m | | | |
| Remark : | ----- | | | |
| HR : | 123°56'36" | | | |
| V : | 20°45'12" | | | |
| HD : | 0.000 m | | | |

Buttons at the bottom: Meas Rec, Meas, Store, ↓

※1) In the case of an input error, you can modify it or press “F1” (Back), re-enter the interface and input again.

5.1.4 Vertical angle grad mode

Confirm the instrument is in angle measurement mode

| Procedure | Display | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--------|--------|--------|-------|------|--------|---|--|--|--|----------|---------|--|--|--|----------|-------|--|--|--|------|-----------|--|--|--|---|--------|--|--|--|------|---------|--|--|--|
| ① Press and hold “F4” (↓ or ←) until button “V/%” appears. Press “F1” (V/%) and the vertical angle will change from degree mode to grad mode. ※1) | <p>The screenshot shows the 'Routine Meas' menu with the following data:</p> <table border="1"><thead><tr><th></th><th>Meas 1</th><th>Meas 2</th><th>Coor.</th><th>Code</th></tr></thead><tbody><tr><td>PtID :</td><td>0</td><td></td><td></td><td></td></tr><tr><td>Pri.HT :</td><td>0.000 m</td><td></td><td></td><td></td></tr><tr><td>Remark :</td><td>-----</td><td></td><td></td><td></td></tr><tr><td>HR :</td><td>65°43'52"</td><td></td><td></td><td></td></tr><tr><td>%</td><td>0.181%</td><td></td><td></td><td></td></tr><tr><td>HD :</td><td>0.000 m</td><td></td><td></td><td></td></tr></tbody></table> <p>Buttons at the bottom: V/%, Code, EDM, ↓</p> | | Meas 1 | Meas 2 | Coor. | Code | PtID : | 0 | | | | Pri.HT : | 0.000 m | | | | Remark : | ----- | | | | HR : | 65°43'52" | | | | % | 0.181% | | | | HD : | 0.000 m | | | |
| | Meas 1 | Meas 2 | Coor. | Code | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PtID : | 0 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pri.HT : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Remark : | ----- | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HR : | 65°43'52" | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| % | 0.181% | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HD : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |

※1) Each time “V/%” is pressed, vertical angle display mode will switch in turn.

5.2 Distance measurement

5.2.1 Laser type setting

Laser type and the constant setting are displayed below the distance measurement tag. For instance, when the constant is 0, reflector: S 0, non-prism: N 0, prism: P 0.

Under star key (★) mode, press F1 (laser type) to change laser type for measurement of the target .

① The laser types switch in the following sequence: prism distance measurement – non-prism distance measurement – reflector distance measurement.

② The chosen laser type will be saved even the instrument is shut down. Thus, next time the



instrument is started, you can directly enter the mode used last time.

③ Different laser types have different target constants. Hence, it shall be confirmed that the target type and the target constant are consistent when the target is changed.

1. Non-prism distance measurement

The range and accuracy of non-prism distance measurement depends on the laser emission conditions of the white surface perpendicular to the Kodak grey card. The range may also be affected by the target shape and its surrounding environment.

. Attention shall be paid to the following points when non-prism distance measurement is adopted: If distance measurement accuracy cannot be satisfied, reflector or prism shall be adopted for measurement.

. Do not stare at the laser during non-prism distance measurement; otherwise, it will hurt your eyes.

① When the laser goes to the target surface in a tilted manner, the measurement results may be inaccurate due to weakened or scattered laser.

② In the case of road surveying, the instrument may not get the correct results due to interference from reflected laser from the front and rear.

③ When measuring a slant target or ball or a rough target, the distance measured may become longer or shorter because the combined value is used for calculation.

④ When there are people or vehicles travelling back and forth in front of the target or there are tree branches, leaves or other objects swaying in front of the target, the instrument may not be able to receive the correct reflected signal and therefore cannot get the correct results.

2. Reflector distance measurement

. When measuring distance, reflecting surface of the reflector shall be perpendicular to the line formed by the instrument and the target and face toward the instrument. If angle of the reflector is not correct, the right distance may not be obtained due to scattered or weakened laser.

3. Actual measurement range of each laser type

. When a wrong laser type is chosen, you cannot get the correct distance. Hence, the right laser type must be selected.

. Reflecting prism distance measurement: reflector may also be used for distance measurement.

. Reflector and prism distance measurement: under this mode, distance measurement can be fulfilled without using the reflector or prism under specific conditions, such as: close range measurement or wall target. Nonetheless, there still will be certain error, so non-prism distance measurement shall be adopted.

. When reflector is used for distance measurement under prism mode or prism is used for distance measurement under reflector mode, special attention shall be paid to adopt the correct target constant and it shall be confirmed.

. For prism or reflector mode, the target distance must be longer than 1.6m, for ease of measurement.

5.2.2 Setting of meteorological correction, prism constant and non-prism constant

When setting meteorological correction, the temperature and air pressure must be measured, so as to calculate the meteorological correction value.





Setting of meteorological correction is performed under star key (★) mode. See “3.4 Meteorological correction setting”.

If prism constant of the prism used is -30, the prism constant shall be set to -30. Hence, the prism constant shall be preset based on the prism used in actual applications.

Prism constant setting is performed under star key (★) mode. See “3.3 Prism constant setting”.

Non-prism constant setting is performed under calibration mode. See “3.1 Instrument constant setting”.

5.2.3 Distance measurement (continuous)

| Procedure | Display |
|--|---|
| ① Sight prism center. |  |
| ② Press and hold ‘F4’ (↓ or ←) until the button ‘Meas’ appears. Press ‘F2’ (Meas). ※1) [Example] The measurement results will be displayed. ※2) ~※3) |  |
| ※1) To change the measuring mode, press “EDM” to enter setting. ※2) Beeping will accompany the display of measurement results. ※3) Measurement will be automatically repeated if the results are affected by atmospheric refraction and other factors. | |




5.2.4 Distance measurement (N measurements)

When the number of measurements is set, the instrument will measure the distance for the set



number of times. Factory default of the instrument is 1 measurement.

1) Setting of measurement number


| Procedure | Display |
|---|--|
| ① Press and hold ‘F4’ (↓ or ←) until the button “EDM” appears. |  |
| ② Press “F3” (EDM) to enter EDM setting interface. ③ You can enter a new measurement number. |  |
| ④ Press “F4” (Determine) to save it and return to the previous menu. |  |

2) Measurement method

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Sight prism center.




- ② Press and hold “F4” (↓ or | ←) until the button ‘Meas’ appears. Press “F2” (Meas).

Example:

5 measurements start

Average distance, accompanied by beeping sound, is displayed and the screen shows the distance measurement progress interface. The figure “5” decreases by one and finally becomes 0, indicating the end of measurement. You can directly cancel the measurement by pressing

“”.



- When the measurement is over, press “F2” (Meas) and the measurement can be repeated.

5.2.5 Fine measurement/tracking mode

- ☆ Fine measurement mode: the normal distance measurement mode.

Measuring time: approx. 2s

Minimum display distance: 1mm

- ☆ Tracking mode: measuring time of this mode is shorter than that of fine measurement mode and it is mainly used for layout measurement. It is quite useful in tracking moving targets and engineering layout.

Measuring time: approx. 0.8s

Minimum display distance: 1mm

► Procedure

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Press and hold “F4” (↓ or ←) until the button ‘EDM’ appears.

The screenshot shows the 'Routine Meas' menu. At the top right, the time is 8:39:19 and there are icons for battery level (345), signal strength, and a map. Below the title, there are four tabs: 'Meas 1', 'Meas 2', 'Coor', and 'Code'. Under 'Meas 1', there are fields for PtID (1), Pri.HT (0.000 m), Remark (-----), HR (0°00'00"), VD (0.000 m), and SD (0.000 m). At the bottom, there is a row with buttons for 'V/%', 'Code', 'EDM', and a downward arrow.

- ② Press “F3” (EDM) to enter EDM setting interface.

The screenshot shows the 'EDM' setting interface. At the top right, the time is 8:37:16 and there are icons for battery level (345), signal strength, and a map. Below the title, there are two tabs: 'Routine' and 'EDM'. Under 'EDM', there are three rows of settings: 'Meas.Mode' set to 'NP.Meas', 'Laser Type' set to 'FR', and 'Meas.Num' set to '5'. At the bottom, there are buttons for 'Back' and 'Determine'.

- ③ EDM setting interface

Press “◀|▶” in the row of Laser Type to switch between fine measurement or tracking mode.

Press “◀|▶” in the row of Meas. Mode to change the laser type. ※1)

The screenshot shows the 'EDM' setting interface. At the top right, the time is 8:37:16 and there are icons for battery level (345), signal strength, and a map. Below the title, there are two tabs: 'Routine' and 'EDM'. Under 'EDM', there are three rows of settings: 'Meas.Mode' set to 'NP.Meas', 'Laser Type' set to 'FR', and 'Meas.Num' set to '5'. At the bottom, there are buttons for 'Back' and 'Determine'.



- ④ Press “F4” (Determine) to save it and return to previous menu.

The screenshot shows the 'Routine Meas' menu with the following data:

| | Meas 1 | Meas 2 | Coor. | Code |
|----------|------------|--------|-------|------|
| PtID : | 1 | | | |
| Pri.HT : | 0.000 m | | | |
| Remark : | ----- | | | |
| HR : | 123°34'56" | | | |
| V : | 33°29'59" | | | |
| HD : | 0.000 m | | | |

Buttons at the bottom: Meas, Rec, Meas, Store, ↓

※1) Each time the button is pressed, the laser type will change in turn.

5.2.6 Lofting

This function can displace the difference between measured distance and preset distance.

Displayed value = measured value – standard (preset) distance

- It can achieve lofting for measurement modes of various distances, such horizontal distance (HD), elevation difference (VD) or slope distance (SD).

| Procedure | Display | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|--|---|--------|--------------|--------------|--------------|------|--------|---|--|--|--|----------|---------|--|--|--|--------|---|--|--|--|-----|---------|--|--|--|-----|---------|--|--|--|-----|---------|--|--|--|
| ① Sight prism center. | <p>The screenshot shows the 'Routine Meas' menu with the following data:</p> <table border="1"><thead><tr><th></th><th>Meas 1</th><th>Meas 2</th><th>Coor.</th><th>Code</th></tr></thead><tbody><tr><td>PtID :</td><td>1</td><td></td><td></td><td></td></tr><tr><td>Pri.HT :</td><td>0.000 m</td><td></td><td></td><td></td></tr><tr><td>Code :</td><td>1</td><td></td><td></td><td></td></tr><tr><td>N :</td><td>0.000 m</td><td></td><td></td><td></td></tr><tr><td>E :</td><td>0.000 m</td><td></td><td></td><td></td></tr><tr><td>Z :</td><td>0.000 m</td><td></td><td></td><td></td></tr></tbody></table> <p>Buttons at the bottom: Lofting, Zero, Ins. HT, ←</p> | | Meas 1 | Meas 2 | Coor. | Code | PtID : | 1 | | | | Pri.HT : | 0.000 m | | | | Code : | 1 | | | | N : | 0.000 m | | | | E : | 0.000 m | | | | Z : | 0.000 m | | | |
| | Meas 1 | Meas 2 | Coor. | Code | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PtID : | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pri.HT : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Code : | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Z : | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| ② Press and hold “F4” (↓ or ←) until the button “Lofting” appears. Press ‘F1’ (Lofting) to enter the layout setting interface. | <p>The screenshot shows the 'Layout' menu with the following data:</p> <table border="1"><thead><tr><th>Data</th></tr></thead><tbody><tr><td>HD : 0.000 m</td></tr><tr><td>VD : 0.000 m</td></tr><tr><td>SD : 0.000 m</td></tr></tbody></table> <p>Buttons at the bottom: Back, Determine</p> | Data | HD : 0.000 m | VD : 0.000 m | SD : 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Data | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| HD : 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| VD : 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| SD : 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



- ③ Enter the HD, VD and SD for the lofting and press “F4” (Determine) to save the setting and return to previous menu.

9:41:51 345 ⚡

[Layout]

| | |
|------|----------|
| Data | 10.000 m |
| HD : | 10.000 m |
| VD : | 5.000 m |
| SD : | 12.000 m |

Back | Determine

- ④ Press and hold “F4” (↓ or ←) until the button “Meas” appears. Press “F1” (Meas) to start measuring.

9:43:02 345 ⚡

[Routine Meas]

| | | | |
|----------|------------|------|------|
| Meas 1 | Meas 2 | Coor | Code |
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Remark : | ----- | | |
| HR : | 123°34'56" | | |
| V : | 33°29'59" | | |
| dHD : | 78.624 m | | |


Meas Rec Meas Store ↓



- Once the standard distance is again set to “0” or the instrument is shut down, it will return to normal distance measurement mode.

5.3 Coordinate measurement

5.3.1 Setting of station coordinate and instrument height

With station (instrument position) coordinate relative to the origin properly set, the instrument can determine coordinate of the unknown point (prism position).



| Procedure | Display |
|--|---|
| ① Press and hold “F4” (\downarrow or \leftarrow) until the button “Station” appears. Press “F1” (Station). |  【Routine Meas】 Meas 1 Meas 2 Coor. Code PtID : 1 Pri.HT : 0.000 m Remark : ----- N : 0.000 m E : 0.000 m Z : 0.000 m Station Tray HR ↓ |
| ② Press “Station” to enter “Set Station”. See “6.1.2 Orientation setting” for related operations. |  【Set Station】 Data PtID : 1 Code : 2 N : 1100.000 m E : 1050.000 m Z : 0.000 m Find Store Determine |



- ③ Press and hold “F4” (↓ or ←) until the button “Ins.HT” appears. Press “F3” (Ins.HT) to enter instrument height setting interface.

The screenshot shows the 'Routine Meas' menu with the following data:

| PtID | 1 |
|--------|---------|
| Pri.HT | 0.000 m |
| Code | 1 |
| N | 0.000 m |
| E | 0.000 m |
| Z | 0.000 m |

Buttons at the bottom include Lofting, Zero, Ins. HT, and back.

- ④ Enter the instrument height.

The screenshot shows the 'Ins. HT Settings' menu with the following data:

| Pri.HT | 0.000 m |
|--------|---------|
| Ins.HT | 0.000 m |

Buttons at the bottom include Back and Determine.

- ⑤ Press “F4” (Determine) to save the settings and return to routine measurement interface.

- ⑥ Press and hold “F4” (↓ or ←) until the button “F2” (Meas) appears.

- ⑦ Press “F2” (Meas) to start coordinate measurement.

The screenshot shows the 'Routine Meas' menu with the following data (values are approximate):

| PtID | 1 |
|--------|-----------|
| Pri.HT | 0.000 m |
| Code | 2 |
| N | 213.654 m |
| E | 245.781 m |
| Z | 12.981 m |

Buttons at the bottom include Meas Rec, Meas, Store, and back.

5.3.2 Prism height setting

The prism height must be entered for coordinate measurement, so as to directly measure coordinate of the unknown point.

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Directly enter prism height into the “Pri.HT” field and press “OK” to confirm, or press and hold “F4” (\downarrow or \leftarrow) until the button “Ins.HT” appears and then press “F3” (Ins.HT) to enter prism height setting interface.

| Meas 1 | Meas 2 | Coor. | Code |
|----------|---------|-------|------|
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Code : | 1 | | |
| N : | 0.000 m | | |
| E : | 0.000 m | | |
| Z : | 0.000 m | | |

Lofting | Zero | Ins. HT | ←

- ② Enter prism height.

| | |
|----------|----------|
| Data | |
| Pri.HT : | 13.000 m |
| Ins.HT : | 11.000 m |

Back | Determine

- ③ Press “F4” (Determine) to save the setting and return to routine measurement interface.

| Meas 1 | Meas 2 | Coor. | Code |
|----------|----------|-------|------|
| PtID : | 1 | | |
| Pri.HT : | 13.000 m | | |
| Code : | 1 | | |
| N : | 0.000 m | | |
| E : | 0.000 m | | |
| Z : | 0.000 m | | |

Meas Rec | Meas | Store | ↓

5.3.3 Coordinate measurement operations

For coordinate measurement, it can directly determine coordinate of the unknown point with the station coordinate, instrument height and prism height that are entered.

- For station coordinate setting, see “6.1.2 Orientation setting”.
- For instrument height and prism height setting, see “1.7.2 VD”.
- The unknown point coordinate calculation and display process is as follows:



Station coordinates: (N_0, E_0, Z_0)

Coordinate difference between instrument center and prism center: (n, e, z)

Coordinates of unknown point: (N_1, E_1, Z_1)


$$N_1 = N_0 + n$$

$$E_1 = E_0 + e$$

$$Z_1 = Z_0 + \text{instrument height} + z - \text{prism height}$$

$$N_1 = N_0 + n$$

$$E_1 = E_0 + e$$



Confirm that it is in coordinate measurement mode

| Procedure | Display | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|--|--------|---------|-------|------|--|--------|--|--|---|--|----------|--|--|---------|--|--------|--|--|---|--|-----|--|--|---------|--|-----|--|--|---------|--|-----|--|--|---------|--|
| <ol style="list-style-type: none">① Set station coordinate and instrument height/prism height. ※1)② Set direction angle of fixpoint. ※2)③ Sight the target point. | <p>【Routine Meas】</p> <table border="1"><thead><tr><th>Meas 1</th><th>Meas 2</th><th>Coor.</th><th>Code</th><th></th></tr></thead><tbody><tr><td>PtID :</td><td></td><td></td><td>1</td><td></td></tr><tr><td>Pri.HT :</td><td></td><td></td><td>0.000 m</td><td></td></tr><tr><td>Code :</td><td></td><td></td><td>1</td><td></td></tr><tr><td>N :</td><td></td><td></td><td>0.000 m</td><td></td></tr><tr><td>E :</td><td></td><td></td><td>0.000 m</td><td></td></tr><tr><td>Z :</td><td></td><td></td><td>0.000 m</td><td></td></tr></tbody></table> <p>Lofting Zero Ins. HT ←</p> | Meas 1 | Meas 2 | Coor. | Code | | PtID : | | | 1 | | Pri.HT : | | | 0.000 m | | Code : | | | 1 | | N : | | | 0.000 m | | E : | | | 0.000 m | | Z : | | | 0.000 m | |
| Meas 1 | Meas 2 | Coor. | Code | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| PtID : | | | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Pri.HT : | | | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Code : | | | 1 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| N : | | | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| E : | | | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Z : | | | 0.000 m | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



④ Press and hold “F4” (↓ or ←) until the button “Meas” appears. Press “F2” (Meas) to display the measurement results. ※3)


| Meas 1 | Meas 2 | Coor. | Code |
|----------|-----------|-------|------|
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Code : | 2 | | |
| N : | 213.654 m | | |
| E : | 245.781 m | | |
| Z : | 12.981 m | | |

Meas Rec Meas Store ↓

※1) If no station coordinate is set, the default value (0, 0, 0) will be used as station coordinate, or the set station coordinate (if any) will be used. If instrument height and prism height are not entered, 0 will be used as default.
※2) See “5.1.3 Setting of horizontal limb reading” or “6.1.2 Orientation setting”.
※3) Press “EDM” and the distance measurement mode will be changed (single fine measurement/N measurements/repeated fine measurement/tracking measurement).

6 Programs mode (Applied measuring programs)

Press [2] or click “Programs”.



Programs mode (applied measuring programs)


This mode covers the following items:

- Station setup




- Measurement
- Layout
- Traverse survey
- Repetition angle measurement
- Resection
- Missing line measurement
- Line measurement
- Area measurement
- Remote elevation measurement
- Offset measurement
- Road measurement

The menu lists all measuring programs installed in the instrument.



Preparation for program application:

Before starting a program, there is a procedure for setting station data (excluding road lofting). When the user selects a program, the set-up procedure dialog will appear. The user can set the contents of the set-up procedure one by one.



[●]: Item(s) already set

[]: Item(s) not set

The following part will introduce the set-up procedure for each program in detail.

6.1 Station setup

(Select the job and enter the station and backsight point coordinates)


Display and select the job.

Display station coordinate and backsight point coordinate entry. With the coordinates entered, it can calculate the backsight orientation angle. If [Data Store] is set to [ON] under parameter mode, the station coordinate will be saved. See “9.3 Meas.Parameter”.

| Procedure | Display |
|---|---------|
| <p>① Press “Meas” under Programs mode to reveal page 1 of the Programs interface.</p> <p>Press “” to return to previous menu.</p> | |



- ② Press “Station Setup” or “1” to enter Station Setup interface.



6.1.1 Select job


If there is an established job in the memory, it can be invoked and set as the current job. If no job is set, Wince total station will automatically save the data into DEFAULT job. See “7.1.2 New job” for creating new jobs.

| Procedure | Display |
|---|---------|
| <p>① Enter the Station Setup interface. Press “” to return to previous menu.</p> | |
| <p>② Press “F1” or “1” to enter job setting interface. ③ Press the button “” following “Job” to choose a job.</p> | |



- ④ Press “F4” (Cont) to save the chosen job as the current job and return to the previous menu.

Press “” to cancel the selection and return to previous menu.



6.1.2 Orientation setting

(Enter station and backsight point coordinates)

Display station coordinate and backsight point coordinate entry. With the coordinates entered, it can calculate the backsight orientation angle. If [Data Store] is set to [ON] under parameter mode, the station coordinate will be saved. See “9.3 Meas.Parameter”.

Example:

| Procedure | Display |
|--|---------|
| ① Press “F4” or “4” to enter orientation setting interface from Station Setup interface. | |



② Enter the station coordinate into the box and select the code; or, press “F1” (Find) to call the point coordinates stored in the coordinate data file in the memory and then operate as follows:

Press “F1” (FIR) to jump to the first point;

Press “F2” (END) to jump to the last point;

Press the button “ ” following “PtID”

to choose the point.

Press ‘F4’ (Detemine) to confirm the point and

return to previous menu, or press “” to return to previous menu.

The image shows three screenshots of a handheld device's display, likely a Trimble TSC2, demonstrating the process of setting a station coordinate and querying data.

Screenshot 1: Set Station (13:50:18)

This screen shows the "Set Station" menu. The "PtID" field contains "1". The "Code" field contains "2". The "N" field contains "1100.000 m". The "E" field contains "1050.000 m". The "Z" field contains "0.000 m". Below the fields are buttons for "Find", "Store", and "Determine".

Screenshot 2: Data Query (13:54:08)


This screen shows the "Data Query" menu. The "PtID" field contains "8". The "Code" field contains "1". The "N" field contains "7.000 m". The "E" field contains "7.000 m". The "Z" field contains "7.000 m". Below the fields are buttons for "FIR", "END", and "Determine".

Screenshot 3: Set Station (13:50:18)

This screen shows the "Set Station" menu again, identical to the first one, with PtID 1, Code 2, N 1100.000 m, E 1050.000 m, and Z 0.000 m. Below the fields are buttons for "Find", "Store", and "Determine".



- ③ Press “Determine” to enter “Set Backsight point”.
④ There are two ways to set the azimuth.



A: (enter station coordinate and backsight point coordinate to set the backsight orientation angle)

- ⑤ Enter the backsight point coordinate into the box and select the code; or, press “F1” (Find) to call the point coordinates stored in the coordinate data file in the memory and then operate as follows:

Press “F1” (FIR) to jump to the first point;

Press “F2” (END) to jump to the last point;



Press the button “◀▶” following ‘PtID’ to choose the point.

Press “F4” (Determine) to confirm the point

and return to previous menu, or press “⬅”, to return to previous menu.

- ⑥ Press “F4” (Determine) to enter “Set the azimuth”.

- ⑦ If the backsight point is correct, sight the backsight point and press “F4” (Determine) to return.





| | | | | | | | | | | | | | | | | | |
|---|--|------|--------|------|--------|---|------------|---|------------|---|---------|------|------------------------------|----|----------|----|----------|
| | <p>【Set Backsight point】</p> <table><tr><td>Data</td><td>[PtID]</td></tr><tr><td>Code</td><td>[Code]</td></tr><tr><td>N</td><td>1119.696 m</td></tr><tr><td>E</td><td>1053.473 m</td></tr><tr><td>Z</td><td>0.000 m</td></tr></table> <p>Find Store Angle Determine</p> <p>【Set the azimuth】</p> <table><tr><td>Data</td><td>[Sighting target set up no?]</td></tr><tr><td>Ho</td><td>0°00'00"</td></tr><tr><td>HR</td><td>0°00'00"</td></tr></table> <p>Back Determine</p> | Data | [PtID] | Code | [Code] | N | 1119.696 m | E | 1053.473 m | Z | 0.000 m | Data | [Sighting target set up no?] | Ho | 0°00'00" | HR | 0°00'00" |
| Data | [PtID] | | | | | | | | | | | | | | | | |
| Code | [Code] | | | | | | | | | | | | | | | | |
| N | 1119.696 m | | | | | | | | | | | | | | | | |
| E | 1053.473 m | | | | | | | | | | | | | | | | |
| Z | 0.000 m | | | | | | | | | | | | | | | | |
| Data | [Sighting target set up no?] | | | | | | | | | | | | | | | | |
| Ho | 0°00'00" | | | | | | | | | | | | | | | | |
| HR | 0°00'00" | | | | | | | | | | | | | | | | |
| B: (enter station coordinate and azimuth to set the backsight orientation angle) | <p>【Set Backsight point】</p> <table><tr><td>Data</td><td>[PtID]</td></tr><tr><td>Code</td><td>[Code]</td></tr><tr><td>N</td><td>1119.696 m</td></tr><tr><td>E</td><td>1053.473 m</td></tr><tr><td>Z</td><td>0.000 m</td></tr></table> <p>Find Store Angle Determine</p> | Data | [PtID] | Code | [Code] | N | 1119.696 m | E | 1053.473 m | Z | 0.000 m | | | | | | |
| Data | [PtID] | | | | | | | | | | | | | | | | |
| Code | [Code] | | | | | | | | | | | | | | | | |
| N | 1119.696 m | | | | | | | | | | | | | | | | |
| E | 1053.473 m | | | | | | | | | | | | | | | | |
| Z | 0.000 m | | | | | | | | | | | | | | | | |
| ⑤ Press "F3" (Angle) to enter "H angle setting". | | | | | | | | | | | | | | | | | |



- ⑥ Enter H angle and press “F4” (Determine) to enter “Set the azimuth”.

The screenshot shows the "H Angle setting" interface. At the top, there are icons for antenna, battery, signal, and a 345 button. The time is 13:52:08. Below the title bar, there is a "Data" input field and a label "H Angle :". At the bottom, there are "Back" and "Determine" buttons.

The screenshot shows the "Set the azimuth" interface. At the top, there are icons for antenna, battery, signal, and a 345 button. The time is 13:52:24. Below the title bar, there is a "Data" input field and a label "Sighting target set up no?". There are two entries: "Ho : 0°00'00"" and "HR : 0°00'00"". At the bottom, there are "Back" and "Determine" buttons.

6.2 Measurement

| Procedure | Display |
|---|--|
| <p>① Click “Meas” to reveal page 1 of the Programs interface.</p> <p>Press “” and you can return to previous menu.</p> <p>② Press “Meas” or “2” to enter measurement configuration interface.</p> | <p>The screenshot shows the "Programs" interface. At the top, there are icons for antenna, battery, signal, and a 345 button. The time is 16:17:05. Below the title bar, there are three tabs: "Meas" (selected), "Meas+", and "Road". There are six numbered icons: 1. Station Setup, 2. Meas, 3. Layout, 4. STORE, 5. Rep.Angle, and 6. Resection.</p> |



Press “F1” or (1) to set the job.

Press “F2” or (2) to set the station.

Press “” to return to previous menu.

Station, azimuth, instrument height and prism height can be set in the measurement interface.

The screenshot shows the [Meas] menu screen. At the top right, it displays the time 13:55:20 and battery level 345. Below the title, there is a text input field labeled "Con.". Underneath, there are three items: "[●] F1 Set Job (1)", "[] F2 Station Setup (2)", and "F4 Start (4)". At the bottom, there is a row of buttons: F1, F2, and F4.




The screenshot shows the [Routine Meas] configuration screen. At the top right, it displays the time 8:38:52 and battery level 345. Below the title, there is a table with four columns: Meas 1, Meas 2, Coor, and Code. The Meas 1 section contains fields for PtID (1), Pri.IHT (0.000 m), Remark (-----), HR (0°00'00"), V (0°00'00"), and HD (0.000 m). At the bottom, there are buttons for Meas, Rec, Meas, Store, and a downward arrow.

③ Set backsight point.

④ Sight backsight point, set the azimuth and press “F4” (Detemine) to return to previous interface.

The screenshot shows the [Set Backsight point] configuration screen. At the top right, it displays the time 13:51:09 and battery level 345. Below the title, there is a table with five rows: Data, PtID, Code, N (1119.696 m), E (1053.473 m), and Z (0.000 m). At the bottom, there are buttons for Find, Store, Angle, and Detemine.



| | |
|--|--|
| |  |
| ⑤ To set prism height, press "F3" (Ins.HT) and enter prism height. Then press "F4" (Determine) to save it and return to previous menu. |   |




- ⑥ Press “F2” (Meas) to start distance and coordinate measurement. To record data measured this time, press “F3” (Store) to record data of the point.

| | | | |
|----------------|----------|-------|---------|
| 【Routine Meas】 | | | |
| Meas 1 | Meas 2 | Coor. | Code |
| PtID : | 1 | | |
| Pri.HT : | 0.000 m | | |
| Remark : | ----- | | |
| HR : | 0°00'00" | | |
| V : | 0°00'00" | | |
| HD : | 0.000 m | | |
| Meas | Rec | Meas | Store ↓ |

6.3 Traverse survey

In this mode, the measured foresight point coordinate will be saved in the memory. When the user moves to the next station, the program will automatically use the previous station for the backsight orientation. When the instrument is moved to another station, erected and aimed at the previous station, it will show back azimuth of the backsight directed edge. If the station coordinate is not entered, it will be set to (0, 0, 0) or the last preset station coordinate will be used.




- Properly set coordinate of station P0 and azimuth between P0 and fixpoint A

| | |
|-----------|---------|
| Procedure | Display |
|-----------|---------|




- ① Under Programs mode, press “Meas” to reveal page 1 of the Programs interface.

Press “” to return to previous menu.



- ② Press “STORE” or (4) to enter traverse survey configuration interface. Press “F1” or (1) to enter job setting interface. Press “F2” or (2) to enter station setup interface.


Press “” to return to previous menu.






- ③ Press “F4” or (4) to enter traverse survey interface.

④ Press and hold “F4” (↓ or |←) until the button “Ins.HT” appears. Press “F1” (Ins.HT) to reset instrument height or prism height.

⑤ Press and hold “F4” (↓ or |←) until the button “EDM” appears. Press “F2” (EDM) to reconfigure EDM.





| | |
|---|--|
| |  |
| ⑥ Sight foresight target point P1 prism. ⑦ Press and hold "F4" (↓ or ←) until the button "Meas" appears. Press "F1" (Meas) to start measuring. |  |
| ⑧ Display horizontal distance and horizontal angle. |  |



⑨ Press and hold “F4” (↓ or ←) until the button “Set” appears. Press “F2” (Set) and coordinate of P1 and the question whether to set up the station will be displayed.

The screen shows a yellow header bar with icons for signal strength, battery, and memory (345). The time is 16:29:26. A yellow bar at the top says "【Message】". Below it, the coordinates are listed:
N: 3.420 m
E: 5.920 m
Z: 2.674 m
Station?
At the bottom are two buttons: "No" and "Yes".

⑩ Press ‘F4’ (YES).
Coordinate of P1 is set as the station.

The screen shows a blue header bar with icons for signal strength, battery, and memory (345). The time is 16:28:03. A blue bar at the top says "【STORE】". Below it, there is a table with fields for PtID, HR, HD, N, E, and Z, all populated with values from the previous screen. At the bottom are four buttons: "Meas", "Set", "Azimuth", and a downward arrow.

(11) Transfer the instrument to P1 and conduct leveling and centering.

The screen shows a blue header bar with icons for signal strength, battery, and memory (345). The time is 14:33:19. A blue bar at the top says "【Traver. incl. Adjus.】". Below it, there is a table with fields for PtID, HR, HD, N, E, and Z, all set to zero. At the bottom are four buttons: "Meas", "Set", "Azimuth", and a downward arrow.



(12) Sight prism for previous instrument station P0. Press and hold “F4” (↓ or | ←) until the button “Azimuth” appears. Press “F3” (Azimuth).

| | |
|------|-----------|
| Ho : | 47°01'44" |
| HR : | 0°00'00" |

Back Determine

(13) Press “F4” (Determine) and the azimuth between P1 and P0 is set.

| | |
|--------|----------|
| PtID : | 1 |
| HR : | 0°00'00" |
| HD : | 0.000 m |
| N : | 0.000 m |
| E : | 0.000 m |
| Z : | 0.000 m |

Meas Set Azimuth ↓

(14) Sight prism for foresight target point P2.

| | |
|--------|----------|
| PtID : | 1 |
| HR : | 0°00'00" |
| HD : | 0.000 m |
| N : | 0.000 m |
| E : | 0.000 m |
| Z : | 0.000 m |

Meas Set Azimuth ↓


(15) Repeat steps ⑦ ~ (15) and the repeat count shall be determined as required.

6.4 Remote elevation measurement

This program is intended for remote measurement of vertical distance (height) of target from the



prism and its elevation from the ground (prism height not required). If prism height is used, the prism is taken as the base point for remote elevation measurement. When prism is not used, the ground point for vertical angle measurement will serve as the base point. Based points for the above two cases are both on the plumb line of the target point.




1) Enter prism height (h) (e.g.: h=1.5m)

| Procedure | Display |
|--|---------|
| <p>① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.</p> <p>Press “” to return to previous menu.</p> | |
| <p>② Press “REM” or (0) and (1) to enter remote elevation measurement configuration interface.</p> <p>Press “F1” or (1) to enter job setting interface.</p> <p>Press “F2” or (2) to enter station setup interface.</p> <p>Press “” to return to previous menu.</p> | |




- ③ Press ‘F4’ or (4) to enter remote elevation measurement interface.




- ④ Press the button “” following Input Pri.HT and select “YES”.

- ⑤ Enter prism height into the field of Pri.HT and press “F4” (Set) to set the prism height.





- ⑥ Sight prism P and press “F1” (Prism).




- ⑦ Press “F1” (Meas) to start measuring and the horizontal distance (HD) between instrument and prism will be displayed.



| | |
|--|--|
| |  |
| <p>⑧ Press “F4” (Set) to return to remote elevation measurement interface.</p> <p>⑨ Sight target K and the vertical distance (VD) will be displayed. ※1)</p> |  |
| ※1) Press “” to return to previous menu. | |

1) No prism height entered




| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.

Press “” to return to previous menu.




- ② Press “REM” or (0) and (1) to enter remote elevation measurement configuration interface.


Press “F1” or (1) to enter job setting interface.

Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.



- ③ Press “F4” or (4) to enter remote elevation measurement interface.





| | |
|--|--|
| <p>④ Press the button “ ” following Input Pri.HT and select “NO”.</p> | <p>The screenshot shows the REM software interface. At the top, there are icons for a camera, a computer monitor, a globe, and a battery level at 34%. The time is 16:04:22. Below the icons, the text "【REM】" is displayed. In the center, there is a "Meas" input field. Underneath it, the text "Input Pri.HT" is followed by a "No" button with left and right arrow keys. To the right of this, there are fields for "VA" (0°00'00") and "VD" (0m). At the bottom, there are tabs for "Prism" and "Ground".</p> |
| <p>⑤ Sight prism P and press “F1” (Prism).</p> | <p>The screenshot shows the REM software interface. At the top, there are icons for a camera, a computer monitor, a globe, and a battery level at 34%. The time is 16:03:36. Below the icons, the text "【REM】" is displayed. In the center, there is a "Meas" input field. The text "Meas Prism: Sight,OK?" is displayed below it. At the bottom, there are tabs for "Meas" and "Set".</p> |
| <p>⑥ Press “F1” (Meas) to start measuring and the horizontal distance (HD) between instrument and prism will be displayed.</p> | <p>The screenshot shows the REM software interface. At the top, there are icons for a camera, a computer monitor, a globe, and a battery level at 34%. The time is 10:33:12. Below the icons, the text "【REM】" is displayed. In the center, there is a "Meas" input field. The text "Meas Prism: Sight,OK?" is displayed below it. Below that, the text "HD" is followed by a value of "58.438m". At the bottom, there are tabs for "Meas" and "Set".</p> |



- ⑦ Press “F4” (Set) to return to remote elevation measurement interface and the prism position is determined.


The figure consists of three vertically stacked screenshots of the REM (Remote Elevation Measurement) software interface. Each screenshot shows a blue header bar with icons for antenna, battery, signal strength, and a circular progress bar labeled '34s'. The main area is titled '[REM]' in blue. The first screenshot shows 'Meas' input fields for 'Input Pri.HT' (No), 'VA' (18°33'58"), and 'VD' (0.000 m). The second screenshot shows the same fields after a measurement. The third screenshot shows the 'Meas' input field and a message 'Meas Ground: Sight,OK?' above the 'VA' field, which now displays '18°33'58"'. At the bottom right of the third screenshot is a blue button labeled 'Set'.

- ⑧ Sight ground point G and press “F2” (Ground). ≈1)

- ⑨ Press “F4” (Set) and the position of G is determined. ≈1)



- ⑩ Sight target K. The vertical distance (VD) will be displayed. ≈1)




≈1) Press "⬅" to return to previous menu.

6.5 Missing line measurement

Horizontal distance (dHD), slope distance (dSD) and elevation difference (dVD) between two prisms can be measured.

Missing line measurement mode has two functions:

1. (A-B, A-C): to measure A-B, A-C, A-D.....
2. (A-B, B-C): to measure A-B, B-C, C-D.....



[Example] 1. (A-B, A-C)

- Measurement procedure for 2. (A-B, B-C) is the same as that for 1. (A-B, A-C).


| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.



Press “” to return to previous menu.




- ② Press “MLM” or (7) to enter missing line measurement configuration interface.


Press “F1” or (1) to enter job setting interface.

Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.



- ③ Press “F4” or (4) to enter missing line measurement method selection interface.





- ④ Press “F2” or (2) to enter missing line measurement interface.

In missing line measurement interface:

Press and hold “F4” (↓ or | ←) until the button “EDM” appears. Press “F2” (EDM) to enter EDM setting interface to configure EDM.

Press and hold “F4” (↓ or | ←) until the button “Reset” appears. Press “F3” (Reset) and you can reset missing line measurement.

| | |
|-------|--|
| Meas1 | |
| HD : | |
| dHD : | |
| dVD : | |
| dSD : | |
| HR : | |
| Num : | |

Meas | EDM | Reset | ↓

Press and hold “F4” (↓ or | ←) until the button “Pre” appears. Press “F2” (Pre) and you can check the previous missing line measurement result until the first missing line measurement result.

Press and hold “F4” (↓ or | ←) until the button “Next” appears. Press “F3” (Next) and you can check the next missing line measurement result until the last missing line measurement result.


- ⑤ Sight prism A and press “F1” (Meas). The horizontal distance between instrument and prism A will be displayed.

| | |
|-------|------------|
| Meas1 | |
| HD : | 56.343 m |
| dHD : | |
| dVD : | |
| dSD : | |
| HR : | 324°23'02" |
| Num : | 0 |


Meas | EDM | Reset | ↓



- ⑥ Sight prism B and press “F1” (Meas). The horizontal distance between instrument and prism B as well as horizontal distance (dHD), elevation difference (dVD) and slope difference (dSD) between prism A and prism B will be displayed.




- ⑦ To measure distance between point A and point C, sight prism C and press “Meas”. Then, the horizontal distance between instrument and prism C as well as horizontal distance (dHD), elevation difference (dVD) and slope difference (dSD) between prism A and prism C will be displayed.



- Press “” to return to previous menu.

6.6 Repetition angle measurement

This program is intended for cumulative repeated angle measurements, display the sum of angle measurements and average value of all angle measurements and record the number of measurements.





| Procedure | Display |
|--|---------|
| <p>① Under Programs mode, press “Meas” to reveal page 1 of the Programs interface.</p> <p>Press “” to return to previous menu.</p> | |
| <p>② Press “Rep.Angle” or “5” to enter repetition angle measurement configuration interface.</p> <p>Press “F1” or (1) to enter job setting interface.</p> <p>Press “F2” or (2) to enter station setup interface.</p> <p>Press “” to return to previous menu.</p> | |
| <p>③ Press “F4” or (4) to enter repetition angle measurement interface:</p> <p>In repetition angle measurement interface: Press “F3” (Reset) to reset repetition angle measurement.</p> | |



- ④ Sight the first target A; press “F1” or (Meas) and the angle will be set to zero.

14:35:34 34s ⚡

【Rep. Angle】

| | |
|---------------------------------|-----------|
| Meas | |
| A P2(B),Meas.,ANG will be held! | |
| H : | 35°14'28" |
| Total : | 0°00'00" |
| Average : | 0°00'00" |
| Difference : | 0°00'00" |
| Num : | 0 <99 |

Meas Reset

- ⑤ Sight the second target B with horizontal clamp screw and horizontal tangent. Press “F1” or (Meas) and the angle will be held.

14:37:02 34s ⚡

【Rep. Angle】

| | |
|-------------------------------------|-----------|
| Meas | |
| A P1(A),Meas.,ANG will be released! | |
| H : | 35°14'28" |
| Total : | 35°14'28" |
| Average : | 35°14'28" |
| Difference : | 0°00'00" |
| Num : | 1 <99 |

Meas Reset

- ⑥ Sight the first target A again with horizontal clamp screw and horizontal tangent. Press “F1” or (Meas) and the angle will be released.

14:42:00 34s ⚡


【Rep. Angle】

| | |
|---------------------------------|-----------|
| Meas | |
| A P2(B),Meas.,ANG will be held! | |
| H : | 35°14'28" |
| Total : | 35°14'28" |
| Average : | 35°14'28" |
| Difference : | 0°00'00" |
| Num : | 1 <99 |


Meas Reset



- ⑦ Sight the second target B again with horizontal clamp screw and horizontal tangent. Press “F1” or (Meas) and the angle will be held. The angle total, average angle and angle difference will be displayed.



- ⑧ Repeat steps ⑥ and ⑦, as required, to conduct repetition angle measurement.



- Press “” to return to previous menu.

6.7 Coordinate layout

The layout program can calculate the layout elements based on layout point coordinate or manually entered angle, horizontal distance and height and the layout difference will be continuously displayed.

Layout procedure:


1. Job setting
2. Station setup
3. Backsight azimuth setting
4. Extract coordinates from the memory and the coordinates here can be either measured or coordinates of a fixpoint that have been entered.

The layout program can help users loft each point number based on the point number and



coordinates at work site. The coordinate data can be transmitted between instrument memory and a computer and the Bluetooth of the instrument can be activated for this.

Coordinate data consist of point number (N, E, Z) and stored in the job name which can have a maximum length of 7 characters. 20 job names can be stored in the instrument and the job name may comprise numbers and characters.



| Procedure | Display |
|--|---------|
| <p>① Under Programs mode, press “Meas” to reveal page 1 of the Programs interface. Press “↶” to return to previous menu.</p> | |




② Press “Layout” or (3) to enter coordinate layout configuration interface.


Press “F1” or (1) to enter job setting interface.

Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.




③ Press “F4” or (4) to enter coordinate layout interface.





6.7.1 Layout point setting

With backsight azimuth set, coordinate layout can be carried out.





6.7.1.1 Coordinate extraction from job

| Procedure | Display | | | | | | | | | | | | |
|---|--|--------------------|------|-------|--|-----------|--------------------|---|-----------|--------------------|---|-----------|--------------------|
| <p>① Enter coordinate layout interface by following the procedure of 6.7.</p> <p>② Enter point name to be lofted into the field of “Search” and press “OK” to start point searching function. (You may also enter the wildcard “*” and start wildcard searching.)</p> |  <p>The screenshot shows the [Layout] dialog box. At the top, there are tabs for Meas, Place, and Coor., with Place being the active tab. Below the tabs are several input fields: Search (containing '*'), PtID (empty), HR (0°00'00"), dHR (0°00'00"), HD (0.000), and dHD (0.000). To the right of these fields is a large yellow rectangular area representing the search results. Below the input fields is a table with columns Meas, Coor., See, and a downward arrow. The first row of the table has Meas as 'stake', Coor. as 'Grid', and See as a downward arrow. The second row has Meas as 'Ins. HT', Coor. as 'EDM', and See as a leftward arrow.</p> | | | | | | | | | | | | |
| <p>③ The program will search for point names in the job and display the result dialog to list all point names that have been found. (If wildcard “*” is entered, all data in the job will be displayed.) Select a point by clicking it.</p> |  <p>The screenshot shows the [List] dialog box. At the top, there are tabs for PtID, Type, and Dates, with PtID being the active tab. Below the tabs is a table with four rows. The columns are PtID, Type, and Dates. The data in the table is as follows:</p> <table border="1"><thead><tr><th>PtID</th><th>Type</th><th>Dates</th></tr></thead><tbody><tr><td></td><td>Fixpoints</td><td>2016/3/10 14:06:22</td></tr><tr><td>1</td><td>Fixpoints</td><td>2016/3/10 15:46:33</td></tr><tr><td>2</td><td>Fixpoints</td><td>2016/3/10 15:44:16</td></tr></tbody></table> <p>At the bottom of the dialog are buttons for Back and See.</p> | PtID | Type | Dates | | Fixpoints | 2016/3/10 14:06:22 | 1 | Fixpoints | 2016/3/10 15:46:33 | 2 | Fixpoints | 2016/3/10 15:44:16 |
| PtID | Type | Dates | | | | | | | | | | | |
| | Fixpoints | 2016/3/10 14:06:22 | | | | | | | | | | | |
| 1 | Fixpoints | 2016/3/10 15:46:33 | | | | | | | | | | | |
| 2 | Fixpoints | 2016/3/10 15:44:16 | | | | | | | | | | | |



- ④ Press “F2” (See) to view the coordinate data.

The screenshot shows the [Coor. Data] interface with the following data:

| | |
|--------|-----------|
| PtID : | 1 |
| Code : | 1 |
| N : | 1.000 m |
| E : | 1.000 m |
| Z : | 3.000 m |
| Type : | Fixpoints |

Buttons at the bottom: Back, Determine.

- ⑤ Press “F4” (Determine) to select the layout point and enter the layout interface.
Press “F1” (Back) to give up and return to previous interface.

The screenshot shows the [Layout] interface with the following data:

| | |
|----------|-------------|
| Search : | * |
| PtID : | 1 |
| HR : | 0°00'00" |
| dHR : | -225°33'32" |
| HD : | 0.000 |
| dHD : | 0.000 |

Buttons at the bottom: Meas, Coor., See.

A large yellow area on the right side contains a black arrow pointing left.

- ⑥ Press “F1” (Meas) to start layout.

The screenshot shows the [Layout] interface with the following data:

| | |
|----------|------------|
| Search : | * |
| PtID : | 1 |
| HR : | 0°00'00" |
| dHR : | 131°52'50" |
| HD : | 10.000 |
| dHD : | 5.000 |

Buttons at the bottom: Meas, Coor., See.

A large yellow area on the right side contains three black arrows: one pointing left, one pointing down, and one pointing right.




6.7.1.2 Manual entry of layout point

A layout point can be manually entered with buttons [Coor.] and [stake].

Method 1: Press “F2” (Coor.) to enter coordinates of the point to be staked and confirm to promptly




enter the layout procedure for this entered point.

| Procedure | Display |
|---|--|
| ① Enter coordinate layout interface by following the procedure of 6.7. |  |
| ② Press "F2" (Coor.) to enter coordinate input interface. ③ Enter the point name, N, E and Z and chose the code. Press "F2" (Store) and you can save to store the data of this point in the job. Press "F1" (Back) to give up and return to previous menu. |  |
| ④ Press "F4" (Determine) to confirm to make the entered point the layout point. |  |



⑤ Press “F1” (Meas) to start layout.



Method 2: Press “F2” (stake) to enter a layout point without point name and the need to store its data.

| Procedure | Display | | | | | | | | | | | | | | | | | | | | | |
|--|---|-------|-------|-------|------------|--|--|--------|--|--|---------------|--|--|----------------|--|--|------------|--|--|-------------|--|--|
| Enter coordinate layout interface by following the procedure of 6.7. | <p>The screenshot shows the Layout interface with the Place tab selected. The display area is completely yellow. The data in the Place tab is identical to the Meas tab in the previous screenshot.</p> <table border="1"><tr><th>Meas</th><th>Place</th><th>Coor.</th></tr><tr><td>Search : *</td><td></td><td></td></tr><tr><td>PtID : </td><td></td><td></td></tr><tr><td>HR : 0°00'00"</td><td></td><td></td></tr><tr><td>dHR : 0°00'00"</td><td></td><td></td></tr><tr><td>HD : 0.000</td><td></td><td></td></tr><tr><td>dHD : 0.000</td><td></td><td></td></tr></table> | Meas | Place | Coor. | Search : * | | | PtID : | | | HR : 0°00'00" | | | dHR : 0°00'00" | | | HD : 0.000 | | | dHD : 0.000 | | |
| Meas | Place | Coor. | | | | | | | | | | | | | | | | | | | | |
| Search : * | | | | | | | | | | | | | | | | | | | | | | |
| PtID : | | | | | | | | | | | | | | | | | | | | | | |
| HR : 0°00'00" | | | | | | | | | | | | | | | | | | | | | | |
| dHR : 0°00'00" | | | | | | | | | | | | | | | | | | | | | | |
| HD : 0.000 | | | | | | | | | | | | | | | | | | | | | | |
| dHD : 0.000 | | | | | | | | | | | | | | | | | | | | | | |



② Press “F2” (stake) to enter layout point input interface.

③ Enter N, E and Z. If N, E and Z are all set to 0, directly press “F2” (Zero). Press “F1” (Back) to give up and return to previous menu.

The screenshot shows the 'Layout' interface with the 'Data' tab selected. It displays three input fields for coordinates: N : 0|m, E : 0|m, and Z : 0|m. Below the input fields are three buttons: 'Back', 'Zero', and 'Determine'. The status bar at the top right shows the time as 14:29:40.

④ Press “F4” (Determine) to confirm to make the entered point the layout point.

The screenshot shows the 'Layout' interface with the 'Meas' tab selected. It displays several parameters: Search : *, PtID : DEFAULT, HR : 0°00'00", dHR : 131°53'27", HD : 0.000, and dHD : 0.000. To the right of the parameters is a large yellow area with a black arrow pointing right. Below the parameters are three buttons: 'Meas', 'Coor.', and 'See'. The status bar at the top right shows the time as 10:30:42.

⑤ Press “F1” (Meas) to start layout.
“Meas” interface: display the measured horizontal angle (HR), layout angle (dHR), measured horizontal angle, difference between measured horizontal distance and theoretical horizontal distance (dHD) and difference between actual height and theoretical height (dZ). When the instrument turns to the direction of the layout point, the HR displayed is the angle to be staked out and the dHR displayed is zero (0°00'00").

The screenshot shows the 'Layout' interface with the 'Meas' tab selected. It displays the same parameters as the previous screenshot: Search : *, PtID : DEFAULT, HR : 0°00'00", dHR : 131°53'27", HD : 10.000, and dHD : 5.000. To the right of the parameters is a large yellow area with a black arrow pointing right and a smaller black arrow pointing down. Below the parameters are three buttons: 'Meas', 'Coor.', and 'See'. The status bar at the top right shows the time as 14:30:05.




“Place” interface: Display the horizontal situation, horizontal distance direction and vertical direction of the point being searched.

▲ / ▼ : vertical direction

↑ / ↓ : horizontal distance direction


→ / ← : horizontal direction

“Coor.” Interface: Display coordinates of the point after layout.



Explanations for the buttons below:

“F3” (EDM): to enter EDM setting interface.





“F3” (See): to view layout point coordinates, point name and code.

| | |
|--------|---------|
| PtID : | 22 |
| Code : | 1 |
| N : | 2.000 m |
| E : | 2.000 m |
| Z : | 2.000 m |

| | |
|----------|---------|
| Pri.HT : | 0.000 m |
| Ins.HT : | 0.000 m |

“F2” (Ins.HT): to enter instrument height setting interface to change instrument height and prism height.

6.7.2 Grid factor

For the purpose of layout, the grid factor can be set. The following formula shows how to calculate the grid factor used for calculation of distance.

Formula:

$$1. \text{Elevation factor} = \frac{R}{R + ELEV}$$

Where: R – mean radius of the earth;

ELEV – elevation above mean sea level

2. Scaling factor

Scaling factor: scaling factor on the station

3. Grid factor

Grid factor = elevation factor X scaling factor

Distance calculation:



1. Grid distance

$$HDg = HD \times \text{grid factor}$$

HDg: grid distance

HD: ground distance



2. Ground distance

$$HD = \frac{HDg}{\text{Grid factor}}$$

Notes: 1. Input range of scaling factor: 0.0900000 ~ 1.0100000; default value is 1.00000


2. Input range of altitude: -1000.000 ~ 10000.000

Keep three decimal places for altitudes and the default altitude is 0.

| Procedure | Display |
|--|--|
| ① Enter coordinate layout interface by following the procedure of 6.7. |  <p>The screenshot shows the Layout interface with the Place tab selected. It includes search fields for PtID, HR, dHR, HD, and dHD, and a large yellow placeholder area.</p> |
| ② Press "F3" (Grid) to enter grid factor setting interface. ③ Enter altitudes and scaling factor. |  <p>The screenshot shows the Grid factor interface with fields for Grid factor (1.000000), High altitudes (0.000 m), and Scaling factor (1).</p> |



- ④ Press “F4” (Determine) to save the settings and return to previous menu. Press “F1” (Back) to return to previous menu without saving the settings.



6.8 Resection

The resection program calculates coordinates of the new station with two points whose coordinates are known and stored in the job. It will display the measured angle and distance between the station and each fixpoint as well as horizontal distance and elevation difference residual errors. If the software cannot calculate coordinates of the new point, it will display “OUT!”. If it accepts the displayed residual errors, coordinates of the new point will be displayed on the next screen.

Calculation of resection point coordinates will be explained in detail in the following part (with the instrument erected on the new point)


| Procedure | Display |
|---|---------|
| <p>① Under Programs mode, press “Meas” to reveal page 1 of the Programs interface.</p> <p>Press “↶” to return to previous menu.</p> | |



② Press “Resection” or (6) to enter resection configuration interface.


Press “F1” or (1) to enter job setting interface.

Press “” to return to previous menu.




③ Press “F4” or (4) to enter resection interface.

Press “” to return to previous menu.



Press “F2” (EDM) and you can enter EDM setting interface.





④ Press “F3” (Coor.) to enter point 1 coordinate setting interface.

⑤ Directly enter coordinates of the point or press “F1” (Find) to search for its coordinates in the file.

The top screenshot shows the "Resection-P1" interface. It displays coordinates for Point 1: PtID: 1, Code: 1c, N: 5.152 m, E: 0.000 m, Z: 1.511 m. Below it, the "Data Query" interface shows coordinates for Point 6: PtID: 6, Code: 1, N: 1.000 m, E: 5.000 m, Z: 6.000 m.

⑥ With coordinates of the point entered, press “F4” (Detemine) to return to point 1 measurement interface.

⑦ Press “F1” (Meas) to measure coordinates of point 1.

The screenshot shows the "Resection" interface with the following data: Routine: 1, No.: 1, HR: 0°00'00", HD: 12.546 m, VD: 1.324 m. At the bottom, there are buttons for Meas, EDM, Coor., and NextPT.



- ⑧ When measurement is finished, press “F4” (NextPT) to enter point 2 measurement interface.

The screenshot shows the Resection interface with the following data:

| | |
|-------|-------------|
| No. : | -----2----- |
| HR : | 0°00'00" |
| HD : | m |
| VD : | m |

Below the interface are four buttons: Meas, EDM, Coor., and NextPT.

- ⑨ Press “F3” (Coor.) to enter point 2 coordinate setting interface.

- ⑩ Directly enter coordinates of the point or press “F1” (Find) to search for its coordinates in the file.

The screenshot shows the Resection-P2 interface with the following data:

| | |
|--------|---------|
| PtID : | 2 |
| Code : | 2c |
| N : | 5.111 m |
| E : | 0.349 m |
| Z : | 1.738 m |

The screenshot shows the Data Query interface with the following data:

| | |
|--------|---------|
| PtID : | 6 |
| Code : | 1 |
| N : | 1.000 m |
| E : | 5.000 m |
| Z : | 6.000 m |

Below the interface are three buttons: Find, Store, and Detemine.



(11) With coordinates of the point entered, press “F4” (Determine) to return to point 2 measurement interface.

(12) Press “F1” (Meas) to measure coordinates of point 2.

The screenshot shows the "Resection" measurement interface. The top status bar displays icons for antenna, computer, battery, signal strength, and time (10:22:42). The main area is titled "[Resection]" with a "Routine" field. Below it, the coordinates for point 2 are listed:

| | | |
|-----|---|-------------|
| No. | : | -----2----- |
| HR | : | 0°00'00" |
| HD | : | 12.435 m |
| VD | : | 3.125 m |

At the bottom, there are tabs for Meas, EDM, Coor., and NextPT.

(13) When measurement is finished, press “F4” (NextPT) and the residual errors will be displayed.

The screenshot shows the "Resection-Residual Error" interface. The top status bar displays icons for antenna, computer, battery, signal strength, and time (15:24:04). The main area is titled "[Resection-Residual Error]" with a "Data" field. Below it, the residual errors are listed:

| | | |
|-----|---|------------|
| dHR | : | 359°59'25" |
| dHD | : | 0.001 m |

At the bottom, there are tabs for Coor. and NextPT.

(14) If residual errors are within allowed ranges, press “F1” (Coor.) and coordinates of the point will be displayed.

The screenshot shows the "Resection-Residual Error" interface. The top status bar displays icons for antenna, computer, battery, signal strength, and time (15:24:47). The main area is titled "[Resection-Residual Error]" with a "Data" field. Below it, the point coordinates are listed:

| | | |
|---|---|---------|
| N | : | 0.002 m |
| E | : | 0.057 m |
| Z | : | 1.511 m |

At the bottom, there are tabs for Station and NextPT.



(15) To record or set coordinates of the station, press “F1” (Station). Enter the point number, select the code and, if you want to save it, press “F3” (Store).

Press “F4” (Determine) and the point will be set as the station.

The image displays three sequential screenshots of the "Resection-Data" software interface from SMART MAX GEOSYSTEMS. The interface is a handheld device screen with a blue header bar and a white data entry area.


Screenshot 1: Resection-Data
The header shows icons for a camera, a computer, and a globe, with the time 15:25:02 and a battery level of 34%. The title bar says "Resection-Data".
The data entry area has fields for "PtID" and "Code". The "PtID" field is empty, and the "Code" field contains the value "1".
Buttons at the bottom include "Data", "Store", and "Determine".

Screenshot 2: Set the azimuth
The header shows the same information: 15:25:23, 34% battery.
The title bar says "Set the azimuth".
The data entry area has fields for "Ho" and "HR". The "Ho" field contains "3°16'33\"", and the "HR" field contains "0°00'00\". A question "Sighting target set up no?" is also present.
Buttons at the bottom include "Back", "Store", and "Determine".

Screenshot 3: Resection
The header shows the same information: 15:25:40, 34% battery.
The title bar says "Resection".
The data entry area has fields for "No.", "HR", "HD", and "VD". The "No." field contains "2", and the "HD" and "VD" fields both contain "m".
Buttons at the bottom include "Meas", "EDM", "Coor.", and "NextPT".




- (16) If you want to continue resection, press “NextPT”.



6.9 Line measurement

It is used to measure the unattainable target height above a ground point. Not only the target overhead but also all points along the ground base line are all unattainable. Set prisms A and B below the overhead line to form a base line, with certain distance between prisms A and B. Respectively measure horizontal distances between instrument and prism A and between instrument and prism B and store them in the instrument. The display will show vertical distance between prism A and B, horizontal distance between instrument and prism B, distance along base line direction as well as vertical distance and horizontal distance between prism A and the target point. Thus, the vertical distance between both ends of the base line and vertical distance between point G and point L in the figure below can also be measured.




[Example: prism input]

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.

Press “” to return to previous menu.




- ② Press “Line Meas” or (8) to enter line measurement configuration interface.

Press “F1” or (1) to enter job setting interface.


Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.




- ③ Press “F4” or (4) to enter line measurement prism selection interface.

Press “” to return to previous menu.







- ④ Press “F1” or (1) to have prism height.
⑤ Enter prism height.



- ⑥ Press “F4” (Determine) to enter line measurement interface.
◦
⑦ Sight prism A and press “F1” (Meas) to start distance measurement.
Press “F2” (EDM) and you can enter EDM setting interface.




- ⑧ Horizontal distance is displayed.







- ⑨ Press “F4” (Set) to save horizontal distance.






- ⑩ Sight prism B and press “F1” (Meas) to start distance measurement.



(11) Horizontal distance is displayed.






| | |
|---|--|
| (12) Press "F4" (Set) to save horizontal distance. |  <p>14:19:25 [Line Meas] <input type="button" value="Set"/> Dist. VD : 34.223 m HD : 63.523 m OFF : 24.546 m LINE</p> |
| (13) Sight point L on overhead line. The display will show measurement data of point L. VD: elevation difference of point L relative to A HD: horizontal distance between instrument station and point L Off: horizontal distance between point A and point L |  <p>14:19:25 [Line Meas] <input type="button" value="Set"/> Dist. VD : 34.223 m HD : 63.523 m OFF : 24.546 m LINE</p> |
| (14) Press "F1" (LINE). This function is intended to measure elevation of overhead line from the ground and the procedure is as follows: <ul style="list-style-type: none">• First sight the point on the overhead line before pressing "F3" (Confirm).• When setting the corresponding ground point G do not turn the horizontal tangent. (15) Turn vertical tangent and sight the ground point G |  <p>14:22:46 [Line Meas] <input type="button" value="Set"/> Dist. Ground : 132°09'03" V : <input type="button" value="Confirm"/></p> |



(16) Press “F3” (Confirm) and overhead line height LH (elevation) and horizontal distance (Off) will be displayed.



- Press “” to end measurement.
- Press “F2” (VD) to return to step (13).
- If the ground point is not clear, you can press “F4” (Cont) to determine another ground point G on the same plumb line.

6.10 Offset measurement mode

There are a total of 4 offset measurement modes:


1. Angle offset measurement
2. Distance offset measurement
3. Plane offset measurement
4. Column offset measurement

6.10.1 Angle offset measurement mode

This mode is quite useful where it is difficult to erect the prism, for example, center of a tree. Under this mode, horizontal distance between instrument and point P (prism) shall be equal to horizontal distance between instrument and target point. With instrument height/prism height set, conduct offset measurement and you can get coordinates of the center of the observed object.

When measuring projection of A0 (coordinates of ground point A1), please set instrument height and prism height.

When measuring coordinates of A0, only instrument height is required (with prism height set to 0).



There are two ways to set vertical angle in angle offset measurement mode:

1. Free vertical angle: the vertical angle changes with movement of the telescope.

2. Hold vertical angle: the vertical angle is locked and will not change with movement of the telescope.

Hence, if the first way is adopted to sight A0, the vertical angle changes with movement of the telescope; so will the slope distance (SD) and elevation distance (VD). If the second way is adopted to sight A0, the vertical angle will be held at the prism position and will not change with movement of the telescope.

| Procedure | Display |
|--|---------|
| <p>① Under Programs mode, press "Meas+" to reveal page 2 of Programs interface.</p> <p>Press "⬅" to return to previous menu.</p> | |




② Press “Offset Meas” or (0) and (2) to enter offset measurement configuration interface.

Press “F1” or (1) to enter job setting interface.


Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.



③ Press “F4” or (4) to enter offset measurement selection interface.

Press “” to return to previous menu.




④ Press “F1” or (1) to enter angle offset measurement selection interface.

Press “” to return to previous menu.







⑤ Press “F1” or (1) to enter free vertical angle offset measurement, or press “F2” or (2) to enter hold vertical angle offset measurement. (Users can choose the suitable vertical angle offset measurement as required.)
Press “F2” (EDM) to enter EDM setting interface.



⑥ Sight prism P and press “F1” (Prism) to conduct measurement.
(If continuous measurement is adopted, “F4” (Set) shall be pressed when measurement is finished.)



⑦ Sight target point A0 with horizontal clamp screw and tangent. Press “F4” (Set) to display elevation difference, horizontal distance and slope difference between instrument and A0 as well as coordinates of target point (N, E, Z).





| | | | |
|--------------|----------|-----|--|
| | 8:56:11 | 345 | |
| Angle Offset | | | |
| Dist. | Coor. | | |
| N : | 4.523 m | | |
| E : | 14.138 m | | |
| Z : | 2.742 m | | |
| Cont | | | |


1) Press “” and you can return to previous menu.

Instrument height/prism height shall be set prior to offset measurement.

Refer to “6.1.2 Orientation setting” for setting of station coordinates.

6.10.2 Distance offset measurement mode

Enter forward/backward and leftward/rightward offsets of target point from the reflector and you can get position of this target.



To measure coordinates of ground point A1, instrument height and prism height shall be set.

To measure coordinates of target point A0, only instrument height is required (with prism height set to 0).


Refer to “6.1.2 Orientation setting” for setting of station coordinates.

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.

Press “” to return to previous menu.




- ② Press “Offset Meas” or (0) and (2) to enter offset measurement configuration interface.

Press “F1” or (1) to enter job setting interface.


Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.



- ③ Press “F4” or (4) to enter offset measurement selection interface.

Press “” to return to previous menu.





④ Press “F2” or “2” to enter distance offset measurement interface.

⑤ Enter horizontal and longitudinal parameters of offset.

The screenshot shows the "Distance Offset" measurement interface. At the top, it displays the time 9:11:01 and various status icons. Below the title, there is a "Data" input field. Underneath, two parameter entries are shown: "dFR : 13.412" and "dRL : 5.231". At the bottom right is a "Set" button.

⑥ Press “F4” (Set) to enter prism point measurement interface.

⑦ Sight prism and press “F1” (Meas) to start measuring. (If continuous measurement is adopted, “F4” (Set) shall be pressed when measurement is finished.)

When measurement is over, measurements after offset correction will be displayed.

The screenshot shows the "Distance Offset" measurement interface. It displays the time 16:11:32 and various status icons. Below the title, there is a "Data" input field. Underneath, a parameter entry "HD : [] m" is shown. At the bottom right are buttons for "Meas", "EDM", and "Set".

The screenshot shows the "Distance Offset" measurement interface. It displays the time 9:11:42 and various status icons. Below the title, there is a "Data" input field. Underneath, a parameter entry "HD : 43.239 m" is shown. At the bottom right are buttons for "Meas", "EDM", and "Set".




- ⑧ Sight target point A0 with horizontal clamp screw and tangent. Press “F4” (Set) to display elevation difference, horizontal distance and slope difference between instrument and A0 as well as coordinates of target point (N, E, Z).

The figure consists of two vertically stacked screenshots of a handheld device's display. Both screens show a 'Distance Offset' menu with a blue header and a white data area. At the top of each screen are icons for a telescope, battery, signal strength, and a warning triangle. The time '9:19:11' and '34s' are also present. The top screen has tabs 'Dist.' and 'Coor.' with 'Dist.' selected. It displays the following data:
HR : 20°45'12"
V : 112°43'32"
HD : 43.239 m
VD : 13.446 m
SD : 73.329 m
A blue 'Cont' button is at the bottom. The bottom screen also has tabs 'Dist.' and 'Coor.' with 'Dist.' selected. It displays:
N : 4.523 m
E : 14.138 m
Z : 2.742 m
A blue 'Cont' button is at the bottom.

6.10.3 Plane offset measurement mode

This function is intended to measure points that cannot be measured directly, for instance, distance or coordinates of a plane edge.

For application of this function, first measure any three points (P1, P2 and P3) to determine a reference plane (plane to be measured); then sight measure point P0 and the instrument will calculate and display distance and coordinates of the point of intersection of collimation axis and the plane.




Refer to “6.1.2 Orientation setting” for setting of station coordinates.

| Procedure | Display |
|--|---------|
| <p>① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.</p> <p>Press “” to return to previous menu.</p> | |
| <p>② Press “Offset Meas” or (0) and (2) to enter offset measurement configuration interface.</p> <p>Press “F1” or (1) to enter job setting interface.</p> <p>Press “F2” or (2) to enter station setup interface.</p> <p>Press “” to return to previous menu.</p> | |



③ Press “F4” or (4) to enter offset measurement selection interface.


Press “” to return to previous menu.



④ Press “F3” or (3) to enter plane offset measurement interface.



⑤ Sight prism P1 and press “F1” (Meas) to start measuring. (If continuous measurement is adopted, “F4” (Set) shall be pressed when measurement is finished.)





- ⑥ Sight P2 and P3 in the same way and measure point 2 and point 3.

Plane Offset

Second Point

HD : 64.325 m

Meas | EDM | Set

- ⑦ Press "F4" (Set) to calculate and display coordinates or distance of point of intersection of collimation axis and the plane.

Plane Offset

Dist. Coor.

HR : 20°45'12"

V : 112°43'32"

HD : 43.239 m

VD : 13.446 m

SD : 73.329 m

Cont

- ⑧ Sight target point A0 with horizontal clamp screw and tangent. Elevation difference, horizontal distance and slope difference between instrument and A0 as well as coordinates of target point (N, E, Z) will be displayed.

Plane Offset

Dist. Coor.

HR : 20°45'12"


V : 112°43'32"

HD : 43.239 m

VD : 13.446 m

SD : 73.329 m

Cont




- If calculation of the three measure points cannot determine a plane, an error message will be displayed. In this case, conduct measurement again starting from the first point.
- When the collimation direction does not intersect the plane determined, an error message will be displayed.

6.10.4 Column offset measurement mode

First, directly measure distance from instrument to P1 on the column surface. Then, respectively measure direction angles from instrument to P2 and P3 on the column surface. Distance, direction angle and coordinates of column center can then be calculated.

Direction angle of column center equals the average of direction angles of P2 and P3.




Refer to “6.1.2 Orientation setting” for setting of station coordinates.

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.

Press “” to return to previous menu.




- ② Press “Offset Meas” or (0) and (2) to enter offset measurement configuration interface.

Press “F1” or (1) to enter job setting interface.


Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.



- ③ Press “F4” or (4) to enter offset measurement selection interface.

Press “” to return to previous menu.





④ Press “F4” or (4) to enter column offset measurement interface.

Column Offset

Data

Center

HD : m

Meas | EDM | Set

⑤ Sight center of column surface (P1) and press “F1” (Meas) to start measuring. (If continuous measurement is adopted, “F4” (Set) shall be pressed when measurement is finished.) When measurement is over, the display will give the prompt to start measurement of angle of point on left edge of column surface (P2).

Column Offset

Data

Center

HD : 43.239 m

Meas | EDM | Set

⑥ Sight point on left edge of column surface (P2) and press “F4” (Set). When measurement is over, the display will give the prompt to start measurement of angle of point on right edge of column surface (P3).

Column Offset

Data

Left

HR : 20°45'12" m

Set



- ⑦ Sight point on right edge of column surface (P3) and press "F4" (Set).

When measurement is finished, elevation difference, horizontal distance and slope distance between instrument and column center (P0) as well as coordinates of target point (N, E, Z) will be calculated and displayed on the screen.

The screenshots show the 'Column Offset' menu with various parameters being set and calculated:

- First Screenshot (Right):** Shows 'Right' selected. HR : 25°29'03" m.
- Second Screenshot (Dist.):** Shows 'Dist.' selected. HR : 20°45'12" V : 112°43'32" HD : 43.239 m VD : 13.446 m SD : 73.329 m
- Third Screenshot (Coor.):** Shows 'Coor.' selected. N : 4.523 m E : 14.138 m Z : 2.742 m



6.11 Road measurement mode

A road file must be selected before starting road measurement and the road file temp is the current road



file by default. See “6.11.3 Road file” for details.

Enter road measurement menu, as follows:

| Procedure | Display |
|---|--|
| ① Under Programs mode, press “Road” to reveal page 3 of the Programs interface. Press “” to return to previous menu. |  <p>The display shows the "Programs" menu with the time 16:17:26 and battery level 34%. The "Road" option is selected. A small icon of a road with a green circle is labeled "Road Meas".</p> |
| ② Press “Road Meas” or (0) and (8) to select road measurement. Press “” to return to previous menu. |  <p>The display shows the "Road Meas" menu with the time 16:18:12 and battery level 34%. The "Select" option is highlighted. Below it are three menu items: F1 Road Designment (1), F2 Road Meas (2), and F3 Select File (3). At the bottom are function keys F1, F2, and F3.</p> |


6.11.1 Road designment

Enter road designment menu, as follows:


| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① Under Programs mode, press “Road Meas” or (0) and (8) to select road measurement.



- ② Press “F1” or (1) to enter road designment menu from road measurement menu.



6.11.1.1 Define horizontal alignment (100 data at most)

Select [Define H. Line] from [Road designment] to define plane curve. See annex for the calculation of the alignment.


Horizontal alignment comprises the following elements: start point, beeline, arc and curve. The definition options will remind you to input details of the start point (pile number, N (north) and E (east) coordinates) and then enter the main line input process screen.

The start point consists of such elements as pile number and north and east coordinates. With detailed data of start point entered, press “F4” (Detemine) to enter main line input process screen:

| Procedure | Display |
|-----------|---------|
|-----------|---------|




① Press “F1” or (1) to enter road designment menu from road measurement menu.




② Press “F1” or (1) to enter horizontal alignment start point input interface from road designment menu.

The start point consists of these elements: pile number and north and east coordinates.



With detailed data of start point entered, press “F4” (Determine) to enter main line input process screen:

This screen displays the current pile number, tangent bearing at this pile number and function keys to create new line types.






The horizontal alignment system provides four definition functions: beeline, arc, curve and point. Press one of the four function keys, enter details of the pile number and elements of alignment will be generated. Press “F4” (Determine) and the system software will calculate the new pile number and bearing and return to the main alignment screen; then, you can define another line type. New alignment elements can only be added to end portion of the original alignment file.




Beeline

With start point or other line types defined, you can proceed to define beeline. Beeline comprises bearing and distance and the distance shall not be negative.

| Procedure | Display |
|--|--|
| <p>① Press “F1” (BEEL) to enter beeline definition screen from input process screen.</p> <p>② Enter bearing and length of the beeline.</p> |  <p>The screenshot shows the 'Define H. Line-BEEL' screen. At the top, there are icons for a camera, a computer monitor, a globe, and a battery level at 34%. The time is 16:21:34. Below the icons, the title 'Define H. Line-BEEL' is displayed. A 'Routine' field is empty. Underneath, there are two input fields: 'Bearing : 25.3636' and 'Distance : 100'. At the bottom right is a blue 'Determine' button.</p> |
| <p>② Press “F4” (Determine) to save the alignment data.</p> |  <p>The screenshot shows the 'Define H. Line-BEEL' screen again. The 'Bearing' and 'Distance' fields remain the same. A message 'Storing data...7' is displayed in the center. The 'Determine' button is visible at the bottom right.</p> |
| <p>③ With the alignment data stored, it will show pile number at the end of beeline and bearing of the pile. • Then, you can define other arcs and curves. • If the beeline is in the middle of the route, bearing of the beeline will be calculated with aforesaid elements. To change the bearing, you can manually enter a new bearing.</p> |  <p>The screenshot shows the 'Define H. Line' screen. The title 'Define H. Line' is at the top. A 'Routine' field is empty. Below, there are two input fields: 'Pile : 1200' and 'Bearing : 25°36'36''. At the bottom, there are four tabs: BEEL (highlighted in blue), ARC, CUR, and PT.</p> |



Arc



Press the button ARC in main line input process screen and you can define the arc which consists of radius and arc length. Radius is defined as moving direction along the arc. The radius is positive when it turns right and negative when it turns left. The arc length shall not be negative.

| Procedure | Display |
|---|---|
| ① Press “F2” (ARC) in input process screen and you can enter arc definition screen. | <p>【Define H. Line】</p> <p>Pile : 1200 Bearing : 25°36'36"</p> <p>BEEL ARC CUR PT</p> |
| ② Enter radius and arc length. Press “F4” (Determine) to save the data. | <p>【Define H. Line-ARC】</p> <p>Rad : 20 len : 30</p> <p>Determine</p> |




- ③ With the alignment data saved, it will return to the main input screen.

【Define H. Line】

| | |
|-----------|------------|
| Routine | |
| Pile : | 1230 |
| Bearing : | 111°33'13" |

BEEL ARC CUR PT

Curve



Press the button CUR in main line input process screen and you can define the curve which comprises the minimum radius and arc length. The definition of positive and negative radius is the same as the arc. Similarly, its arc length shall not be negative.

| Procedure | Display | | | | | | |
|---|--|---------|--|--------|------|-----------|------------|
| ① Press "F3" (CUR) in input process screen and you can enter curve definition screen. | <p>【Define H. Line】</p> <table border="1"><tr><td>Routine</td><td></td></tr><tr><td>Pile :</td><td>1230</td></tr><tr><td>Bearing :</td><td>111°33'13"</td></tr></table> <p>BEEL ARC CUR PT</p> | Routine | | Pile : | 1230 | Bearing : | 111°33'13" |
| Routine | | | | | | | |
| Pile : | 1230 | | | | | | |
| Bearing : | 111°33'13" | | | | | | |



- ② Enter minimum radius and arc length of the curve.

【Define H. Line-CUR】

| | |
|---------|----|
| Routine | |
| Rad : | 20 |
| len : | 24 |

Determine

- ③ Press ‘F4’ (Determine) to save the data and return to main screen.


If “” is pressed, it will return to main input screen without saving the data.

【Define H. Line】

| | |
|-----------|------------|
| Routine | |
| Pile : | 1254 |
| Bearing : | 145°55'52" |

BEEL | ARC | CUR | PT

Point



Press the button PT in main line input process screen and you can define the point which comprises coordinates, radius as well as A1 and A2 parameters of the curve. The radius, A1 and A2 shall not be negative. If radius is entered, an arc of specified radius will be inserted between current point and next point. If parameters of the curve A1 and A2 are entered, a curve of specified length will be inserted between the beeline and the arc.

| Procedure | Display |
|-----------|---------|
|-----------|---------|



| | | | | | | | | | | | |
|---|--|--------|------|-----------|------------|-------|----|------|---|------|---|
| ① Press “F4” (PT) in input process screen and you can enter point definition screen. | <p>【Define H. Line】</p> <table border="1"><tr><td>Pile :</td><td>1254</td></tr><tr><td>Bearing :</td><td>145°55'52"</td></tr></table> <p>BEEL ARC CUR PT</p> | Pile : | 1254 | Bearing : | 145°55'52" | | | | | | |
| Pile : | 1254 | | | | | | | | | | |
| Bearing : | 145°55'52" | | | | | | | | | | |
| ② Enter N and E coordinates, radius, A1 and A2. | <p>【Define H. Line-PT】</p> <table border="1"><tr><td>N :</td><td>10</td></tr><tr><td>E :</td><td>10</td></tr><tr><td>Rad :</td><td>50</td></tr><tr><td>A1 :</td><td>0</td></tr><tr><td>A2 :</td><td>0</td></tr></table> <p>Determine</p> | N : | 10 | E : | 10 | Rad : | 50 | A1 : | 0 | A2 : | 0 |
| N : | 10 | | | | | | | | | | |
| E : | 10 | | | | | | | | | | |
| Rad : | 50 | | | | | | | | | | |
| A1 : | 0 | | | | | | | | | | |
| A2 : | 0 | | | | | | | | | | |
| ③ Press “F4” (Determine) to save the data and return to main screen. If “↶” is pressed, it will return to main input screen without saving the data. | <p>【Define H. Line】</p> <table border="1"><tr><td>Pile :</td><td>1254</td></tr><tr><td>Bearing :</td><td>145°55'52"</td></tr></table> <p>BEEL ARC CUR PT</p> | Pile : | 1254 | Bearing : | 145°55'52" | | | | | | |
| Pile : | 1254 | | | | | | | | | | |
| Bearing : | 145°55'52" | | | | | | | | | | |




[Note]: When A1 and A2 are entered based on L1 and L2 curve lengths, A1 and A2 shall be calculated with the following formulas:

$$A_1 = \sqrt{L_1 \cdot R} \quad A_2 = \sqrt{L_2 \cdot R}$$

Alignment can only be modified with the alignment editing menu.



6.11.1.2 Edit horizontal alignment

| Procedure | Display |
|---|--|
| ① Under Programs mode, press “Road Meas” or (0) and (8) to select road measurement. |  |
| ② Press ‘F1’ or (1) to enter road designment menu from road measurement menu. |  |
| ③ In road designment menu, press “F2” or (2). |  |

Horizontal alignment editing interface:



FIR: Press this button and the cursor will move to the beginning of the file.

END: Press this button and the cursor will move to the end of the file.



Pre: This button is used to display data of previous point. Press it to show data of previous point.

Next: This button is used to display data of next point. Press it to show data of next point.

6.11.1.3 Define vertical alignment (100 data at most)

In road measurement menu, press “F1” or (1) ([Road Designment]) to enter road designment menu.

In this menu, press “F3” or (3) ([Define V. Line]) to enter vertical alignment definition screen:


| Procedure | Display |
|---|--|
| ① Under Programs mode, press “Road Meas” or (0) and (8) to select road measurement. |  <p>The screenshot shows the "Road Meas" menu. At the top, there are icons for a camera, a barcode, and a gear. The time is 16:18:12. On the right, there are buttons for "345" and "Star". Below the icons is a blue bar with the text "[Road Meas]" and a back arrow icon. A "Select" button is highlighted. The menu items are: F1 Road Designment (1), F2 Road Meas (2), and F3 Select File (3). At the bottom is a blue footer bar with buttons F1, F2, F3, and F4.</p> |
| ② Press “F1” or (1) to enter road designment menu from road measurement menu. |  <p>The screenshot shows the "Road Designment" menu. At the top, there are icons for a camera, a barcode, and a gear. The time is 16:19:08. On the right, there are buttons for "345" and "Star". Below the icons is a blue bar with the text "[Road Designment]" and a back arrow icon. A "Select" button is highlighted. The menu items are: F1 Define H.Line (1), F2 Edit H.Line (2), F3 Define V.Line (3), and F4 Edit V.Line (4). At the bottom is a blue footer bar with buttons F1, F2, F3, and F4.</p> |



③ In road design menu, press “F3” or (3) to enter vertical alignment definition screen.

The screenshot shows a software interface titled "Define V. Line". At the top, there are several icons: a compass, a computer monitor, a globe, and a battery. The time "16:27:18" and a file number "345" are also displayed. Below the title, there is a "Routine" field. Under "Pile", the value "1100" is entered. Under "VD", the value "20" is entered. Under "Len", the value "30" is entered. At the bottom right of the screen is a blue button labeled "Determine".

Vertical alignment comprises a group of intersection points which comprise pile number, elevation and curve length. The curve lengths of start point and end point of vertical alignment must be zero.



| | | | | |
|-------------|------|------|------|------|
| Pile number | 1000 | 1300 | 1800 | 2300 |
| Elevation | 50 | 70 | 60 | 90 |
| Length | 0 | 300 | 300 | 0 |

The intersection points can be entered into the vertical alignment screen in any order. When data of a point is entered, press “F4” (Determine) to save data of the point and enter input screen for the next point, or press “” to withdraw from the vertical alignment screen without saving the data.


6.11.1.4 Edit vertical alignment

In road measurement menu, press “F1” or (1) ([Road Designment]) to enter road designment menu. Then press “F4” or (4) ([Edit V. Line]) to enter vertical alignment editing screen:


| Procedure | Display |
|-----------|---------|
|-----------|---------|




- ① Under Programs mode, press “Road Meas” or (0) and (8) to select road measurement.



- ② Press “F1” or (1) to enter road designment menu from road measurement menu.



- ③ Press “F4” or (4) in road designment menu to enter vertical alignment editing screen.



The alignment data can be processed with this menu and the operations are the same as that for editing horizontal alignment data. See “6.11.1.2 Edit horizontal alignment”.

6.11.2 Road layout



Select [Road Mea] from road measurement menu:

For the purpose of road layout, line type must be defined first. Method for definition of horizontal alignment: manually enter the data in [Road Designment] process. The definition of vertical horizontal data is optional, but it is mandatory if fill or cut is required. The method is the same as that for horizontal alignment.

Requirements for road layout data are as follows:

Offset:


Left: horizontal distance between left pile and center line; right: horizontal distance between right pile and center line

Elevation difference:

Left/right: elevation difference between left/right pile and center line point


6.11.2.1 Road layout menu

You can enter the road layout menu by following the procedure below:


| Procedure | Display |
|---|---|
| ① Under Programs mode, press “Road” to reveal page 3 of Programs interface. Press “” to return to previous menu. |  |



- ② Press “Road Meas” or (0) and (8) to select road measurement.



- ③ In road measurement menu, press “F2” or (2) to enter road layout menu.




6.11.2.2 Station setup for road layout

The station for road layout can be set by following the procedure below:

| Procedure | Display |
|-----------|---------|
|-----------|---------|



① In road measurement menu, press “F2” or (2) to enter road layout menu.





② To set station coordinates and azimuth, press “F2” or (2) to enter station setup interface.

Press “F3” (Pile) to search for station coordinates based on pile number.

Press “F1” (FIR) to display data of the first pile.

Press “F2” (END) to display data of the last pile.

Press “F4” (Determine) to set the pile as the station and return to station setup interface.





③ Press “F4” (BS) in station setup interface to enter backsight point setting interface. Press “F3” (Pile) to search for backsight point coordinates based on pile number.

Press “F1” (FIR) to display data of the first pile.

Press “F2” (END) to display data of the last pile.

Press “F4” (Detemine) to set the pile as the station and return to backsight point setting interface.

【Set Backsight point】

| | |
|-----|---------|
| N : | 5.111 m |
| E : | 0.349 m |
| Z : | 1.738 m |

Angle | Pile | Azimuth

Sear.

| | |
|--------|------------|
| Pile : | 1120.000 m |
| N : | 1118.035 m |
| E : | 1058.645 m |

FIR | END | Detemine


④ Press “F4” (Azimuth) in backsight point setting interface to enter azimuth setting interface. To set the azimuth, press “F4” (Detemine).

【Set the azimuth】

| | |
|----------------------------|----------|
| Data | |
| Sighting target set up no? | |
| Ho : | 0°00'00" |
| HR : | 0°00'00" |


Back | Detemine



| | |
|--|--|
| ⑤ With azimuth set, press “F4” (Determine) to return to road layout interface. |  |
|--|--|

6.11.2.3 Road curve layout

The station for road layout can be set by following the procedure below:

| Procedure | Display |
|--|---|
| ① In road measurement menu, press “F2” or (2) to enter road layout menu. |  |



② In road layout menu, press “F4” or (4) to enter start point setting interface.

The screenshot shows the 'Set Point 1' interface. At the top, there are icons for signal strength, battery level, and a warning. The time is 11:11:22. Below the title '【Set Point 1】' are several input fields:

| | |
|------------|------------|
| ST.Pile : | 1100.000 m |
| Inc.Pile : | 20.000 m |
| L.Offset : | 10.000 m |
| R.Offset : | 20.000 m |
| L.dZ : | 30.000 m |
| R.dZ : | 40.000 m |

At the bottom right is a blue button labeled 'Determine'.

③ Enter start point pile number and pile increment and then press “F4” (Determine). Enter road layout setting interface.

Left offset (“F1” (LOff)): button used for staking left side pile;

Right offset (“F1” (ROff)): button used for staking right side pile;

Add pile (“F1” (AddP)): button used to increase pile number (the increased value equals current pile number plus pile increment);

Decrease pile (“F2” (DecP)): button used to decrease pile number (the decreased value equals current pile number minus pile increment)

Prism height: prism height at the pile position

The screenshot shows the 'Road Meas' interface. At the top, there are icons for signal strength, battery level, and a warning. The time is 11:13:03. Below the title '【Road Meas】' are several input fields:

| | |
|-------------|------------|
| Pile : | 1100.000 m |
| Deviation : | 0.000 m |
| dZ : | 0.000 m |
| Pri.HT : | 0.000 m |

At the bottom are three buttons: 'AddP', 'DecP', and 'Determine'.




④ With pile number, offset and height difference of layout point set, press “F3” (Determine) to enter road layout interface.

Press “F1” (Meas) to measure distance offset and height offset of layout point.

Press “F2” (EDM) to select EDM setting.

Press “F3” (Comm) to show distance offset and height offset of measuring point and layout point.

Press “F4” (Coor.) to show coordinates of measuring point.



6.11.3 Road file


Enter road file interface, as follows:

| Procedure | Display |
|-----------|---------|
|-----------|---------|




① Under Programs mode, press “Road Meas” or (0) and (8) to select road measurement.

Press “” and you can return to previous menu.



② Press “F3” or (3) in road measurement menu to enter road file interface and the status of each file will be displayed (file name, extension and creation date).

Press “” and you can return to previous menu.




6.11.3.1 Save road file as


| Procedure | Display |
|-----------|---------|
|-----------|---------|




① In Road measurement menu, press “F3” or (3) to enter road file interface.




② Select a file by clicking it and press “F1” (Save) to enter road file save interface. The current file name will be displayed. Enter the file name (7 characters at most) to be saved and select the save type.




③ Press “F4” (Determine) to save the file as the new file.





| |  |
|---|--|
| The file is saved in the folder Mounted_Volume\fdp2\output. | |


6.11.3.2 Create new road file

| Procedure | Display |
|---|---|
| ① In Road measurement menu, press “F3” or (3) to enter road file interface. |  |




② In road file interface, press “F2” (New) to enter new file interface.


Enter name of the new file (7 characters at most).



③ To save the new file, press “F4” (Determine).





④ Press “F4” (Cont) to return to road file interface.






6.11.3.3 Delete road file

When the file is deleted, another road file shall be selected before conducting road measurement.

| Procedure | Display |
|--|---|
| ① In Road measurement menu, press “F3” or (3) to enter road file interface. |  |
| ② Select a file by clicking it and then press “F3” (Del) to enter road file deletion prompt interface. |  |



③ To delete the file, press “F4” (Yes). When the file is deleted, another road file shall be selected before conducting road measurement.



6.11.3.4 Rename road file

| Procedure | Display |
|-----------|---------|
|-----------|---------|



- ① In Road measurement menu, press “F3” or (3) to enter road file interface.

The screenshot shows a software interface titled "Road Meas-Select a job". At the top, there are icons for a compass, a barcode, a globe, and a battery level at 34%. The time is 10:04:09. Below the title is a table with three columns: "File", "Creat Time", and "Type". The table contains three rows of data:

| File | Creat Time | Type |
|------|--------------------|------|
| temp | 2016/3/10 16:49:45 | hal |
| 232 | 2016/3/24 10:02:57 | hal |
| 121 | 2016/3/24 10:03:49 | hal |


Below the table, a box labeled "Current Mission" shows "232.hal". At the bottom are two rows of buttons: "Save", "New", "Del", "↓", "Rename", "See", and "←".

- ② Select a file by clicking it and then press “F1” (Rename) to enter road file rename interface.

The screenshot shows a software interface titled "File Rename". At the top, there are icons for a compass, a barcode, a globe, and a battery level at 34%. The time is 10:16:15. Below the title, there is a "Routine" field containing "232". A "Current Mission" field shows "232". Below that, a "New Mission" field has "111" entered. At the bottom are two rows of buttons: "Back" and "Determine".

- ③ Press “F4” (Yes) to confirm to rename the file.

The screenshot shows a software interface titled "Message". The background is yellow. The text "FileRenameSuccessed" is displayed in black. At the bottom, there is a row of four blue buttons.



6.11.3.5 View road file

| Procedure | Display | | | | | | | | | | | | |
|---|--|------|-------------|------|------|--------------------|-----|-----|--------------------|-----|-----|--------------------|-----|
| ① In Road measurement menu, press "F3" or (3) to enter road file interface. | <p>The screenshot shows the same software interface as the previous one, but with a different set of files listed in the table:</p> <table border="1"><thead><tr><th>File</th><th>Create Time</th><th>Type</th></tr></thead><tbody><tr><td>temp</td><td>2016/3/10 16:49:45</td><td>hal</td></tr><tr><td>232</td><td>2016/3/24 10:02:57</td><td>hal</td></tr><tr><td>121</td><td>2016/3/24 10:03:49</td><td>hal</td></tr></tbody></table> <p>Below the table, a message "Current Mission : 232.hal" is shown. At the bottom, there are four buttons: "Save", "New", "Del", and a downward arrow button. Additionally, there are two more buttons: "Rename" and "See".</p> | File | Create Time | Type | temp | 2016/3/10 16:49:45 | hal | 232 | 2016/3/24 10:02:57 | hal | 121 | 2016/3/24 10:03:49 | hal |
| File | Create Time | Type | | | | | | | | | | | |
| temp | 2016/3/10 16:49:45 | hal | | | | | | | | | | | |
| 232 | 2016/3/24 10:02:57 | hal | | | | | | | | | | | |
| 121 | 2016/3/24 10:03:49 | hal | | | | | | | | | | | |



- ② Select a file by clicking it and then press “F2” (See) to enter road file viewing interface.

| File | N | E | Z | Dir. Angle |
|------|------------|------------|--------|------------|
| 1100 | 1100. 0... | 1050. 0... | 0.0000 | 0. 4469... |
| 1120 | 1118. 0... | 1058. 6... | 0.0000 | 0. 4469... |
| 1140 | 1136. 0... | 1067. 2... | 0.0000 | 0. 4469... |
| 1160 | 1154. 1... | 1075. 9... | 0.0000 | 0. 4469... |
| 1180 | 1172. 1... | 1084. 5... | 0.0000 | 0. 4469... |

Save | Modify | Del | Emptv

- ③ To save the file in road file viewing interface, press “F1” (Save).

Press “F4” (Determine) to confirm to save the file.

Routine

Current Mission : temp

File : temp

Save Type : DADI NEZ(*.dad)

Back | Determine

【Message】

FileSave!



- ④ To modify the data in the road file viewing interface, first select a row data by clicking it.

Then, press “F2” (Modify) to modify the row data.

To save the modified data, press “F4” (Determine).

| File | N | E | Z | ir. Angle |
|------|-----------|-----------|--------|-----------|
| 1100 | 1100.0... | 1050.0... | 0.0000 | 0.4469... |
| 1120 | 1118.0... | 1058.6... | 0.0000 | 0.4469... |
| 1140 | 1136.0... | 1067.2... | 0.0000 | 0.4469... |
| 1160 | 1154.1... | 1075.9... | 0.0000 | 0.4469... |
| 1180 | 1172.1... | 1084.5... | 0.0000 | 0.4469... |

| | |
|---------|-----------|
| Routine | |
| Pile | 1120 |
| PtID : | |
| N : | 1118.0351 |
| E : | 1058.6449 |
| Z : | 0.0000 |

- ⑤ To delete the data in the road file viewing interface, first select the row data by clicking it.

Then, press “F3” (Del).

| File | N | E | Z | ir. Angle |
|------|-----------|-----------|--------|-----------|
| 1100 | 1100.0... | 1050.0... | 0.0000 | 0.4469... |
| 1120 | 1118.0... | 1058.6... | 0.0000 | 0.4469... |
| 1140 | 1136.0... | 1067.2... | 0.0000 | 0.4469... |
| 1160 | 1154.1... | 1075.9... | 0.0000 | 0.4469... |
| 1180 | 1172.1... | 1084.5... | 0.0000 | 0.4469... |



Press “F4” (Yes) to confirm to delete the data.

Sure you want to delete the dat
Data is unrecoverable!

No | Yes

The screenshot shows a software interface with a red header bar containing icons for a monitor, keyboard, globe, and battery, followed by the time "10:23:16" and a "34s" button. A red box highlights the text "【Warning】". Below the header is a blue message box with the text "Sure you want to delete the dat" and "Data is unrecoverable!". At the bottom of the message box is a horizontal button bar with "No" and "Yes" options. The main area contains a table titled "Select a job-SeeData" with columns: File, N, E, Z, Dir. Angle. The table lists five rows of data:


| File | N | E | Z | Dir. Angle |
|------|-----------|-----------|--------|------------|
| 1120 | 1118.0... | 1058.6... | 0.0000 | 0.4469... |
| 1140 | 1136.0... | 1067.2... | 0.0000 | 0.4469... |
| 1160 | 1154.1... | 1075.9... | 0.0000 | 0.4469... |
| 1180 | 1172.1... | 1084.5... | 0.0000 | 0.4469... |
| 1200 | 1190.1... | 1093.2... | 0.0000 | 0.4469... |

At the bottom of the table is a blue button bar with "Save", "Modify", "Del", and "Empty" buttons.

⑥ To empty data in the road file viewing interface, press “F4” (Empty).

The screenshot shows a software interface with a blue header bar containing icons for a monitor, keyboard, globe, and battery, followed by the time "10:23:05" and a "34s" button. A blue box highlights the text "【Select a job-SeeData】". Below the header is a blue message box with the text "Select a job-SeeData". The main area contains a table with columns: File, N, E, Z, Dir. Angle. The table lists five rows of data. The "Z" column for the first row is highlighted with a dotted blue border. At the bottom of the table is a blue button bar with "Save", "Modify", "Del", and "Empty" buttons.

| File | N | E | Z | Dir. Angle |
|------|-----------|-----------|--------|------------|
| 1100 | 1100.0... | 1050.0... | 0.0000 | 0.4469... |
| 1120 | 1118.0... | 1058.6... | 0.0000 | 0.4469... |
| 1140 | 1136.0... | 1067.2... | 0.0000 | 0.4469... |
| 1160 | 1154.1... | 1075.9... | 0.0000 | 0.4469... |
| 1180 | 1172.1... | 1084.5... | 0.0000 | 0.4469... |



6.12 Area measurement mode


6.12.1 Calculate area with coordinate data file

| Procedure | Display |
|-----------|---------|
|-----------|---------|



① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface.

Press “” to return to previous menu.




② Press “Area Meas” or (9) to enter area measurement configuration interface.


Press “F1” or (1) to enter job setting interface.

Press “F2” or (2) to enter station setup interface.

Press “” to return to previous menu.



③ Press “F4” or (4) to enter area measurement selection interface.





- ④ Press ‘F1’ or (1) to enter the first point setting interface for area measurement.

Press “F3” (Job) and you can select the job to which the coordinates belongs.

The top part of the image shows the 'Area Meas-File Data' screen. It has fields for 'Area(m.sq)' (0.000), 'Points' (0), and 'N', 'E', 'Z' coordinates. Below this is a table with columns 'Add PT', 'Coor.', 'Job', and a dropdown arrow. The bottom part shows a 'Select a job' dialog with a table for 'Job name', 'Type', and 'Dates'. The table contains one row for 'DEFAULT' (Type: raw, Dates: 2016/3/10 13:57:31). A 'Cont' button is at the bottom right.

- ⑤ Press ‘F2’ (Coor.) to search for the coordinates and press “F4” (Determine) to select the coordinates.


The image shows the 'Data Query' screen. It has a 'Data' search field and a table with columns 'PtID', 'Code', 'N', 'E', and 'Z'. The table rows show values: PtID : 1, Code : 1, N : 1.000 m, E : 2.000 m, Z : 3.000 m. At the bottom are buttons for 'FIR', 'END', and 'Determine'.



| | | | | | | | | | | | | | |
|--|--|---------|--|------------|--------|--------|---|---|-------|---|-------|---|-------|
| | <p>15:45:20 345</p> <p>[Area Meas-File Data]</p> <table border="1"><tr><td>Routine</td><td></td></tr><tr><td>Area(m.sq)</td><td>0.000</td></tr><tr><td>Points</td><td>0</td></tr><tr><td>N</td><td>1.000</td></tr><tr><td>E</td><td>2.000</td></tr><tr><td>Z</td><td>3.000</td></tr></table> <p>Add PT Coor. Job</p> | Routine | | Area(m.sq) | 0.000 | Points | 0 | N | 1.000 | E | 2.000 | Z | 3.000 |
| Routine | | | | | | | | | | | | | |
| Area(m.sq) | 0.000 | | | | | | | | | | | | |
| Points | 0 | | | | | | | | | | | | |
| N | 1.000 | | | | | | | | | | | | |
| E | 2.000 | | | | | | | | | | | | |
| Z | 3.000 | | | | | | | | | | | | |
| ⑥ Press “F1” (Add PT) to add a point and continue to set coordinates of the second point. | <p>15:45:38 345</p> <p>[Area Meas-File Data]</p> <table border="1"><tr><td>Routine</td><td></td></tr><tr><td>Area(m.sq)</td><td>0.000</td></tr><tr><td>Points</td><td>1</td></tr><tr><td>N</td><td>0</td></tr><tr><td>E</td><td>0</td></tr><tr><td>Z</td><td>0</td></tr></table> <p>Add PT Coor. Job</p> | Routine | | Area(m.sq) | 0.000 | Points | 1 | N | 0 | E | 0 | Z | 0 |
| Routine | | | | | | | | | | | | | |
| Area(m.sq) | 0.000 | | | | | | | | | | | | |
| Points | 1 | | | | | | | | | | | | |
| N | 0 | | | | | | | | | | | | |
| E | 0 | | | | | | | | | | | | |
| Z | 0 | | | | | | | | | | | | |
| ⑦ Repeat steps ⑤~⑥ to add more points. When the number of points is ≥ 3 , the area of the graphic formed by all points will be automatically calculated. Example: Area of the graphic formed by the 4 points and the diagrammatic sketch are displayed. | <p>15:51:26 345</p> <p>[Area Meas-File Data]</p> <table border="1"><tr><td>Routine</td><td></td></tr><tr><td>Area(m.sq)</td><td>49.000</td></tr><tr><td>Points</td><td>4</td></tr><tr><td>N</td><td>0</td></tr><tr><td>E</td><td>0</td></tr><tr><td>Z</td><td>0</td></tr></table> <p>Add PT Coor. Job</p> <p>A diagrammatic sketch of a quadrilateral is shown on the right side of the screen.</p> | Routine | | Area(m.sq) | 49.000 | Points | 4 | N | 0 | E | 0 | Z | 0 |
| Routine | | | | | | | | | | | | | |
| Area(m.sq) | 49.000 | | | | | | | | | | | | |
| Points | 4 | | | | | | | | | | | | |
| N | 0 | | | | | | | | | | | | |
| E | 0 | | | | | | | | | | | | |
| Z | 0 | | | | | | | | | | | | |



- ⑧ Press “F1” (Dec PT) to remove the last point and the area of the graphic formed by the three points will be automatically calculated and the diagrammatic sketch displayed.



6.12.2 Calculate area with measurement data

| Procedure | Display |
|---|--|
| <p>① Under Programs mode, press “Meas+” to reveal page 2 of Programs interface. Press “ ” to return to previous menu. ↺</p> | <p>The screenshot shows the 'Programs' screen. At the top right, the time is 16:17:17 and there are battery and signal indicators. Below the title bar, there are three tabs: 'Meas' (selected), 'Meas+', and 'Road'. In the center, there are six icons arranged in two rows of three: 7 MLM, 8 Line Meas, 9 Area Meas, 01 REM, and 02 Offset Meas. The 'Meas+' tab is highlighted in blue.</p> |




② Press “Area Meas” or (9) to enter area measurement configuration interface.

Press “F1” or (1) to enter job setting interface.

Press “F2” or (2) to enter station setup interface.


Press “” to return to previous menu.



The screenshot shows the "Area Meas" menu interface. At the top, there are icons for a receiver, a computer, a globe, and a warning sign, followed by the time "15:40:53" and a battery indicator showing "34s". Below the header, the title "[Area Meas]" is displayed in a blue bar. A "Con." input field is present. The main menu items are listed in a grid:

| | | |
|------------------------|-----|----|
| [•] F1 Set Job | (1) | |
| [•] F2 Station Setup | (2) | |
| F4 Start | | |
| F1 | F2 | F4 |

③ Press “F4” or (4) to enter area measurement selection interface.




The screenshot shows the "Area Meas" selection menu. The top section is identical to the previous one. The main menu items are:

| | | | |
|--------------|-----|--|--|
| F1 File Data | (1) | | |
| F2 Meas Data | (2) | | |
| F1 | F2 | | |

④ Press “F1” or (1) to enter the first point setting interface for area measurement.

Press “F1” (Station) to enter station setup interface.

Press “F1” (EDM) to enter EDM setting interface.



The screenshot shows the "Area Meas-Meas Data" interface. The top section is identical to the previous ones. The main data entry fields are:

| | |
|------------|-------|
| Area(m.sq) | 0.000 |
| Points | 0 |
| N | |
| E | |
| Z | |

Below the data fields is a control panel with three rows of buttons:

| | | | |
|---------|----------|--------|---|
| Meas | Add PT | Dec PT | ↓ |
| EDM | Pri. HT | Unit | ↓ |
| Station | New Area | | ← |



- ⑤ Press “F1” (Meas) to enter first point coordinate measurement interface.

16:03:29 345 ⚡ ↻

【Area Meas-Meas Data】

| | |
|------------|-------|
| Routine | |
| Area(m.sq) | 0.000 |
| Points | 0 |
| N | 1.213 |
| E | 3.845 |
| Z | 2.430 |

Meas Add PT Dec PT ↓

- ⑥ Press “F2” (Add PT) to add a point and enter the second point measurement interface.

16:07:12 345 ⚡ ↻

【Area Meas-Meas Data】

| | |
|------------|-------|
| Routine | |
| Area(m.sq) | 0.000 |
| Points | 1 |
| N | 0 |
| E | 0 |
| Z | 0 |

Meas Add PT Dec PT ↓

- ⑦ Repeat steps ⑤~⑥ to add more points. When the number of points is ≥ 3 , the area of the graphic formed by all points will be automatically calculated.

Example:

Area of the graphic formed by the 4 points and the diagrammatic sketch are displayed.

15:58:17 345 ⚡ ↻


【Area Meas-Meas Data】

| | |
|------------|--------|
| Routine | |
| Area(m.sq) | 49.000 |
| Points | 4 |
| N | 0 |
| E | 0 |
| Z | 0 |

EDM Pri. HT Unit ↓



⑧ Press “F1” (Dec PT) to remove the last point and the area of the graphic formed by the three points will be automatically calculated and the diagrammatic sketch displayed.



6.12.3 Conversion of display unit

| Procedure | Display |
|--|---|
| <p>① Press the button Unit to enter area measurement unit selection interface.</p> <p>Select a proper unit. For example, to choose “acre”, change m.sq into acre.</p> <p>② Press “F4” (Detemine) to save the modification and return to previous menu. Press “F1” (Back) to return to previous menu without saving the modification.</p> | <p>The figure shows a handheld device's display. At the top, there are icons for signal strength, battery level (34%), and other system status. The time is 15:42:30. Below the status bar, the title "【Area Meas】" is displayed. Underneath the title, there is a "Set" input field. Below the input field, there is an "Area unit" entry field with the value "m.sq". At the bottom of the screen, there are two buttons: "Back" and "Determine".</p> |

6.12.4 New area

| Procedure | Display |
|-----------|---------|
|-----------|---------|




① Press “F2” (New Area) to recalculate the area.

The screenshot shows the 'Area Meas-File Data' screen. At the top, there are icons for a receiver, keyboard, globe, battery level (34%), and signal strength. The time is 15:41:58. Below the title bar, there's a 'Routine' field and a large yellow rectangular area. On the left side, there are input fields for 'Area(m.sq)' (0.000), 'Points' (0), and coordinates N, E, Z. At the bottom, there are buttons for 'Add PT', 'Coor.', 'Job', 'Dec PT', 'New Area', 'Unit', and navigation arrows.


7 Manage mode

Press [3] or click the button “Manage”.



This mode covers the following items:

1. Job
2. Fixpoints
3. Measurement data
4. Code
5. Memory initialization



7.1 Job

This function can manage deletion, addition and creation of jobs.

The various measurement data, such as fixpoints and measuring points, are all stored in the selected job.

Definition of a job comprises the job name and operator.

| Procedure | Display |
|---|---------|
| ① Under Manage mode, press "Job" or "1" to enter job setting interface. Press "↶" to return to previous menu. | |

Description of file formats in the memory is as follows:

*****.dat system file

*****.RAW raw data file




*****.HAL horizontal alignment data file

*****.VCL vertical alignment data file




7.1.1 Job deletion

This function is used to delete jobs in the memory. A protected file cannot be deleted, unless the protection is eliminated. Only one file can be deleted at one time.



| Procedure | Display |
|---|--|
| ① Enter job setting interface. ② Press “◀ ▶” to select a job. |  <p>【See/new/delete job】</p> <p>Routine</p> <p>Job : 1</p> <p>Operator : q</p> <p>Remark1:</p> <p>Remark2:</p> <p>Date : 15.3.2016</p> <p>Time : 8:23:43</p> <p>Del New Cont</p> |
| ③ Press “F1” (Del) to enter deletion interface. |  <p>【Warning】</p> <p>Are you want to delete the data(j) Data is unrecoverable!</p> |
| ④ Press “F4” (Yes) to delete the job. Press “F1” (No) to return to previous menu without deleting it. |  <p>【Message】</p> <p>Delete the job successfully!</p> |





| | |
|--|--|
| |  |
|--|--|

7.1.2 New job

This function is used to create new job and only one job can be created at one time.


| Procedure | Display |
|---|--|
| ① Enter job setting interface. |  |
| ② Press “F4” (Cont) to enter job creation interface. It will display items to be entered (job name, operator, remark 1 and remark 2). |  |



| | |
|---|--|
| <p>③ With all items entered, press “F4” to generate a new job, or press “F1” (Back) to return to previous menu without saving it.</p> |  <p>The new job was saved successfully</p> |
| <p>④ Press “F4” (Cont) return.</p> |  <p>Routine</p> <p>Job : DEFAULT</p> <p>Operator :</p> <p>Remark1:</p> <p>Remark2:</p> <p>Date : 2016/3/10</p> <p>Time : 13:57:31</p> <p>Cont</p> <p>New</p> <p>Del</p> |

7.2 Fixpoints

Search, editing, deletion and other operations of fixpoints of a job in the memory can be achieved with this function. Valid fixpoints comprises at least the point name and coordinates (X, Y) or height (Z).



| Procedure | Display |
|--|---------|
| <p>① Under Manage mode, press “Fixpoints” or “2” to enter fixpoint setting interface.</p> <p>Press “” and you can return to previous menu.</p> <p>②   e buttons “ <p>Data</p><p>Job : DEFAULT</p><p>PtID : 1</p><p>X : 1.000 m</p><p>Y : 1.000 m</p><p>Z : 3.000 m</p><p>Find</p><p>Del</p><p>New</p><p>Modify</p></p> | |



“

7.2.1 Fixpoint query

Enter the point name or wildcard “*” to find fixpoint(s) in the selected job.

| Procedure | Display |
|--|---|
| ① Enter the fixpoint setting interface. Press the buttons “  | |
| ② Press “F1” (Find) to enter fixpoint query interface. |  |



③ Enter the fixpoint name or the wildcard “*” and press “F4” (Find).

④ The search results will be displayed.

If you are searching for a certain fixpoint, coordinates of the point will be displayed.

If wildcard “*” is entered, you can view all fixpoints one by one with the buttons “◀▶”.

The screenshot shows the "Fixpoints" interface with the following data:

| Data | |
|--------|---------|
| Job : | DEFAULT |
| PtID : | 2 |
| X : | 4.000 m |
| Y : | 5.000 m |
| Z : | 6.000 m |

Buttons at the bottom: Find, Del, New, Modify.

7.2.2 New fixpoint

This function allows the creation of new fixpoints in a job.

| Procedure | Display | | | | | | | | | | | | |
|---|---|------|--|-------|---------|--------|---|-----|---------|-----|---------|-----|---------|
| ① Enter the fixpoint setting interface. Press the buttons “◀▶” following “Job” to select a job. | <p>The screenshot shows the "Fixpoints" interface with the following data:</p> <table border="1"><thead><tr><th colspan="2">Data</th></tr></thead><tbody><tr><td>Job :</td><td>DEFAULT</td></tr><tr><td>PtID :</td><td>1</td></tr><tr><td>X :</td><td>1.000 m</td></tr><tr><td>Y :</td><td>1.000 m</td></tr><tr><td>Z :</td><td>3.000 m</td></tr></tbody></table> <p>Buttons at the bottom: Find, Del, New, Modify.</p> | Data | | Job : | DEFAULT | PtID : | 1 | X : | 1.000 m | Y : | 1.000 m | Z : | 3.000 m |
| Data | | | | | | | | | | | | | |
| Job : | DEFAULT | | | | | | | | | | | | |
| PtID : | 1 | | | | | | | | | | | | |
| X : | 1.000 m | | | | | | | | | | | | |
| Y : | 1.000 m | | | | | | | | | | | | |
| Z : | 3.000 m | | | | | | | | | | | | |



② Press “F3” (New) to enter new fixpoint interface.

To return to previous menu, press “F1” (Back).

【Input a new fixpoint】

| | |
|--------|---------|
| Data | |
| Job : | DEFAULT |
| PtID : | 6 |
| X : | 1 m |
| Y : | 5 m |
| Z : | 6 m |

Back Cont

③ Enter point name and coordinates of the new fixpoint and then press “F4” (Cont) to complete the addition of the new fixpoint and save it behind existing fixpoints in the job.

④ Press “F4” (Cont) to enter new fixpoint interface.

This point was saved successfull


【Input a new fixpoint】

| | |
|--------|---------|
| Data | |
| Job : | DEFAULT |
| PtID : | |
| X : | m |
| Y : | m |
| Z : | m |

Back Cont



⑤ If there is already a fixpoint of the entered name, a prompt box will pop up. Please enter a new point name and save it.



7.2.3 Fixpoint modification

This function allows editing of fixpoints in a job.

| Procedure | Display |
|---|---------|
| <p>① Enter the fixpoint setting interface. Press the buttons “◀ ▶” following “Job” to select a job. Press the buttons “◀ ▶” following “PtID” to select the fixpoint to be modified.</p> | |
| <p>② Press “F4” (Modify) to enter fixpoint modification interface. To return to previous menu, press “F1” (Back).</p> | |



| | | | | | | | | | | | | | |
|--|---|------|--|-------|---------|--------|---|-----|---------|-----|---------|-----|---------|
| <p>③ Enter the fixpoint name and coordinates. Then, press “F4” (Cont) to modify the fixpoint. Press “F1” (No) to return to previous menu without modifying it.</p> | A screenshot of a software interface showing a message dialog. The title bar says "【Message】". The message text reads: "The point already exists! Sure you want to overwrite any data change?". Below the message are two buttons: "No" and "Yes". | | | | | | | | | | | | |
| <p>④ Press “F4” (Yes) to confirm to modify the fixpoint.</p> | A screenshot of a software interface showing a message dialog. The title bar says "【Message】". The message text reads: "Point update success!". A screenshot of a software interface titled "【Fixpoints】". It shows a table of data fields: <table border="1"><tr><td>Data</td><td></td></tr><tr><td>Job :</td><td>DEFAULT</td></tr><tr><td>PtID :</td><td>1</td></tr><tr><td>X :</td><td>5.000 m</td></tr><tr><td>Y :</td><td>6.000 m</td></tr><tr><td>Z :</td><td>8.000 m</td></tr></table> <p>Below the table are four buttons: "Find", "Del", "New", and "Modify".</p> | Data | | Job : | DEFAULT | PtID : | 1 | X : | 5.000 m | Y : | 6.000 m | Z : | 8.000 m |
| Data | | | | | | | | | | | | | |
| Job : | DEFAULT | | | | | | | | | | | | |
| PtID : | 1 | | | | | | | | | | | | |
| X : | 5.000 m | | | | | | | | | | | | |
| Y : | 6.000 m | | | | | | | | | | | | |
| Z : | 8.000 m | | | | | | | | | | | | |

7.2.4 Fixpoint deletion

This function allows the deletion of fixpoints in a job.

| Procedure | Display |
|-----------|---------|
| | |




| | |
|---|---|
| <p>① Enter the fixpoint setting interface. Press the buttons “ ” following “Job” to select a job. Press the button “ ” following “PtID” to choose the fixpoint to be deleted.</p> | <p>13:42:23 345 [Fixpoints] Data Job : DEFAULT PtID : 1 X : 5.000 m Y : 6.000 m Z : 8.000 m Find Del New Modify</p> |
| <p>② Press “F2” (Del) to enter fixpoint deletion interface.</p> | <p>13:42:44 345 [Warning] you want to delete the data(Fixp Data is unrecoverable!)</p> |
| <p>③ Press “F4” (Yes) to confirm to delete the fixpoint and return to previous menu. Or press “F1” (No) to return to previous menu without deleting the fixpoint.</p> | <p>13:43:09 345 [Fixpoints] Data Job : DEFAULT PtID : 2 X : 4.000 m Y : 5.000 m Z : 6.000 m Find Del New Modify</p> |

7.3 Meas. Data

The measurement data in the memory can be searched and displayed.


| Procedure | Display |
|-----------|---------|
| | |



| | |
|---|--|
| <p>① Under Manage mode, press “Meas. Data” or “3” to enter measuring point setting interface.</p> <p>Press “” and you can return to previous menu.</p> <p>Press the buttons “” following “Job” to select a job.</p> <p>Enter the station name in the field following “Station”.</p> |  |
|---|--|

7.3.1 Measuring point query


This function allows search for specific measuring points in a job.

| Procedure | Display |
|--|---|
| <p>① Enter measuring point setting interface.</p> <p>All query conditions are station based. Hence, the station name entered here can either be a specific one or a wildcard “*”. The system default is wildcard “*”, namely, all stations.</p> <p>※1)</p> |  |




| | |
|---|--|
| <p>② Press “F3” (Find) to enter measuring point query interface. The station name entered here can either be a specific one or a wildcard “*”. The system default is wildcard “*”, namely, all stations.</p> | |
| <p>③ Display search results. Press “F2” to search for measuring point(s) in a job.</p> <p>A:</p> <p>If points consistent with the query conditions are found, they will be displayed on the screen in the order of storage in the memory. Press “◀▶” to view the points one by one.</p> <p>B:</p> <p>If no point consistent with the query conditions is found, a prompt will pop up and then it will automatically return to measuring point viewing interface.</p> <p>④ Press “F4” (Search) to measuring point query interface.</p> | <p>PtID : 12</p> <p>Station :</p> <p>Ins.HT : 0</p> <p>X : 3.000</p> <p>Y : 4.000</p> <p>Z : 5.000</p> <p>No search to point data!</p> |



| | |
|---|--|
| |  |
| <p>※1) Since the station name and point name can both be either specific or a wildcard “*”, the search results of the various combinations will be explained here. All search results are based on the selected job name:</p> <p>Station name (specific) + point name (specific): the search results show all measurement data named after this point name on the specific station.</p> <p>Station name (*) + point name (specific): the search results show all measurement data named after this point name on all stations of the job.</p> <p>Station name (specific) + point name (*): the search results show all measuring points on the specific station.</p> <p>Station name (*) + point name (*): the search results show all measurement data in the job.</p> | |

7.3.2 Measuring point viewing

This function allows searching for measuring points in a job.

| Procedure | Display |
|--|--|
| <p>① Enter measuring point setting interface.</p> <p>All query conditions are station based. Hence, the station name entered here can either be a specific one or a wildcard “*”. The system default is wildcard “*”, namely, all stations.</p> <p>※1)</p> |  |



② Press “F4” (See) to view the search results.

A:

If points consistent with the query conditions are found, they will be displayed on the screen in the order of storage in the memory. Press “ ” to view the points one by one.

B:

If no point consistent with the query conditions is found, a prompt will pop up and then it will automatically return to measuring point viewing interface.

③ Press “F4” (Search) to measuring point query interface.

| | |
|-----------|-----------|
| Routine | Coor. |
| PtID : | 12 |
| Type : | Resection |
| Job : | a90 |
| Station : | |
| Date : | 2016/1/18 |
| Time : | 13:37:21 |

Del | Search

14:11:25 345 【Message】

No search to point data!

| |
|------|
| Data |
|------|

Check Meas.

| | |
|-----------|---------|
| Job : | All job |
| Station : | * |

Find | See

10:32:54 345 【Message】

※1) Since the station name can be either specific or a wildcard “*”, the search results of all combinations will be explained here. All search results are based on the selected job name:




Station name (specific) + point name (*): the search results show all measuring points on the specific station.

Station name (*) + point name (*): the search results show all measurement data in the job.



7.3.3 Measuring point deletion

This function allows deletion of measuring points in a job.

| Procedure | Display |
|--|--|
| ① Find data of the measuring point to be deleted and press “F1”(Del). |  |
| ② Press “F4” (Yes) to delete the measuring point, or press “F1” (No) to return to previous menu without deleting it. |  <p>you want to delete the data(Mea Data is unrecoverable!</p> <p>No Yes</p>  |



7.4 Code

Creation, search and deletion of codes in the encoding library can be realized here.

Codes in the encoding library can be manually entered.

Each code can have a description and at most 8 attributes each of less than 16 characters.


Code: name

Description: additional comment

Info1: editable, containing more content information


.....

Info8: other information line

| Procedure | Display |
|---|---|
| <p>① Under Manage mode, press “Code” or “4” to enter code setting interface.</p> <p>Press “” and you can return to previous menu.</p> <p>Press the buttons “ ” following “Code” to select a code.</p> |  |

7.4.1 New code

This function allows the creation of new codes.

| Procedure | Display |
|---------------------------------|--|
| ① Enter code setting interface. |  |



② Press “F1” (New) to enter new code creation interface. Enter code, description and other information.

【Input code】

| | |
|----------------|--------|
| Code 1 | Code 2 |
| Code : 9 | |
| Q-Code : -- | |
| Desc. : q | |
| Info 1 : ----- | |
| Info 2 : ----- | |
| Info 3 : ----- | |

Back Cont

③ Press ‘F4’ (Cont) to save the new code.

【Message】

Code is saved successfully!


【See/Create/Delete code】

| | |
|----------------|--------|
| Code 1 | Code 2 |
| Find : * | |
| Code : 1 | ◀ ▶ |
| Q-Code : -- | |
| Desc. : ----- | |
| Info 1 : ----- | |
| Info 2 : ----- | |

New Del All Del



④ If there is an existing code with the name entered, the prompt will pop up. Please enter a new code name and then save it.



7.4.2 Code query

This function allows searching for codes.

| Procedure | Display |
|--|---------|
| ① Enter code setting interface. | |
| ② A: You can search for the code by directly pressing "◀ ▶" and the codes in the file will be displayed one by one. B: Enter the name (or wildcard "*") of the code you are looking for into the field of "Code" and press "OK". | |



| | |
|--|--|
| | |
| (3) A: The query results will be displayed under the code entry. B: If wildcard “*” is entered, press “◀ ▶” to see all codes in the file one by one. C: If there is no such code in the file, the code entry will be empty. Please enter the correct code you want to find. | <p>The screenshot shows the "See/Create/Delete code" interface. The title bar displays the time as 15:50:38 and a battery level of 345. The main area has two tabs: "Code 1" (selected) and "Code 2". Under "Code 1", the "Find" field contains the value "1". Below it, the "Code" field also contains "1". The "Q-Code" field is empty. The "Desc." field contains a dashed line. The "Info 1" and "Info 2" fields are also empty. At the bottom, there are buttons for "New", "Del All", and "Del".</p> |

7.4.3 Code deletion

This function allows deletion of codes.


| Procedure | Display |
|--|---|
| ① Enter code setting interface. A: Directly press “◀ ▶” view codes in the file one by one to find the code to be deleted. B: Enter the name of the code to be deleted into the field following “Find” and press “OK”. ② | <p>The screenshot shows the "See/Create/Delete code" interface. The title bar displays the time as 14:53:35 and a battery level of 345. The main area has two tabs: "Code 1" (selected) and "Code 2". Under "Code 1", the "Find" field contains the value "*". Below it, the "Code" field contains "1". The "Q-Code" field is empty. The "Desc." field contains a dashed line. The "Info 1" and "Info 2" fields are also empty. At the bottom, there are buttons for "New", "Del All", and "Del".</p> |



② When the code to be deleted is found, press “F3” (Del) to delete the specific code.


③ Press ‘F4’ (Yes) to delete the code; press ‘F1’ (No) to return to previous menu without deleting the code.

④ It will return to code setting interface when the specified code is deleted.




Sure you want to delete
Code 1?
Data is unrecoverable!

No | Yes




Delete code success!






⑤ Enter code setting interface.




⑥ Press ‘F2’ (Del All) to delete all codes.



⑦ Press ‘F4’ (Yes) to delete all codes; press ‘F1’ (No) to return to previous menu without deleting the codes.


Sure you want to delete
All code?
Data is unrecoverable!



Delete code success!



⑧ It will return to code setting interface when all codes are deleted.



| | |
|--|--|
| |  |
|--|--|

7.5 Memory initialization

A single data field or all data in the memory can be deleted with this function.


| Procedure | Display |
|---|---------|
| <p>① Under Manage mode, press “Del. Data” or “6” to enter memory initialization setting interface.</p> <p>Press “” and you can return to previous menu.</p> <p>Press buttons “   </p> | |



| | |
|---|--|
| C: Code includes: all codes and single code. | <p>【Del. Data】</p> <p>Routine</p> <p>File type : Road file</p> <p>Road file : All road file</p> <p>Del Back</p> |
| ② With the file selected, press "F1" (Del). | <p>【Del. Data】</p> <p>Routine</p> <p>File type : Code</p> <p>Code : All code</p> <p>Del Back</p> <p>【Warning】</p> <p>Sure you want to delete the data? Data is unrecoverable!</p> <p>No Yes</p> |




③ Press “F4” (Yes) to delete the file; press “F1” (No) to return to previous menu without deleting it.



④ It will return to memory initialization interface after data deletion.


8 Transfer mode

Press [4] or click the button “Transfer”.



This mode covers the following item:

1. Exporting data



8.1 Export data



Data can be exported in two ways with this function.

1. Bluetooth: Data in the instrument memory can be transferred to a receiver (such as PC with a Bluetooth receiver, etc.) via Bluetooth. Data transferred in this way do not undergo check. Bluetooth PIN: 1234. Bluetooth must be activated before exporting the data. See “9.6 Interface” for details.
2. File: Save the file in the folder Mounted_Volume\fdp2\output.



2.1 Via USB connection: First, the computer must install Active Sync of the version higher than 4.0 and double click it. USB device (USB Download Firmware) connection driver shall also be installed (start the total station, connect the computer to the total station with USB cable, then the driver installation prompt will pop up; find the folder and install it). Afterwards, connect USB device connection cable to the total station. Ensure that the computer has already the connection driver installed. When the total station starts and enters the system, the computer can access files in the total station.

2.2 Via SD card connection: Turn off the total station, insert the SD card into the SD card slot and then turn on the total station. When it enters the system, you can access files in the total station and copy them to the SD card.

| Procedure | Display |
|--|---|
| <p>① Under transfer mode, click the button “Exporting Data” or press “1” to enter data export setting interface.</p> <p>Press “” to return to previous menu.</p> <p>Press “F1” (Back) to return to previous menu.</p> <p>Press “F3” (List) to list the jobs.</p> <p>Press “F4” to select a job.</p> <p>Press “F2” (Search) to search for job(s).</p> |   |



The image displays three screenshots of a handheld device's software interface, likely a GPS receiver. The top two screenshots are stacked vertically, and the bottom one is positioned below them.

Screenshot 1: Job search

This screen shows a search interface with a "Search" field containing a placeholder "Search :". Below it is another search field with a placeholder "Search :". At the bottom are "Back", "Cont", and a "Job search" icon.

Screenshot 2: Select a job

This screen displays a table of jobs:

| Job name | Type | Dates |
|----------|------|--------------------|
| a90 | raw | 2014/3/19 10:38:27 |
| DEFAULT | raw | 1/1/2006 12:19:55 |

At the bottom are "Back", "Cont", and a "Select a job" icon.

Screenshot 3: Exporting Data

This screen shows export settings:




- "Select" field
- "To" field set to "Bluetooth"
- "Data type" field set to "Meas.& Fixpoints"
- "Job" field set to "All job"
- "Save Type" field set to "DADI NEZ)(*.dad")

At the bottom are "Back", "Search", "List", and "Cont" buttons.

Text Description:


② Press buttons “◀▶” following “To” to select the place to save the data. The options include Bluetooth and File.



| | |
|--|--|
| <p>③ Press buttons “◀ ▶” following “Data type” to select output data type. The options include: Meas.Data, Fixpoints and Meas.&Fixpoints.</p> |  <p>The screenshot shows the "Exporting Data" menu. The "Data type" field is highlighted and set to "Meas.& Fixpoints". Other options shown are "Meas.Data" and "All job". The "Save Type" field is set to "DADI NEZ(*.dad)". Navigation buttons for "Back", "Search", "List", and "Cont" are at the bottom.</p> |
| <p>④ Press buttons “◀ ▶” following “Job” to select the job(s). The options include single job and all jobs. You can press “F2” (Search) to search for the job file(s) or press “F3” (List) to invoke the job file(s).</p> |  <p>The screenshot shows the "Exporting Data" menu. The "Job" field is highlighted and set to "All job". Other options shown are "Single job" and "Search". The "Save Type" field is set to "DADI NEZ(*.dad)". Navigation buttons for "Back", "Search", "List", and "Cont" are at the bottom.</p> |
| <p>⑤ Press buttons “◀ ▶” following “Save Type” to select the storage type. The options include: (DADI NEZ)(*.<u>dad</u>), (DADI ENZ)(*.<u>dad</u>), (South)(*.<u>dat</u>), (SCS)(*.<u>dat</u>), (SV300)(*.<u>svf</u>) and (Topcom)(*.<u>pts</u>)</p> |  <p>The screenshot shows the "Exporting Data" menu. The "Save Type" field is highlighted and set to "DADI NEZ(*.dad)". Other options shown are "Bluetooth", "Meas.& Fixpoints", and "All job". Navigation buttons for "Back", "Search", "List", and "Cont" are at the bottom.</p> |




- ⑥ Press “F4” (Cont) to confirm the options and prepare for exporting the data.




No Yes

- ⑦ Press “F4” (Yes) to transfer the file(s); press “F1” (No) to return to previous menu without transferring the file(s).




Back

- ⑧ Press “F1” (Back) to return to previous menu.



9 Configuration mode

Press [5] or click the button “Configuration”.



This mode covers the following items:

1. Work
2. Regional
3. Meas.Parameter
4. Screen & Audio
5. EDM
6. Interface



| Menu | Item | Content |
|------|------------|---|
| Work | USER key 1 | Select function of the USER key, including: Laser Line, Laser Point, Regional, VD, Home and Meas. |
| | USER key 2 | Select function of the USER key, including: Laser Line, Laser Point, Regional, VD, Home and Meas. |



| | | |
|----------------|-------------------------|--|
| Regional | Vertical angle | Select vertical angle zero reading: either zenith or horizontal direction. |
| | Angular unit | Select angular unit, including degree-minute-second (360 °), gon (400 Gon), mil (6400 Mil) and degree (360 °). |
| | Distance unit | Select distance unit, either meter or foot. |
| | Date format | Select date display format, including: |
| Meas.Parameter | Air pressure | Air pressure can be entered. |
| | Temperature | Temperature can be entered. |
| | PPM | PPM can be entered or it can also be calculated with the air pressure and temperature entered. |
| | Prism constant | Prism constant can be entered. |
| | Reflector constant | Reflector constant can be entered. |
| | Data storage | To choose to or not to store the data |
| | Measurement storage | To choose to or not to store measurement information |
| Screen & Audio | Beep | Set beep to OFF or ON during setting of the audio mode. |
| EDM | Measurement mode | Select the measurement mode, including S.Meas, P.Meas and NP.Meas. |
| | Laser type | Select the laser type, including fine measurement and tracking. |
| | Number of measurements | Number of measurements can be entered. |
| Interface | Bluetooth communication | Set Bluetooth communication to ON or OFF. |

9.1 Work

This function allows general work configuration and configuration of USER key 1 and 2.

| Procedure | Display |
|-----------|---------|
|-----------|---------|





① Under Configuration mode, press the button “Work” or “1” to enter general work configuration interface.


Press “” to return without saving the configuration.

Press “F4” (Yes) to save the configuration and return to previous menu.




Press “F1” (No) to return to general work configuration interface without saving the configuration.




Sure you want to interrupt?
Data changes will be ignored!





| | |
|--|---|
| <p>② In general work configuration interface, function of USER key 1 can be configured with the buttons “◀▶” behind “USER Key1” and the options include: Laser Line, Laser Point, Regional, VD, Home and Meas.</p> |  <p>The screenshot shows the 'Work' configuration interface. At the top, there are icons for a monitor, a computer, a globe, and a battery. The time is 9:51:10. A circular badge indicates '345'. Below the header, the title '[Work]' is displayed above 'Page 1'. Under the configuration section, 'USER Key1' is set to 'Home' and 'USER Key2' is set to 'Meas'. Navigation arrows are shown to the right of each key assignment. A blue bar at the bottom right contains the text 'Cont'.</p> |
| <p>② Press the buttons “◀▶” behind “USER Key2” to configure the function of USER key 2 and the options include: Laser Line, Laser Point, Regional, VD, Home and Meas.</p> |  <p>The screenshot shows the 'Work' configuration interface. At the top, there are icons for a monitor, a computer, a globe, and a battery. The time is 9:51:10. A circular badge indicates '345'. Below the header, the title '[Work]' is displayed above 'Page 1'. Under the configuration section, 'USER Key1' is set to 'Home' and 'USER Key2' is set to 'Meas'. Navigation arrows are shown to the right of each key assignment. A blue bar at the bottom right contains the text 'Cont'.</p> |
| <p>④ Press ‘F4’ (Cont) to save the configuration and return to previous menu.</p> |  <p>The screenshot shows a message screen with the title '[Message]' in yellow. The main text area displays 'Complete parameter setting!' in black. At the bottom, there is a blue horizontal bar with four segments.</p> |



9.2 Regional

This function allows regional configuration, including the configuration of vertical angle, angular unit, distance unit and date format.

| Procedure | Display |
|---|--|
| ① Under Configuration mode, press the button “Regional” or “2” to enter regional configuration interface. | <p>The display shows the Regional configuration interface. It includes settings for V-Setting (Zenith 0°), Language (English), and Lang.Choice (Off). A blue bar at the bottom right contains the text "Cont".</p> |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|---|---------------------------------|---|------|--------------|------------------------|---|-------------|------------------------|---|-------------|-------------------------|--|--------------|--------------------------|--|---------|------|------|-------------|------------------------------|--|--------|--------------------------------|--|----------|---------------------------------|---|----|--|-----|
| <p>Press “<p>【Regional】</p><table border="1"><tr><td>Routine</td><td>Unit</td><td>Time</td></tr><tr><td>Angle Unit :</td><td><input type="text"/> °</td><td> </td></tr><tr><td>Dist.Unit :</td><td><input type="text"/> m</td><td> </td></tr><tr><td>Temp.Unit :</td><td><input type="text"/> °C</td><td></td></tr><tr><td>Press.Unit :</td><td><input type="text"/> hPa</td><td></td></tr></table><p>9:51:46 345  </p><p>【Regional】</p><table border="1"><tr><td>Routine</td><td>Unit</td><td>Time</td></tr><tr><td>Time(24h) :</td><td><input type="text"/> 9:52:06</td><td></td></tr><tr><td>Date :</td><td><input type="text"/> 10.3.2016</td><td></td></tr><tr><td>Format :</td><td><input type="text"/> dd.mm.yyyy</td><td> </td></tr></table><p>9:52:06 345  </p><p>【Message】</p><p>Sure you want to interrupt? Data changes will be ignored!</p><table border="1"><tr><td>No</td><td></td><td>Yes</td></tr></table></p> | Routine | Unit | Time | Angle Unit : | <input type="text"/> ° |   | Dist.Unit : | <input type="text"/> m |   | Temp.Unit : | <input type="text"/> °C | | Press.Unit : | <input type="text"/> hPa | | Routine | Unit | Time | Time(24h) : | <input type="text"/> 9:52:06 | | Date : | <input type="text"/> 10.3.2016 | | Format : | <input type="text"/> dd.mm.yyyy |   | No | | Yes |
| Routine | Unit | Time | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Angle Unit : | <input type="text"/> ° |   | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Dist.Unit : | <input type="text"/> m |   | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Temp.Unit : | <input type="text"/> °C | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Press.Unit : | <input type="text"/> hPa | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Routine | Unit | Time | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Time(24h) : | <input type="text"/> 9:52:06 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Date : | <input type="text"/> 10.3.2016 | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| Format : | <input type="text"/> dd.mm.yyyy |   | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| No | | Yes | | | | | | | | | | | | | | | | | | | | | | | | | | | | |



| | |
|---|---|
| | <p>The Configuration screen displays six main categories: Work (1), Regional (2), Meas.Parameter (3), Screen & Audio (4), EDM (5), and Interface (6). Each category has a corresponding icon and label below it.</p> |
| ② In regional configuration interface, press the buttons “◀ ▶” behind “V-Setting” to configure vertical angle zero reading and the options include Zenith 0° and Horizon 0°: | <p>The Regional configuration screen shows the following settings:</p> <ul style="list-style-type: none">V-Setting : Zenith 0° (with navigation buttons)Language : EnglishLang.Choice : Off |
| ③ Press the buttons “◀ ▶” behind “Angle Unit” to configure the angular unit and the options include: ° (360°), gon (400 Gon), mil (6400 Mil) and ° (360°). Press the buttons “◀ ▶” behind “Dist.Unit” to configure the distance unit and the options include m and ft. | <p>The Regional configuration screen shows the following settings:</p> <ul style="list-style-type: none">Angle Unit : ° (with navigation buttons)Dist.Unit : m (with navigation buttons)Temp.Unit : °CPress.Unit : hPa |






| | |
|--|------------------------------------|
| <p>④ Press the buttons “ ”, behind “Format” to configure the date format and the options include: dd.mm.yyyy, mm.dd.yyyy and yyyy.mm.dd.</p> | |
| <p>⑤ Press ‘F4’ (Cont) to save the configuration and return to previous menu.</p> | <p>Complete parameter setting!</p> |

9.3 Meas.Parameter

This function allows configuration of measurement parameters, including air pressure, temperature, PPM, prism constant, reflector constant, data storage and measurement storage.



| Procedure | Display |
|---|--|
| ① Under Configuration mode, press the button “Meas.Parameter” or “3” to enter measurement parameter configuration interface. |   |
| Press “↶” to return without saving the entered data and configuration. | |
| Press “F4” (Yes) to save the entered data and configuration and return to previous menu; Press “F1” (No) to return to measurement parameter configuration interface without saving the entered data and configuration. |  |



| | | | | | | | | | | | |
|--|---|--------------|------------|------------|-------|-----------------------|-----------|-------|--------|---------|------|
| | <p>The Configuration screen displays six main categories: Work, Regional, Meas.Parameter, Screen & Audio, EDM, and Interface. Each category has a corresponding icon and label.</p> | | | | | | | | | | |
| ② In measurement parameter configuration interface, the prism constant can be entered in the field of "Prism". Enter the reflector constant into the field of "NP. Const". | <p>The Meas. Parameter screen shows various atmospheric parameters and correction factors:</p> <table border="1"><tr><td>Air Pressure</td><td>1013.7 hPa</td></tr><tr><td>Temp</td><td>20 °C</td></tr><tr><td>Meteorological Correc</td><td>4.586 PPM</td></tr><tr><td>Prism</td><td>-30 mm</td></tr><tr><td>NPConst</td><td>0 mm</td></tr></table> | Air Pressure | 1013.7 hPa | Temp | 20 °C | Meteorological Correc | 4.586 PPM | Prism | -30 mm | NPConst | 0 mm |
| Air Pressure | 1013.7 hPa | | | | | | | | | | |
| Temp | 20 °C | | | | | | | | | | |
| Meteorological Correc | 4.586 PPM | | | | | | | | | | |
| Prism | -30 mm | | | | | | | | | | |
| NPConst | 0 mm | | | | | | | | | | |
| ③ Press the buttons "↔" behind "Data Store" to choose to or not to store the data and the options include: ON and OFF. Press the buttons "↔" behind "Meas Store" to choose to or not to store measurement data and the options include: ON and OFF. | <p>The Meas. Parameter screen shows the Data Store and Meas Store settings:</p> <table border="1"><tr><td>Data Store</td><td>ON</td></tr><tr><td>Meas Store</td><td>ON</td></tr></table> | Data Store | ON | Meas Store | ON | | | | | | |
| Data Store | ON | | | | | | | | | | |
| Meas Store | ON | | | | | | | | | | |



| | |
|--|--|
| <p>④ Press “F2” (Air) to configure air pressure and temperature. Enter air temperature into the field of “Air Pressure”. Enter temperature into the field of “Temp”. Press “F4” (Determine) to save the air pressure and temperature, calculate PPM and then return to measurement parameter configuration menu; Press “F1” (Back) to return to measurement parameter configuration interface without saving air pressure and temperature.</p> | <p>Air Pressure 1013.7 hPa Temp 20 °C</p> <p>Back Determine </p> |
| <p>⑤ Press “F3” (PPM) to configure PPM. Enter PPM into the field of “M.C”. Press “F4” (Determine) to save the PPM and return to measurement parameter configuration menu; Press “F1” (Back) to return to measurement parameter configuration interface without saving the PPM.</p> | <p>M.C 4.586 PPM</p> <p>Back Determine </p> |





| | |
|--|--|
| | <p>【Meas. Parameter】</p> <p>Air Pressure 1013.7 hPa Temp 20 °C Meteorological Corrected 4.586 PPM Prism -30 mm NP.Const 0 mm</p> <p>Air PPM Detemine</p> |
| ⑥ Press "F4" (Detemine) to save the configuration and return to previous menu. | <p>【Message】</p> <p>Complete parameter setting!</p> |
| | <p>【Configuration】</p> <p>Work Regional Meas.Parameter Screen & Audio EDM Interface</p> |







9.4 Screen & Audio

This function allows configuration of the screen and audio and set beep to ON or OFF under audio mode.

| Procedure | Display |
|---|---|
| ① Under Configuration mode, press the button “Screen & Audio” or “4” to enter screen and audio configuration interface. Press “” to return without saving the configuration. |   |
| Press ‘F4’ (Yes) to save the configuration and return to previous menu. Press ‘F1’ (No) to return to Screen & Audio configuration interface without saving the configuration. |  |



| | |
|--|---|
| |  |
| ② In screen and audio configuration interface, press the buttons “◀ ▶” behind “Beep” to set it to ON or OFF under audio mode. To save the modification, press “F4” (Cont). |  <p>Set</p> <p>Beep : <input type="button" value="OFF"/> <input type="button" value="ON"/></p> |
| ③ Press “F4” (Cont) to save the configuration and return to previous menu. |  <p>9:48:14</p> <p>【Message】</p> <p>Complete parameter setting!</p> |



9.5 EDM

This function allows configuration of EDM, including measurement mode, laser type and number of measurements.

| Procedure | Display |
|--|---------|
| ① Under Configuration mode, press the button “EDM” or “5” to enter EDM configuration interface. | |
| Press “↶” to return without saving the configuration. Press “F1” (Back) to return without saving the configuration. | |




previous menu.


Press “F1” (No) to return to EDM configuration interface without saving the configuration.

Sure you want to interrupt?
Data changes will be ignored!

No | Yes



- ② In EDM configuration interface, press the buttons “ ” behind “Meas.Mode” to configure the measurement mode and the options include: S.Meas, P.Meas and NP.Meas.





③ Press the buttons “◀▶”

behind “Laser Type” to configure the laser type and the options include: TR and FR.

☆ FR mode: fine measurement, the normal distance measurement mode.

Measuring time: approx. 2s



Minimum display distance:
1mm

☆ TR mode: tracking; measuring time of this mode is shorter than that of fine measurement mode and it is mainly use for layout measurement. It is quite useful in tracking moving targets and engineering layout.

Measuring time: approx. 0.8s


Minimum display distance:
1mm

④ Enter the number of measurement in the field of “Meas.Num”.





- ⑤ Press “F4” (Determine) to save the configuration and return to previous menu.




9.6 Interface

This function allows communication interface configuration and whether to activate the Bluetooth or not.


| Procedure | Display |
|-----------|---------|
|-----------|---------|



① Under Configuration mode, press the button “Interface” or “6” to enter interface configuration interface.



Press “” to return without saving the configuration.



Press ‘F4’ (Yes) to save the configuration and return to previous menu.


Press ‘F1’ (No) to return to

Sure you want to interrupt?
Data changes will be ignored!






| | | | | | | | | | | | | | |
|---|---|--------|-----------|-------------|----------|-------------|------|------------|---|----------|------|----------|-------|
| interface configuration interface without saving the configuration. | <p>The Configuration menu screen displays six icons numbered 1 through 6:</p> <ul style="list-style-type: none">1 Work2 Regional3 Meas.Parameter4 Screen & Audio5 EDM6 Interface | | | | | | | | | | | | |
| ② In interface configuration interface, press the buttons “◀ ▶” behind “Bluetooth” to configure the Bluetooth and the options include: Active and Inactive. | <p>The Interface configuration screen for Con. 1 shows the following port settings:</p> <table border="1"><tr><td>Port :</td><td>Bluetooth</td></tr><tr><td>Bluetooth :</td><td>Inactive</td></tr><tr><td>Baud rate :</td><td>9600</td></tr><tr><td>Data bits:</td><td>8</td></tr><tr><td>Parity :</td><td>None</td></tr><tr><td>Endmark:</td><td>CR/LF</td></tr></table> <p>Buttons at the bottom right: ◀ ▶ and Cont.</p> | Port : | Bluetooth | Bluetooth : | Inactive | Baud rate : | 9600 | Data bits: | 8 | Parity : | None | Endmark: | CR/LF |
| Port : | Bluetooth | | | | | | | | | | | | |
| Bluetooth : | Inactive | | | | | | | | | | | | |
| Baud rate : | 9600 | | | | | | | | | | | | |
| Data bits: | 8 | | | | | | | | | | | | |
| Parity : | None | | | | | | | | | | | | |
| Endmark: | CR/LF | | | | | | | | | | | | |
| ③ Press “F4” (Cont) to save the configuration and return to previous menu. | <p>The Message screen displays the message: Complete parameter setting!</p> | | | | | | | | | | | | |




10 Tools mode

Press [6] or click the button “Tools”.



This mode covers the following items:

1. Adjustment
2. Exit
3. Info



10.1 Adjustment

The compensator can automatically measure the angle between the instrument and the horizontal plane and compensate vertical angle measured by the instrument, to make the results more accurate. Therefore, the compensator shall be frequently inspected and adjusted.

10.1.1 Compensator adjustment

For specific operations, please contact local dealers.

| Procedure | Display |
|---|---------|
| ① Under Tools mode, press the button “Adjustment” or “1” to enter adjustment setting interface. | |
| ② Press “F1” or (1) to enter compensator adjustment interface. For specific operations, please contact local dealers. | |



10.1.2 Index error

For specific operations, see “11.6 Index error of vertical circle (angle i) and vertical circle index zero setting”.




10.1.3 Instrument constant

Instrument constant can be configured with this function, including that for “prism distance measurement”, “Reflector distance measurement” and “non-prism distance measurement”.


| Procedure | Display |
|---|---|
| ① In adjustment setting interface, press “F3” or (3) to enter instrument constant setting interface. |  <p>The screenshot shows the "Adjustment" menu with three options: "F1 Tilt Compensation", "F2 Vertical Index", and "F3 Instrument constant". The "F3" option is highlighted with a blue bar at the bottom.</p> |
| ② Enter the constant for “prism distance measurement”, “Reflector distance measurement” and “non-prism distance measurement”. |  <p>The screenshot shows the "Instrument constant" data entry screen with three fields: "S.Meas" (-55 mm), "P.Meas" (-55 mm), and "NP.Meas" (-55 mm). At the bottom are buttons for "Back", "test", and "Determine".</p> |



| | |
|---|---|
| <p>③ Press “F4” (Determine) to save the settings and return to previous menu; or press “F1” (Back) to cancel the operation and return to previous menu.</p> |  <p>The screenshot shows the Adjustment menu with the following options:</p> <ul style="list-style-type: none">F1 Tilt Compensation (1)F2 Vertical Index (2)F3 Instrument constant (3) <p>At the bottom are buttons for F1, F2, and F3.</p> |
|---|---|


10.2 Info

This function allows display of system information, including instrument type, battery level, operating system, language, version number, job information, number of measurements and fixpoints in a job, road file quantity, code quantity and options.

| Procedure | Display |
|---|---|
| <p>① Under Tools mode, press “Info” or “3” to enter system information interface. Press “F4” (Back) to return to previous menu.</p> |  <p>The screenshot shows the Info menu with the following tabs:</p> <ul style="list-style-type: none">SystemSoftwareMemory <p>Under System, it shows:</p> <ul style="list-style-type: none">Instr. Type: Total stationBattery: 0 % <p>At the bottom are buttons for Options and Back.</p> |



| | |
|--|---|
| | <p>System Software Memory</p> <p>Oper. System: WinCE Active Language: English Build Number: V1.0</p> <p>Back</p> |
| | <p>System Software Memory</p> <p>Job: All job Meass.Data: 6 Fixpoints: 13 Road file: 3 Code: 3</p> <p>Back</p> |
| ② In the page of “system”, press “F2” (Options) to enter options interface. Press “F4” (Back) to return to previous menu. | <p>Option 1 Option 2</p> <p>Laser Point: OFF Laser Line: OFF Single Keyb.: Color & Touch USG Host: Yes USB Equip.: Yes Bluetooth: Yes</p> <p>Back</p> |




11 Inspection and calibration

本仪器在出厂时均经过严密的检验与校正，符合质量要求。但仪器经过长途运输或环境变化，其内部结构会受到一些影响。因此，新购买本仪器以及到测区后在作业之前均应对仪器进行本节的各项检验与校正，以确保作业成果精度。

The instrument is carefully inspected and calibrated in the factory and conforms to quality requirements. However, the internal structure may be affected due to long-distance transport or environmental changes. Hence, newly purchased instrument and instrument prior to operation in the survey region shall undergo the various inspection and calibration items specified in this chapter, to ensure accuracy of the measurement results.

11.1 Level tube



- Inspection:

See 4.2 “Level the instrument with level tube in a fine manner” of this document for the method.



- Calibration:

1. During inspection, if bubble in the level tube is not on the center, first adjust it with the foot screws parallel with the level tube to make the bubble move toward the center for half of the offset; for the rest half, turn the adjusting screw (on the right of the level tube) of the level tube with the adjusting pin to set the bubble to the center.
 2. Rotate the instrument for 180 ° to check whether the bubble is centered. If not, repeat step 1 until it is centered.
 3. Rotate the instrument for 90 ° and adjust the bubble to the center with the third foot screw.
- Repeat the inspection and calibration procedure until the bubble is centered whichever direction the alidade is turned to.

11.2 Circular vial

- Inspection:

If bubble of circular vial is in the center after correct inspection and calibration of the level tubes, no calibration is required.

- Calibration


If the bubble is not centered, it shall be set to the center by adjusting the adjusting screws below the bubble with adjusting pin or Allen wrench. For calibration, first loosen the adjusting screw (1 or 2) on the opposite of the offset direction and then tighten other adjusting screws in the near the bubble to center the bubble. When centering the bubble, the tightening force applied to the three adjusting screws shall be uniform.

11.3 Telescope reticle

- Inspection:


1. With the instrument leveled, select a target point A on the sight line of the telescope, sight A with graticule on the reticle and then fix the horizontal and vertical clamp screws.
2. Turn vertical tangent of the telescope to move point A to edge of the field of view (point A').
3. If point A moves along the vertical line of the graticule, namely, point A' is within the vertical line, no calibration is required if the graticule does not slant.

As shown in the following figure, if point A' is not on the center of the vertical line, namely, the graticule tilts, calibration of the reticle is required.



- Calibration


1. First remove the reticle base cover between telescope eyepiece and focusing knob and the four screws retaining the reticle base will be exposed (see the figure attached).
2. Evenly unscrew the four screws with a screwdriver and turn the reticle base around the collimation axis to make point A' on the vertical line.
3. Evenly tighten the four screws and check the calibration results with the method stated above.
4. Reinstall the cover.



11.4 Perpendicularity of collimation axis and horizontal axis (2C)

- Inspection:

1. Set a target A far away at the same height of the instrument, finely level the instrument and switch on the power.
2. With circle left, sight target A with the telescope and read the horizontal angle.
(e.g.: horizontal angle $L = 10^\circ 13' 10''$)
3. Releasing vertical and horizontal clamp screws to adjust the telescope and then turn the alidade circle right to sight the same point A and read the horizontal angle. Horizontal and vertical clamp screws shall be tightened prior to sighting.
(e.g.: horizontal angle $L = 190^\circ 13' 40''$)
4. $2C = L - (R \pm 180^\circ) = -30'' \geq \pm 20''$ and calibration is required.



- Calibration

1. Adjust the horizontal angle reading to the correct value with C offset by adjusting horizontal tangent:

$$R + C = 190^\circ 13' 40'' - 15'' = 190^\circ 13' 25''.$$

2. Remove the reticle base cover between telescope eyepiece and focusing knob and adjust the two horizontal graticule adjusting screws on the reticle. First loosen the screw on one side and then tighten the one on the other side. Move the reticle to sight target A with the graticule.

3. Repeat the inspection and calibration procedure until it conforms to the requirement of $|2C| < 20''$.

4. Reinstall the cover.

11.5 Vertical circle index zero automatic compensation

- Inspection:

1. With the instrument installed and leveled, make direction of the telescope consistent with the line formed by instrument center and any of the foot screws X and tighten the horizontal clamp screw.

2. Turn on the instrument, set vertical circle index to zero, tighten vertical clamp screw and the instrument will display vertical angle of current telescope direction.

3. Turn the foot screw X for 10mm circumference along one direction and the vertical angle displayed will change along until it disappears and the “out” message pops up, indicating the instrument vertical axis tilts for over 3° and has exceeded design range of vertical circle compensator. When the foot screw is turned in the opposite direction to restore it, the instrument will display the vertical angle again. Repeat the test at the critical position to see the change which indicates the vertical circle compensator works normally.

- Calibration

The instrument shall be sent to the factory for repair when any fault with the compensator is found.

11.6 Index error of vertical circle (angle i) and vertical circle index zero setting

Conduct this test after items of 11.3 and 11.5 are carried out.

- Inspection:

1. With the instrument erected, leveled and turned on, sight any clear target A with the telescope and get the vertical angle circle left reading L.



2. Turn the telescope and sight A again to get the vertical angle circle right reading R.

$$i = (L + R - 180^\circ) / 2 \text{ 或 } (L + R - 540^\circ) / 2.$$

3. If vertical angle zenith is 0° , $i = (L + R - 360^\circ) / 2$; if vertical angle horizontal is 0° , $i = (L + R - 180^\circ) / 2$ or $(L + R - 540^\circ) / 2$.


4. If $|i| \geq 10''$, vertical circle index zero shall be reset.

• Calibration

| Procedure | Display |
|--|---------|
| ① With instrument leveled, press POWER to turn on the instrument. | |
| ② Press the button "Tools" or "6" to enter Tools mode. | |




- ③ Press the button “Adjustment” or “1” to enter adjustment setting interface.





- ④ Press “F2” or “2” to enter index error setting interface.

- ⑤ Accurately sight the target at normal position (circle left) of the telescope and press “F4” (Confirm) to proceed with next step.



- ⑥ Turn the telescope and accurately sight the same target with telescope inverted (circle right). Press “F4” (Confirm) to finish setting and it will automatically return to adjustment menu.





Notes: 1. Repeat the inspection procedure to measure the index error (angle i) again. If the index error still cannot meet the requirement, it shall be checked whether the three calibration (index zero setting) steps are properly conducted and whether the target is properly sighted. Please reset it as required.

2. The instrument shall be sent to the factory for repair if the requirements are not met after repeated inspection and calibration.

● The vertical angles displayed during zero setting are values not compensated or corrected and can only serve as reference in the setting process. They shall not be used for other applications.

11.7 Optical plummet

- Inspection:


1. Set the instrument onto the tripod, draw a cross on a white paper and place it on the ground right below the instrument.

2. Properly adjust focusing distance of the optical plummet and move the white paper to set the cross to the center of the sight field.

3. Turn the foot screw to make center mark of the plummet coincide with intersection of the cross.

4. Turn the alidade. Observe overlap ratio of center mark of the plummet with intersection of the cross for every turn of 90° .

5. If center mark of the optical plummet coincides with intersection of the cross while turning the alidade, no calibration is required. Otherwise, it shall be calibrated in the following way.



- Calibration

1. Remove the adjusting screw cover between optical plummet eyepiece and focusing knob.
2. Retain the white paper with a cross and mark drop point of plummet center mark on the paper for each turn of 90 ° of the instrument, point A, B, C and D, as shown in the figure.
3. Draw two lines connecting diagonal points AC and BD and intersection point of the two lines is O.
4. Adjust the four adjusting screws of the plummet with the adjusting pin to make center mark of the plummet coincide with point O.
5. Repeat inspection step 4 to check whether it meets the requirements after calibration.
6. Reinstall the cover.

11.8 Instrument constant (K)


Instrument constant is inspected before it leaves factory and the instrument is adjusted to set K to 0. The instrument constant rarely changes, but we suggested checking it once or twice every year. This inspection shall be conducted on a standard base line or in the way described below.

- Inspection:

1. Select a flat field and erect and level the instrument at point A. carefully mark point A, B and C on the same line with an equal space of 50m and accurately install and align the reflector prism.
2. With temperature and air pressure entered into the instrument, accurately measure the horizontal distances AB and AC.
3. Erect and accurately align the instrument at point B and accurately measure the horizontal distance BC.
4. Then you can get the instrument constant:

$$K = AC - (AB + BC)$$

K shall be approximately 0. If $|K| > 6\text{mm}$, strict inspection shall be conducted in a standard base line site and calibration shall be conducted based on the test value.




- Calibration

It has been verified through strict tests that changes have occurred when the instrument constant is not approximately 0. If the user must calibrate it, the instrument addition constant shall be set to the composite constant K.

- Vertical line of the instrument shall be used for orientation, to make points A, B and C strictly on the same line. There shall be a solid and clear alignment mark on the ground at point B.
- Whether prism center at point B coincide with instrument center is an important factor affecting measurement accuracy. Hence, it would be preferred to use a tripod or a universal base at point B. if three-leg type prism connector and base are adopted, the tripod and base shall remain still when exchanging them and only exchange the parts of the prism and the instrument above the base, to reduce coincidence error.

11.9 Parallelism of collimation axis and emission electric-optical axis



- Inspection:

1. Erect a reflector prism at 50m from the instrument.
2. Accurately sight the reflector prism center with the telescope.
3. Switch on the power and enter routine measurement mode. Press "Meas" to conduct distance



measurement. Turn horizontal tangent left and right and vertical tangent up and down for electric sighting. Find the center of the emission electric-optical axis for distance measurement based on the left and right flashing points and up and down flashing points indicating smooth optical path for distance measurement.

4. Check whether graticule center of the telescope coincides with center of emission electric-optical axis. If so, it is qualified.

- Calibration

If telescope graticule center deviates hugely from center of emission electric-optical axis, it shall be sent to the professional repair department for calibration.

11.10 Base foot screw

If the foot screw is found loose, it can be tightened by adjusting the 2 adjusting screws on eth base. Tighten the screws with proper torque.

11.11 Assemblies for reflector prism

1. Reflector prism connector

It shall be checked whether the level tubes and optical plummet on the base connector are correct. See 11.1 and 11.7 for the inspection methods.

2. Centering rod perpendicularity

As shown in the figure in 11.7, draw a “+” at point C and insert lower tip of centering rod into the point. Do not move it throughout the inspection. The two feet e and f shall be respectively at point E and F on the cross. Adjust the length of e and f to set bubble of centering rod circular level to the center.

Erect the leveling instrument at point A not far from the cross. Sight point C with center of graticule. Retain horizontal clamp screw with foot point and tilt the telescope upward to make point D on upper part of centering rod near the horizontal line. Withdraw and extend only foot e of the centering rod to move point D left and right to sight center of the graticule. At this time, points C and D shall be both on centerline of the graticule.

Erect the instrument on point B another point on the graticule in the same way. At this time, only withdraw and extend foot f to make point D on the centering rod coincide with point C on the graticule centerline.

After calibration at point A and B, the centering rod is already perpendicular. If bubble of the circular level on the rod is not at the center, adjust the three adjusting screws below the circular level to center the bubble.

Conduct inspection and calibration again until the centering rod is perpendicular in both directions and the bubble is centered.



12 Technical parameters

| | | Wince total station |
|---|--|-------------------------|
| Distance measurement | | |
| Maximum distance (under good weather conditions) | Single prism | 2.5 Km |
| | Three prisms | 5.0 Km |
| | Non-prism | 400m or 600m (optional) |
| Numeric display | Maximum: 99999999.999 m minimum: 1mm | |
| Accuracy | Non-prism: 5+3ppm; prism: 3+2ppm | |
| Unit | m/ft (optional) | |
| Measuring time | Fine measurement: 2s each time; tracking: 0.8s | |
| Number of measurements | 1~99 measurements can be taken | |
| Meteorological correction | It will automatically correct it with parameters entered | |
| Atmospheric refraction and earth curvature correction | It will automatically correct it with parameters entered; K=0.14 | |
| Prism constant correction | It will automatically correct it with parameters entered | |
| Angle measurement | | |
| Measurement mode | Absolute code | |
| Grating disc diameter (horizontal, vertical) | 79mm | |
| Minimum display reading | 1" | |
| Detection method | Vertical disc: diameter | |



| | |
|---------------------------------------|---|
| | Horizontal disc: diameter |
| Accuracy | 2" |
| Telescope | |
| Imaging | Positive image |
| Barrel length | 170mm |
| Effective aperture of objective lens | 48mm |
| Magnifying ratio | 30× |
| Field angle | 1°30' |
| Resolution | 3.5" |
| Minimum focusing distance | 1.5m |
| Automatic vertical compensator | |
| System | Single- or double-axis liquid electronic sensing and compensation |
| Operating range | ±3' |
| Accuracy | ±3" |
| Level | |
| Level tube | 20"/2mm, 30"/2mm |
| Circular vial | 8'/2mm |
| Optical plummet | |
| Imaging | Positive image |
| Magnifying ratio | 3× |
| Focusing range | 0.5m~∞ |
| Field angle | 5° |
| Display | |
| Type | Double-side, diagram form |
| Data transmission | |
| Interface | RS-232C |
| Bluetooth | |
| Onboard battery | |
| Power | Rechargeable mh-ni battery, rechargeable lithium battery |



| | |
|--------------------------|--|
| \Voltage | Lithium battery: DC7.6V; mh-ni battery: DC7.2V |
| Continuous working hours | 7h |
| Size and weight | |
| Overall dimensions | 174×207×383 mm |
| Weight | 6.8 kg |



13 Accessories

| | |
|-------------------------------|------------------------------------|
| ● Packing box | 1 pcs |
| ● Main machine | 1 set |
| ● Standby onboard battery | 1 set |
| ● Charger | 1 set |
| ● Plumb | 1 pcs (laser plummet has no plumb) |
| ● Adjusting pin | 2 pcs |
| ● Soft brush | 1 pcs |
| ● Screwdriver | 1 pcs |
| ● Allen wrench | 2 pcs |
| ● Lint | 1 pcs |
| ● Drying agent | 1 bag |
| ● Certificate of quality | 1 pcs |
| ● Instrument operation manual | 1 copy |
| ● USB data line | 1 pcs |
| ● Driver disk | 1 set |



14 [Annex] Road alignment element calculation

The alignment elements in road alignment layout program include beeline, arc and curve.

Notes:

- 1) Road alignment data are directly manually entered;
- 2) Road alignment data are management based on pile number;
- 3) Though [Layout store] is set to ON, the layout data can neither be printed or stored;
- 4) A job name corresponds with a road data alignment and multiple alignments can be created by creating several job names.


1. Road alignment elements

They are manually entered into the Wince total station.

The way to enter the alignment elements is described below.

| Alignment element | Parameters |
|-------------------|--|
| Beeline | Azimuth, distance |
| Curve | Radius, curve length |
| Arc | Radius, arc length |
| Point | N and E coordinates, radius, A1 and A2 |

Note: When data is loaded from the computer or the items are entered by selecting the point name, calculation of the parameters is not required.



| PT name | North (N) | East (E) | Radius (R) | Curve A1 | Curve A2 |
|---------|--------------|-------------|---------------|----------|----------|
| BP | 1100.000 | 1050.000 | | | |
| IP1 | 1300.000 | 1750.000 | 100.000 | 80.000 | 80.000 |
| IP2 | 1750.000 | 1400.000 | 200.000 | 0.000 | 0.000 |
| EP | 2000.000 | 1800.000 | | | |

For example:

Under Programs menu, select [Road Designment] and then [Define H. Line] to define road horizontal alignment. Enter the data in the following way:

| | |
|------|---------------------------------------|
| Pile | <input type="text" value="0"/> |
| N | <input type="text" value="1100.000"/> |
| E | <input type="text" value="1050.000"/> |

Press [Detemine]; then press [PT] and enter the data as follows:

| | |
|----|---------------------------------------|
| N | <input type="text" value="1300.000"/> |
| E | <input type="text" value="1750.000"/> |
| R | <input type="text" value="100.000"/> |
| A1 | <input type="text" value="80.000"/> |
| A2 | <input type="text" value="80.000"/> |

Enter the following data in the way described above:

| | |
|----|---------------------------------------|
| N | <input type="text" value="1750.000"/> |
| E | <input type="text" value="1400.000"/> |
| R | <input type="text" value="200.000"/> |
| A1 | <input type="text" value="0.000"/> |
| A2 | <input type="text" value="0.000"/> |

| | |
|---|---------------------------------------|
| N | <input type="text" value="2000.000"/> |
|---|---------------------------------------|



| | |
|----|----------|
| E | 1800.000 |
| R | 0.000 |
| A1 | 0.000 |
| A2 | 0.000 |

The format of the above data to be transferred from the instrument to the computer is as follows:

START 0.000, 1050.000, 1100.000 CRLF
PT 1750.000, 1300.000, 100.000, 80.000, 80.000 CRLF
PT 1400.000, 1750.000, 200.000, 0.000, 0.000 CRLF
PT 1800.000, 1800.000, 2000.000 CRLF

2. Calculation of road alignment elements

(1) Calculation of curve length

$$L_{12} = \frac{A_{12}^2}{R}$$

L_{12} : curve length

A_{12} : curve parameter

R : radius

$$L_1 = \frac{A_1^2}{R} = \frac{80^2}{100} = 64 \text{ m}$$

$$L_2 = \frac{A_2^2}{R} = \frac{80^2}{100} = 64 \text{ m}$$

(2) Calculation of steering angle

$$\tau = \frac{L^2}{2A^2}$$

$$\tau_1 = \frac{64^2}{2 \cdot 80^2} = 0.32 \text{ rad} \quad \Rightarrow \quad \text{deg} \quad \Rightarrow \quad 0.32 \frac{180}{\pi} = 18^\circ 20' 06''$$

$$\therefore \tau_1 = -\tau_2$$

(3) Calculation of curve point coordinates

$$N = A \cdot \sqrt{2\tau} \left(1 - \frac{\tau^2}{10} + \frac{\tau^4}{216} - \frac{\tau^6}{9360} \dots \right)$$

$$E = A \cdot \sqrt{2\tau} \left(\frac{\tau}{3} - \frac{\tau^3}{42} + \frac{\tau^5}{1320} - \frac{\tau^7}{7560} \dots \right)$$



$$\begin{aligned}
 N &= 80 \cdot \sqrt{2 \cdot 0.32} \left(1 - \frac{(0.32)^2}{10} + \frac{(0.32)^4}{216} - \frac{(0.32)^6}{9360} \dots \right) \\
 &= 64 \left(1 - \frac{0.01024}{10} + \frac{0.0104857}{216} - \frac{0.00107344}{9360} \right) \\
 &= 64 \left(1 - 0.0104857 + 0.0004855 \right) \\
 &= 64 * 0.98981 \\
 &= 63.348
 \end{aligned}$$

Similarly, the value of E is:

$$\begin{aligned}
 E &= 80 \cdot \sqrt{2 \cdot 0.32} \left(\frac{0.32}{3} - \frac{(0.32)^3}{42} + \frac{(0.32)^5}{1320} - \frac{(0.32)^7}{7560} \dots \right) \\
 &= 64 (0.10666667000780490000026)
 \end{aligned}$$

This example shows a symmetric curve. N1=N2, E1=E2

(4) Calculation of rise ΔR

$$\begin{aligned}
 \Delta R &= E - R(1 - \cos \tau) \\
 \Delta R &= 6.777 - 100(1 - \cos 18^\circ 20' 06'') \\
 &= 1.700
 \end{aligned}$$

For a symmetric curve, $\Delta R_1 = \Delta R_2$.

(5) Calculation of transition point coordinates

$$N_m = N - R \sin \tau = 63.348 - 100 \sin 18^\circ 20' 06'' = 31.891$$

For a symmetric curve, $N_{m1} = N_{m2}$.

(6) Calculation of tangent length

$$\begin{aligned}
 D_1 &= R \tan\left(\frac{LA}{2}\right) + \Delta R_2 \csc(LA) - \Delta R_1 \cot(LA) + N_{m1} \\
 LA &= +111^\circ 55' 47'', \quad \csc = \frac{1}{\sin}, \quad \cot = \frac{1}{\tan} \\
 D_1 &= 100 * \tan(111^\circ 55' 47'' / 2) + 1.7(1 / \sin 111^\circ 55' 47'')
 \end{aligned}$$

$$\begin{aligned}
 &-1.7(1 / \tan 111^\circ 55' 47'') + 31.891 \\
 &= 148.06015 + 1.8326 + 0.6844 + 31.891 \\
 &= 182.468
 \end{aligned}$$

$$D_1 = D_2$$

(7) Calculation of coordinates of KA1

$$\begin{aligned}
 N_{KA1} &= N_{IPI} - D_1 \cdot \cos \alpha_1 \\
 E_{KA1} &= E_{IPI} - D_1 \cdot \sin \alpha_1
 \end{aligned}$$



Azimuth from BP to IP1 $\Rightarrow \alpha_1 = 74^\circ 03'16.6''$

$$N_{KA1} = 1300 - 182.468 * \cos 74^\circ 03'16.6'' = 1249.872 \text{ m}$$

$$E_{KA1} = 1750 - 182.468 * \sin 74^\circ 03'16.6'' = 1574.553 \text{ m}$$

(8) Calculation of curve length

$$\begin{aligned} L &= R(LA - \tau_1 + \tau_2) \\ &= R(111^\circ 55'47'' - 2 * 18^\circ 20'06'') \\ &= 100(75^\circ 15'35'' \frac{\pi}{180^\circ}) \\ &= 131.353 \text{ m} \end{aligned}$$

(9) Calculation of coordinates of KA2

$$\begin{aligned} N_{KA2} &= N_{IP1} - D_2 \cdot \cos \alpha_2 \\ E_{KA2} &= E_{IP1} - D_2 \cdot \sin \alpha_2 \end{aligned}$$

Azimuth from IP1 to IP2 $\Rightarrow \alpha_2 = 322^\circ 07'30.1''$

$$N_{KA2} = 1300 - (-182.468) * \cos 322^\circ 07'30.1'' = 1444.032 \text{ m}$$

$$E_{KA2} = 1750 - (-182.468) * \sin 322^\circ 07'30.1'' = 1637.976 \text{ m}$$

(10) Calculation of curve length feature point coordinates BC and EC

$$\text{Curve length } CL = R \cdot IA$$

$$IA = 95^\circ 52'11''$$

So,

$$CL = 200 * 95^\circ 52'11'' * \frac{\pi}{180^\circ} = 334.648 \text{ m}$$

Tangent length

$$TL = R \cdot \tan\left(\frac{IA}{2}\right) = 200 * \tan(95^\circ 52'11'' / 2) = 221.615 \text{ m}$$

Calculation of coordinates of each point is as follows:

$$N_{BC} = N_{IP2} - TL \cdot \cos \alpha_2$$

$$E_{BC} = E_{IP2} - TL \cdot \sin \alpha_2$$

$$N_{EC} = N_{IP2} - TL \cdot \cos \alpha_3$$

$$E_{EC} = E_{IP2} - TL \cdot \sin \alpha_3$$

Where:

$$\alpha_2 \text{ (Azimuth from IP1 to IP2)} = 322^\circ 07'30.1''$$

$$\alpha_3 \text{ (Azimuth from IP2 to EP)} = 57^\circ 59'40.6''$$




$$N_{BC} = 1750 - 221.615 * \cos 322^\circ 07' 30.1'' = 1575.068 \text{ m}$$

$$E_{BC} = 1400 - 221.615 * \sin 322^\circ 07' 30.1'' = 1536.058 \text{ m}$$

$$N_{EC} = 1750 - (-221.615) * \cos 57^\circ 59' 40.6'' = 1867.456 \text{ m}$$

$$E_{EC} = 1400 - (-221.615) * \sin 57^\circ 59' 40.6'' = 1587.929 \text{ m}$$

The diagram showing the calculation results is as follows:



Calculate coordinates and distances in the way described below:

1) Calculation of beeline length

Beeline

$$\text{BP KA1} = \sqrt{(1249.872 - 1100.000)^2 + (1574.553 - 1050)^2} = 545.543 \text{ m}$$

$$\text{Beeline KA2 BC} = \sqrt{(1575.068 - 1444.032)^2 + (1536.058 - 1637.976)^2} = 166.005 \text{ m}$$

Beeline

$$\text{EC EP} = \sqrt{(2000 - 1867.456)^2 + (1800 - 1587.929)^2} = 250.084 \text{ m}$$

Start point coordinates (BP)

N 1100.000 m

E 1050.000 m

Beeline between BP and KA1



Azimuth 74°03'16.6"

Distance 545.543 m

Curve between KA1 and KE1

Radius -100 m ("—" indicates the curve turns left toward the direction of the terminal)

Length 64 m

Curve between KE1 and KE2

Radius -100 m ("—" indicates the curve turns left toward the direction of the terminal)

Length 131.354 m

Curve between KE2 and KA2

Radius -100 m ("—" indicates the curve turns left toward the direction of the terminal)

Length 64 m

Beeline between KA2 and B

Azimuth 322°07'30.1"

Distance 166.004 m

Curve between BC and EC

Radius 200 m (no symbol before it indicates the curve turns right toward the direction of the terminal)

Length 334.648 m

Beeline between EC and EP

Azimuth 57°59'40.6"

Distance 250.084 m